



# Master Cross Reference Chart

Updated April 5, 2010

Includes: Pro A/V, Keyboard, Guitar, Recording, and DJ gear

| Manufacturer  | Model                | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)         |
|---------------|----------------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| 360 Systems   | DR600                | Digital Audio Gear | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    |                 |                 |
| 3M            | S15                  | Projector          | GAV-20          |                 |                 |                 |                 |
| 3M            | S40                  | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| 3M            | S50                  | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |                 |
| 3M            | S55                  | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| 3M            | X40                  | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| 3M            | X45                  | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| 3M            | X50                  | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| 3M            | X55                  | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| 3M            | X75                  | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |                 |
| Access        | VIRUS CLASSIC        | Keyboard           | G-MEDIA PROBPXL |                 |                 |                 |                 |
| Access        | VIRUS TI 61          | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Access        | VIRUS TI DESKTOP     | Keyboard           | G-MEDIA PROBPXL |                 |                 |                 |                 |
| Adam          | SUB10                | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| Adam          | SUB8                 | Speaker            | GPA-600         |                 |                 |                 |                 |
| Adam Audio    | SUB10 MKII           | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| Akai          | APC40                | Digital Audio Gear | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   |                 |
| Akai          | Miniak               | Keyboard           | G-MULTIFX-2411  |                 |                 |                 |                 |
| Akai          | MPC1000              | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOUR 12X17    |                 |
| Akai          | MPC2000XL-MCD        | Digital Audio Gear | GMC-2222        | G-MIX-B 1815    | G-MIX-B 1818    | G-MIX-B 2118    | G-MIX-L 1618A   |
| Akai          | MPC2500              | Digital Audio Gear | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   |                 |
| Akai          | MPC4000 PLUS         | Digital Audio Gear | G-MIX 19X21     | G-MIX-B 2118    | GP-PC309        | G-TOUR 19X21    | GX-1921-7.5     |
| Akai          | MPC500               | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Akai          | MPC5000              | Digital Audio Gear | GMC-2222        | G-MIX-B 1818    | G-MIX-L 1822    | G-TOUR 19X21    |                 |
| Akai          | MPD 32               | Digital Audio Gear | GKC-1540        |                 |                 |                 |                 |
| Akai          | MPD16                | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Akai          | MPD24                | Digital Audio Gear | G-MEDIA PRO BP  | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR 12X17    |                 |
| Akai          | MPK25                | Digital Audio Gear | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622    | G-TOURCARRYONFO |                 |
| Akai          | MPK49                | Keyboard           | GKC-1540        |                 |                 |                 |                 |
| Akai          | MPK88                | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Akai          | PDP4290              | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Akai          | PDP4294              | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Akai          | PDP4298ED            | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Akai          | PDP4298ED1           | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| AKG           | AS16X12              | Mixer              | G-MIX 12X24     |                 |                 |                 |                 |
| AKG           | AS8                  | Mixer              | G-MIX 12X24     |                 |                 |                 |                 |
| AKG           | AS8TC                | Mixer              | G-MIX 12X24     |                 |                 |                 |                 |
| AKG           | WMS40                | Wireless System    | GM-1W           | GM-1WP          | GM-2W           |                 |                 |
| Akira -Neoart | EMP 500              | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Akira -Neoart | EMP420A/B            | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Akira -Neoart | HPT500AW             | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Akira -Neoart | SV-4201              | LCD/Plasma         | G-LCDCOVER-42   |                 |                 |                 |                 |
| Akira -Neoart | SV-4201H             | LCD/Plasma         | G-LCDCOVER-42   |                 |                 |                 |                 |
| Akira -Neoart | SV4202IQ             | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |                 |
| Alesis        | A6                   | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Alesis        | ANDROMEDA            | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Alesis        | CD TWIN LE           | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                 |                 |                 |
| Alesis        | FUSION 6HD           | Keyboard           | GK-49           | GKC-1540        | G-TOUR 61       |                 |                 |
| Alesis        | FUSION 8HD           | Keyboard           | GK-76           | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Alesis        | iMultiMix 16 USB     | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622    | G-MIX-L 1724    | G-MIX-L 1822    |
| Alesis        | iMULTIMIX 16USB      | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622    | G-MIX-L 1724    | G-MIX-L 1822    |
| Alesis        | iMULTIMIX 8USB       | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |                 |
| Alesis        | ION                  | Keyboard           | GK-49           | GKC-1540        |                 |                 |                 |
| Alesis        | MasterControl        | Digital Audio Gear | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118    | G-MIX-L 1622    | G-TOUR 19X21    |
| Alesis        | MICRON               | Keyboard           | G-MULTIFX-2411  |                 |                 |                 |                 |
| Alesis        | MULTIMIX 12 FIREWIRE | Mixer              | G-MIX 17X18     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR CDMX1317 |                 |
| Alesis        | MULTIMIX 12 FX       | Mixer              | G-MIX 17X18     | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |
| Alesis        | MULTIMIX 12 USB      | Mixer              | G-MIX 17X18     | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |
| Alesis        | MULTIMIX 12FXD       | Mixer              | G-MIX 17X18     | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |
| Alesis        | MULTIMIX 16 FIREWIRE | Mixer              | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR CDMX1317 |                 |
| Alesis        | MultiMix 4 USB       | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Alesis        | MULTIMIX 6FX         | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Alesis        | MULTIMIX 8 FW        | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Alesis        | MULTIMIX 8 FX        | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Alesis        | MULTIMIX 8 USB       | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Alesis        | MULTIMIX 8 USB 2.0   | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Alesis        | MULTIMIX12FIREWIRE   | Digital Audio Gear | G-MIX 17X18     | G-MIX-B 1818    | G-MIX-L 1618A   |                 |                 |
| Alesis        | MULTIMIX16FIREWIRE   | Digital Audio Gear | GMC-2222        | G-MIX-B 1815    | G-MIX-B 1818    | G-MIX-B 2118    | G-MIX-L 1618A   |
| Alesis        | MULTIMIX8FIREWIRE    | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Alesis        | PHOTONX25            | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411  |                 |                 |
| Alesis        | QS6.2                | Keyboard           | GK-4212         | GKB-49          | GKPE-49-TSA     |                 |                 |
| Alesis        | QS8.2                | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76       |                 |                 |
| Alesis        | SR16                 | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |

| Manufacturer   | Model                   | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)         |
|----------------|-------------------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Alesis         | SR-16                   | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Alesis         | STUDIO 24               | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Allen & Heath  | GL2400 16               | Mixer              | GMC-3333        |                 |                 |                 |                 |
| Allen & Heath  | GL2400 24               | Mixer              | GMC-3333        |                 |                 |                 |                 |
| Allen & Heath  | PA 12                   | Mixer              | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118    | G-MIX-L 1822    | G-TOUR 19X21    |
| Allen & Heath  | PA 12-CP                | Mixer              | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118    | G-MIX-L 1822    | G-TOUR 19X21    |
| Allen & Heath  | PA-20                   | Mixer              | GMC-3333        |                 |                 |                 |                 |
| Allen & Heath  | WZ3:12:2                | Mixer              | G-MIX 20X25     |                 |                 |                 |                 |
| Allen & Heath  | WZ3:12M                 | Mixer              | G-MIX 20X25     |                 |                 |                 |                 |
| Allen & Heath  | WZ3:14:4:2              | Mixer              | G-MIX 20X25     |                 |                 |                 |                 |
| Allen & Heath  | WZ3:16:2                | Mixer              | G-MIX 20X25     |                 |                 |                 |                 |
| Allen & Heath  | WZ3:20S                 | Mixer              | G-MIX 20X25     |                 |                 |                 |                 |
| Allen & Heath  | XONE 464                | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1822    | G-TOUR 19X21    | GX-1921-7.5     |
| Allen & Heath  | ZED 420                 | Mixer              | GMC-3333        | G-TOUR 24X36    |                 |                 |                 |
| Allen & Heath  | ZED 436                 | Mixer              | G-MIX 22X46     |                 |                 |                 |                 |
| Allen & Heath  | ZED-12FX                | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622    | G-TOUR 19X21    |                 |
| Allen & Heath  | ZED-14                  | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622    | G-TOUR 19X21    |                 |
| Allen & Heath  | ZED-22FX                | Mixer              | GMC-3333        | G-MIX-L 1926    | G-TOUR 20X30    |                 |                 |
| Allen & Heath  | ZED-24                  | Mixer              | GMC-3333        | G-MIX-L 1926    | G-TOUR 20X30    |                 |                 |
| Allen & Heath  | ZED-R16                 | Mixer              | GMC-3333        | G-MIX 24X36     | G-TOUR 20X30    | G-TOUR 24X36    |                 |
| Alto Audio     | AMX 100                 | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Alto Audio     | AMX 100 FX              | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Alto Audio     | L-12                    | Mixer              | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1618A   | GX-1718-7       |                 |
| Alto Audio     | L-16                    | Mixer              | GMC-2222        | G-MIX-B 2020    |                 |                 |                 |
| Alto Audio     | L-20                    | Mixer              | GMC-2222        | G-MIX-B 2020    |                 |                 |                 |
| Alto Audio     | L-6                     | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Alto Audio     | L-8                     | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Alto Audio     | PM-12 DRAGONFLY         | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Alto Audio     | S-12                    | Mixer              | G-MIX 17X18     | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |
| Alto Audio     | S-16                    | Mixer              | GMC-2222        | G-MIX-B 1815    | G-MIX-B 1818    | G-MIX-B 2118    | G-MIX-L 1618A   |
| Alto Audio     | S-6                     | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Alto Audio     | S-8                     | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Alvarez        | AC60S                   | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Alvarez        | Artist Series AD60K Dao | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Alvarez        | Artist Series AD60S     | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Alvarez        | Artist Series AD70S     | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Alvarez        | Artist Series AD80SSB   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Alvarez        | CYM95                   | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Alvarez        | MC90                    | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Alvarez        | RC10                    | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Alvarez        | RD20S                   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Alvarez        | RD8                     | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Alvarez        | RD9                     | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| American Audio | CDI 300                 | CD/DVD Player      | G-TOUR CD-13X17 |                 |                 |                 |                 |
| American Audio | CDI 300 MP3             | CD/DVD Player      | G-TOUR CD-13X17 |                 |                 |                 |                 |
| American Audio | CDI 500                 | CD/DVD Player      | G-TOUR CD-13X17 |                 |                 |                 |                 |
| American Audio | CDI 500 MP3             | CD/DVD Player      | G-TOUR CD-13X17 |                 |                 |                 |                 |
| American Audio | CDS-1                   | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |                 |
| American Audio | CK-1000                 | Mixer              | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1618A   | G-MIX-L 1622    |                 |
| American Audio | CK-800                  | Mixer              | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1618A   | G-MIX-L 1622    |                 |
| American Audio | DLS-15                  | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| American Audio | DLS-15P                 | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| American Audio | HTD 4.5                 | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| American Audio | MX-1400                 | Mixer              | G-MIX 17X18     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR CDMX1317 |                 |
| American Audio | PSW-15                  | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| American Audio | PSW-15P                 | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| American Audio | PXI-12P                 | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| American Audio | PXI-15P                 | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| American Audio | Q-221                   | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |
| American Audio | Q-2221/SX               | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| American Audio | Q-2221/X                | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| American Audio | Q-D1                    | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| American Audio | Q-D1 MKII               | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| American Audio | Q-D3                    | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |
| American Audio | Q-D5                    | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |                 |
| American Audio | Q-D5 MKII               | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |                 |
| American Audio | Q-D5B                   | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |                 |
| American Audio | Q-D6                    | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |                 |
| American Audio | Q-MX2BPM                | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| American Audio | TTD-2500MKII            | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| American Audio | XDM-221                 | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| American Audio | XDM-241                 | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Ampeg          | BA600                   | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Ampeg          | J20                     | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Anchor Audio   | BWKII                   | Mixer              | G-MIX-B 1515    |                 |                 |                 |                 |
| Anchor Audio   | Liberty LIB-7500        | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| Apple          | 20 CINEMA DISPLAY       | LCD/Plasma         | G-TOURLCDP-2023 |                 |                 |                 |                 |
| Apple          | M8893ZM/A               | LCD/Plasma         | G-TOURLCDP-2023 |                 |                 |                 |                 |
| Apple          | MACBOOK 13"             | Laptop             | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |

| Manufacturer   | Model                 | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)         |
|----------------|-----------------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Apple          | MACBOOK AIR           | Laptop             | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| Apple          | MACBOOK PRO 15"       | Laptop             | GAV-1813-UR     |                 |                 |                 |                 |
| Apple          | MACBOOK PRO 17"       | Laptop             | GAV-1813-UR     |                 |                 |                 |                 |
| Arp            | ODYSSEY MKI (2800)    | Digital Audio Gear | G-MIX 20X25     | GP-PC309        |                 |                 |                 |
| Arturia        | ANALOG FACTORY        | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411  |                 |                 |
| Ashly          | LX308B                | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX-L 1224    | G-MULTIFX-2411  | G-TOURCARRYONFO | G-TOURCARRYONFO |
| Ashton         | BA50                  | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226  |                 |                 |
| Ashton         | MPA100                | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Audio Technica | ATM351                | Mixer              | G-MIX-B 1815    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |                 |
| Audio Technica | ATMX341A              | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Audio Technica | ATPL120               | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Audio Technica | ATW2120               | Wireless System    | GM-1W           | GM-2W           | GM-5W           |                 |                 |
| Audio Technica | ATW-2129              | Wireless System    | GM-1W           | GM-2W           | GM-5W           |                 |                 |
| Audio Technica | ATW-2192-TH           | Wireless System    | GM-1W           | GM-2W           | GM-5W           |                 |                 |
| Audio Technica | ATW-251               | Wireless System    | GM-1W           | GM-1WP          | GM-2W           | GM-5W           |                 |
| Audio Technica | ATW-251/H92-TH        | Wireless System    | GM-1W           | GM-1WP          | GM-2W           | GM-5W           |                 |
| Audio Technica | ATW-252               | Wireless System    | GM-1W           | GM-1WP          | GM-2W           | GM-5W           |                 |
| Audio Technica | ATW3131A              | Wireless System    | GM-1W           | GM-2W           |                 |                 |                 |
| Audio Technica | ATW3141A              | Wireless System    | GM-1W           | GM-2W           |                 |                 |                 |
| Audio Technica | ATW-3192A             | Wireless System    | GM-1W           | GM-2W           |                 |                 |                 |
| Audio Technica | ATW-3192A-TH          | Wireless System    | GM-1W           | GM-2W           |                 |                 |                 |
| Audio Technica | ATW-701               | Wireless System    | GM-1W           | GM-1WP          | GM-2W           | GM-5W           |                 |
| Audio Technica | ATW-701 700 Series    | Wireless System    | GM-1W           | GM-1WP          | GM-2W           | GM-5W           |                 |
| Audio Technica | ATW-701/H92-TH        | Wireless System    | GM-1W           | GM-1WP          | GM-2W           | GM-5W           |                 |
| Audio Technica | ATW-702               | Wireless System    | GM-1W           | GM-1WP          | GM-2W           | GM-5W           |                 |
| Azden          | CAM3                  | Mixer              | G-TOUR CDMX912  |                 |                 |                 |                 |
| B-52           | AT-100                | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |                 |
| B-52           | AT112                 | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226  |                 |                 |
| B-52           | AT212                 | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |                 |
| B-52           | LG10012S              | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| B-52           | LG-100A               | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| B-52           | LG200AS               | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| B-52           | LG7512                | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226  | G-TOUR AMP2430  |                 |
| B-52           | PRODIGY               | Mixer              | G-MIX 20X30     |                 |                 |                 |                 |
| B-52           | PRODIGY FX            | Mixer              | G-MIX 20X30     |                 |                 |                 |                 |
| B-52           | ST-100A               | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |                 |
| B-52           | ST6012                | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| B-52           | ST60A                 | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |                 |
| Behringer      | B1220 PRO             | Speaker            | GPA-700         |                 |                 |                 |                 |
| Behringer      | B212                  | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| Behringer      | B212A                 | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| Behringer      | B212XL                | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| Behringer      | B215                  | Speaker            | GPA-700         |                 |                 |                 |                 |
| Behringer      | B215A                 | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| Behringer      | B215XL                | Speaker            | GPA-700         |                 |                 |                 |                 |
| Behringer      | BCD2000               | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |
| Behringer      | BCF2000               | Digital Audio Gear | G-MEDIA PRO BP  | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR 12X17    |                 |
| Behringer      | BCR2000               | Digital Audio Gear | G-MEDIA PRO BP  | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR 12X17    |                 |
| Behringer      | BEDDX3216             | Mixer              | G-MIX 20X25     |                 |                 |                 |                 |
| Behringer      | BX4210A               | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Behringer      | DDM4000               | Digital Audio Gear | GMC-2222        | G-MIX-B 1815    | G-MIX-B 1818    | G-MIX-B 2118    | G-MIX-L 1618A   |
| Behringer      | DDX3216               | Mixer              | G-MIX 20X25     |                 |                 |                 |                 |
| Behringer      | DEEJAY BCD3000        | CD/DVD Player      | G-TOUR CD-13X17 |                 |                 |                 |                 |
| Behringer      | DJX400                | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX912  |                 |                 |
| Behringer      | DJX700                | Mixer              | G-MIX 17X18     | G-MIX-B 1818    | G-MIX-L 1618A   |                 |                 |
| Behringer      | DX052                 | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    |                 |                 |
| Behringer      | DX-626                | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Behringer      | E1220                 | Speaker            | GPA-600         |                 |                 |                 |                 |
| Behringer      | E1520                 | Speaker            | GPA-700         |                 |                 |                 |                 |
| Behringer      | Eurodesk SX3282       | Mixer              | GMC-4221        |                 |                 |                 |                 |
| Behringer      | EURORACK UB1202       | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Behringer      | EURORACK UB2442FX PRO | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1822    | G-TOUR 19X21    |
| Behringer      | EURORACK UB802        | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Behringer      | K1800FX               | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Behringer      | K900FX                | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Behringer      | KX1200                | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |                 |
| Behringer      | LC2412                | Digital Audio Gear | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1618A   | G-MULTIFX-2411  | G-TOURCARRYONFO |
| Behringer      | LX112                 | Amp/Cabinet        | G-112A          | G-TOUR AMP2226  | G-TOUR AMP2430  |                 |                 |
| Behringer      | MX1604A               | Mixer              | GMC-2222        | G-MIX-B 1515    | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR CDMX1317 |
| Behringer      | MX1804X               | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Behringer      | MX2004A               | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Behringer      | MX2442A               | Mixer              | GMC-3333        | G-MIX 24X36     | G-TOUR 20X30    | G-TOUR 24X36    |                 |
| Behringer      | MX3282A               | Mixer              | GMC-4221        |                 |                 |                 |                 |
| Behringer      | MX602A                | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Behringer      | MX802A                | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Behringer      | MX882                 | Digital Audio Gear | GK-2110         | G-MEDIA PROBPXL | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411  |
| Behringer      | MXB1002               | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Behringer      | PMH1000               | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Behringer      | PMH2000               | Mixer              | GPA-720         |                 |                 |                 |                 |

| Manufacturer | Model                   | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)        | Fit (5)         |
|--------------|-------------------------|--------------------|-----------------|-----------------|-----------------|----------------|-----------------|
| Behringer    | PMH3000                 | Mixer              | GMC-2222        | G-MIX 20X25     | G-MIX-B 2020    | G-TOUR 19X21   | GX-1921-7.5     |
| Behringer    | PMH5000                 | Mixer              | GMC-3333        | G-MIX 20X30     | G-TOUR 20X30    |                |                 |
| Behringer    | PMH518M                 | Mixer              | G-MIX-B 1815    |                 |                 |                |                 |
| Behringer    | PMP1000                 | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1618A  | G-TOUR 19X21    |
| Behringer    | PMP2000                 | Mixer              | GPA-720         |                 |                 |                |                 |
| Behringer    | PMP3000                 | Mixer              | GMC-2222        | G-MIX-B 2020    | G-MIX-B 2519    | G-TOUR 19X21   | GX-1921-7.5     |
| Behringer    | PMP5000                 | Mixer              | GMC-3333        | G-MIX 20X30     | G-TOUR 20X30    |                |                 |
| Behringer    | PMX 2000                | Mixer              | GPA-720         |                 |                 |                |                 |
| Behringer    | RX-1202FX               | Digital Audio Gear | GP-PC314        |                 |                 |                |                 |
| Behringer    | SL2442FX-PRO            | Mixer              | G-MIX 20X30     | G-TOUR 20X30    |                 |                |                 |
| Behringer    | SL3242FX-PRO            | Mixer              | GMC-4221        |                 |                 |                |                 |
| Behringer    | SX2442FX                | Mixer              | G-MIX 20X30     |                 |                 |                |                 |
| Behringer    | SX3242FX                | Mixer              | GMC-4221        |                 |                 |                |                 |
| Behringer    | UB1002                  | Mixer              | G-MIX-B 1212    |                 |                 |                |                 |
| Behringer    | UB1202                  | Mixer              | G-MIX-B 1212    |                 |                 |                |                 |
| Behringer    | UB1224FX-PRO            | Mixer              | G-MIX 17X18     | G-MIX-B 1818    | G-MIX-L 1618A   |                |                 |
| Behringer    | UB1622FX-PRO            | Mixer              | G-MIX 17X18     | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR 12X17   | G-TOUR CDMX1317 |
| Behringer    | UB1832FX-PRO            | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A  | G-TOUR 19X21    |
| Behringer    | UB2222FX-PRO            | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A  | G-TOUR 19X21    |
| Behringer    | UB2442FX-PRO            | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1822   | G-TOUR 19X21    |
| Behringer    | UB802                   | Mixer              | G-MIX-B 1212    |                 |                 |                |                 |
| Behringer    | UBB1002                 | Mixer              | G-MIX-B 1212    |                 |                 |                |                 |
| Behringer    | ULTRACOUSTIC ACX1800    | Amp/Cabinet        | G-112A          | G-TOUR AMP2226  |                 |                |                 |
| Behringer    | ULTRACOUSTIC ACX900     | Amp/Cabinet        | G-112A          | G-TOUR AMP2226  |                 |                |                 |
| Behringer    | ULTRASTACK BG412F       | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                |                 |
| Behringer    | ULTRASTACK BG412H       | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                |                 |
| Behringer    | ULTRASTACK BG412S       | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                |                 |
| Behringer    | V-AMPIRE LX1200H        | Amp/Cabinet        | G-901           |                 |                 |                |                 |
| Behringer    | VMX100                  | Mixer              | G-MIX-B 1212    |                 |                 |                |                 |
| Behringer    | VMX1000                 | Mixer              | G-MIX 12X24     |                 |                 |                |                 |
| Behringer    | VMX200                  | Mixer              | G-MIX-B 1212    |                 |                 |                |                 |
| Behringer    | VMX300                  | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                |                 |
| Behringer    | V-TONE GMX1200H         | Amp/Cabinet        | G-901           |                 |                 |                |                 |
| Behringer    | V-TONE GMX210           | Amp/Cabinet        | G-112A          | G-TOUR AMP2226  | G-TOUR AMP2430  |                |                 |
| Behringer    | V-TONE GMX212           | Amp/Cabinet        | G-212A          |                 |                 |                |                 |
| Behringer    | X V-AMP                 | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                |                 |
| Behringer    | XENYX 1002              | Mixer              | G-MIX-B 1212    |                 |                 |                |                 |
| Behringer    | XENYX 1002 FX           | Mixer              | G-MIX-B 1212    |                 |                 |                |                 |
| Behringer    | XENYX 1202              | Mixer              | G-MIX-B 1212    |                 |                 |                |                 |
| Behringer    | XENYX 1202 FX           | Mixer              | G-MIX-B 1212    |                 |                 |                |                 |
| Behringer    | XENYX 1204              | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                |                 |
| Behringer    | XENYX 1204FX            | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                |                 |
| Behringer    | XENYX 1222 FX           | Mixer              | G-MIX 17X18     | G-MIX-B 1818    | G-MIX-L 1618A   |                |                 |
| Behringer    | XENYX 1622 FX           | Mixer              | G-MIX 17X18     | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR 12X17   | G-TOUR CDMX1317 |
| Behringer    | XENYX 1832 FX           | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A  | G-TOUR 19X21    |
| Behringer    | XENYX 2222FX            | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A  | G-TOUR 19X21    |
| Behringer    | XENYX 2442 FX           | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1822   | G-TOUR 19X21    |
| Behringer    | XENYX 802               | Mixer              | G-MIX-B 1212    |                 |                 |                |                 |
| Belkin       | TUNE STUDIO             | Mixer              | G-MIX 17X18     |                 |                 |                |                 |
| Benchmark    | DAC1C                   | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                |                 |
| BenQ         | PB8220                  | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                |                 |
| BenQ / Acer  | 859                     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                |                 |
| BenQ / Acer  | 46W1                    | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                |                 |
| Bogner       | ALCHEMIST CAB           | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                |                 |
| Bogner       | ALCHEMIST HEAD          | Amp/Cabinet        | G-901           |                 |                 |                |                 |
| Bogner       | Alchemist Series 112    | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                |                 |
| Bogner       | Alchemist Series 212    | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                |                 |
| Bogner       | CAB 112O                | Amp/Cabinet        | G-112-ROTO      | G-TOUR AMP2226  |                 |                |                 |
| Bogner       | CAB 212C                | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                |                 |
| Bogner       | CUSTOM SHOP DUENDE HEAD | Amp/Cabinet        | G-901           |                 |                 |                |                 |
| Bogner       | CUSTOM SHOP ECSTASY 101 | Amp/Cabinet        | G-901           |                 |                 |                |                 |
| Bogner       | CUSTOM SHOP SHIVA HEAD  | Amp/Cabinet        | G-901           |                 |                 |                |                 |
| Bonger       | ALCHEMIST 212           | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                |                 |
| Bonger       | DUENDE110               | Amp/Cabinet        | G-212A          |                 |                 |                |                 |
| Bonger       | DUENDE112-15            | Amp/Cabinet        | G-212A          |                 |                 |                |                 |
| Bonger       | SHIVA112RV              | Amp/Cabinet        | G-212A          |                 |                 |                |                 |
| Bose         | B1                      | Speaker            | GPA-600         |                 |                 |                |                 |
| Bose         | T1 ToneMatch            | Mixer              | G-MIX-B 1212    |                 |                 |                |                 |
| Boss         | AD-3                    | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                |                 |
| Boss         | AD-8                    | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                |                 |
| Boss         | BR1180CD                | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX 12X24     | G-MIX-B 1815    | G-MIX-L 1224   | G-MULTIFX-2411  |
| Boss         | BR1200CD                | Digital Audio Gear | GMC-2222        | G-MIX 12X24     | G-MIX-L 1224    | G-MIX-L 1622   | G-MIX-L 1724    |
| Boss         | BR1600CD                | Digital Audio Gear | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118    | G-MIX-L 1622   |                 |
| Boss         | BR-600                  | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                |                 |
| Boss         | BR-864                  | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOUR 12X17   |                 |
| Boss         | BR-900CD                | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOURCARRONFO |                 |
| Boss         | DD-20                   | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                |                 |
| Boss         | DR. 880                 | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                |                 |
| Boss         | DR-3                    | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                |                 |

| Manufacturer  | Model         | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)         |
|---------------|---------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Boss          | DR-670        | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Boss          | GS-10         | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOUR 12X17    |                 |
| Boss          | GT-10         | Digital Audio Gear | GMC-2222        | GMC-2222        | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411  |
| Boss          | GT-10B        | Digital Audio Gear | GK-2110         | GMC-2222        | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411  |
| Boss          | GT-3          | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Boss          | GT-6          | Digital Audio Gear | GK-LT25W        | GMC-2222        | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411  |
| Boss          | GT-6B         | Digital Audio Gear | GK-LT25W        | GMC-2222        | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411  |
| Boss          | GT-8          | Digital Audio Gear | GK-LT25W        | GMC-2222        | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411  |
| Boss          | ME-20         | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                 |                 |                 |
| Boss          | ME-50         | Digital Audio Gear | G-MIX-B 1815    | G-TOUR 12X17    | G-TOURCARRYONFO |                 |                 |
| Boss          | ME-50B        | Digital Audio Gear | G-MEDIA PROBPXL | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOURCARRYONFO |                 |
| Boss          | ME-70         | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX-B 1815    | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOURCARRYONFO |
| Boss          | RE-20         | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Boss          | SP-505        | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                 |                 |                 |
| Boxlight      | 7200          | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |                 |
| Boxlight      | PD4600        | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Budda         | SUPERDRIVE 18 | Amp/Cabinet        | G-112-ROTO      | G-TOUR AMP2226  |                 |                 |                 |
| Cakewalk      | V Studio 100  | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Califone      | 1005AV        | Digital Audio Gear | GP-PC309        |                 |                 |                 |                 |
| Canon         | LV-5220       | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |                 |
| Canon         | LV-7220       | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |                 |
| Canon         | LV-7225       | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |                 |
| Canon         | LV-7230       | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |                 |
| Canon         | LV-X4         | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| Canon         | REALIS SX-50  | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |                 |
| Carl Martin   | QUATTRO       | Digital Audio Gear | G-MEDIA PROBPXL | G-MULTIFX-2411  |                 |                 |                 |
| Carlo Robelli | Acoustic Bass | Bass Guitar        | GL-AC-BASS      |                 |                 |                 |                 |
| Carlsbro      | COLT 40       | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Carlsbro      | COLT 85       | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Carlsbro      | DX 8-2 XP     | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1822    | G-TOUR 19X21    | GX-1921-7.5     |
| Casio         | 140           | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Casio         | 140S          | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Casio         | CDP-100       | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Casio         | CTK-2000      | Keyboard           | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Casio         | CTK-230       | Keyboard           | GKB-49          | GKPE-49-TSA     |                 |                 |                 |
| Casio         | CTK3000       | Keyboard           | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Casio         | CTK4000       | Keyboard           | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Casio         | CTK-496       | Keyboard           | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Casio         | CTK5000       | Keyboard           | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Casio         | CTK-691       | Keyboard           | GKB-61          | GKPE-61-TSA     | G-TOUR 61       |                 |                 |
| Casio         | CTK710        | Keyboard           | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Casio         | CTK800        | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Casio         | CTK810        | Keyboard           | GKB-61          | GKPE-61-TSA     | G-TOUR 61       |                 |                 |
| Casio         | CTK900        | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Casio         | LK100         | Keyboard           | GK-4212         | GKC-1540        |                 |                 |                 |
| Casio         | LK-2005       | Keyboard           | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Casio         | LK-220        | Keyboard           | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Casio         | LK-300TV      | Keyboard           | GKB-61          | GKPE-61-TSA     | G-TOUR 61       |                 |                 |
| Casio         | LK94          | Keyboard           | GKC-1540        | G-TOUR 61       |                 |                 |                 |
| Casio         | P70           | Keyboard           | GKPE-88SLXL-TSA |                 |                 |                 |                 |
| Casio         | P70S          | Keyboard           | GKPE-88SLXL-TSA |                 |                 |                 |                 |
| Casio         | PS20          | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Casio         | PX-100        | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Casio         | PX110         | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Casio         | PX-120        | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Casio         | PX-200        | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Casio         | PX-300        | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Casio         | PX-320        | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Casio         | PX-330        | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Casio         | PX500L        | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Casio         | WK-110        | Keyboard           | GK-76           | GKC-1648        | GKPE-76-TSA     | G-TOUR 76       |                 |
| Casio         | WK-1300       | Keyboard           | GKC-1648        |                 |                 |                 |                 |
| Casio         | WK-200        | Keyboard           | GK-76           | GKC-1648        |                 |                 |                 |
| Casio         | WK-3000       | Keyboard           | GKC-1648        |                 |                 |                 |                 |
| Casio         | WK3200        | Keyboard           | GKC-1648        |                 |                 |                 |                 |
| Casio         | WK-3300       | Keyboard           | GKC-1648        |                 |                 |                 |                 |
| Casio         | WK-3500       | Keyboard           | GKC-1648        |                 |                 |                 |                 |
| Casio         | WK3700        | Keyboard           | GKC-1648        |                 |                 |                 |                 |
| Casio         | WK-3800       | Keyboard           | GKC-1648        |                 |                 |                 |                 |
| Casio         | WK500         | Keyboard           | GK-76           | GKC-1648        |                 |                 |                 |
| Casio         | WK8000        | Keyboard           | GKC-1648        |                 |                 |                 |                 |
| Casio         | YPG-225       | Keyboard           | GK-76           | GKC-1648        | GKPE-76-TSA     | G-TOUR 76       |                 |
| Casio         | YPG-525       | Keyboard           | GK-88           | GKC-1648        | GKPE-88-TSA     | G-TOUR 88       |                 |
| Casio         | YPG-625       | Keyboard           | GKC-1648        | G-TOUR 88       |                 |                 |                 |
| Cerwin Vega   | CLS-155       | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| Cerwin Vega   | CVA-118       | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| Cerwin Vega   | HT2510        | Speaker            | GPA-600         |                 |                 |                 |                 |
| Cerwin Vega   | HTS-10        | Speaker            | GPA-600         |                 |                 |                 |                 |
| Cerwin Vega   | HTS15A        | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |

| Manufacturer | Model             | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)         |
|--------------|-------------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Cerwin Vega  | LW10              | Speaker            | GPA-600         |                 |                 |                 |                 |
| Cerwin Vega  | LW15              | Speaker            | GPA-777         |                 |                 |                 |                 |
| Cerwin Vega  | PSX-36            | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| Cerwin Vega  | SUB15 MKII        | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| Champion     | 42CV1             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Cicognani    | H150              | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Clavia       | G2X               | Keyboard           | GK-4212         |                 |                 |                 |                 |
| Clavia       | NORD ELECTRO 2 61 | Keyboard           | GK-4212         | GKB-49          | GKC-1540        | GKPE-49-TSA     |                 |
| Clavia       | NORD ELECTRO 61   | Keyboard           | GK-4212         | GKB-49          | GKC-1540        | GKPE-49-TSA     |                 |
| Clavia       | NORD LEAD 2       | Keyboard           | GK-4212         | GKB-49          |                 |                 |                 |
| Clavia       | NORD LEAD 2X      | Keyboard           | GK-4212         | GKB-49          | GKPE-49-TSA     |                 |                 |
| Clavia       | NORD LEAD 3       | Keyboard           | GK-4212         | GKB-49          | GKPE-49-TSA     |                 |                 |
| Clavia       | NORD MODULAR G2X  | Keyboard           | GK-4212         |                 |                 |                 |                 |
| Clavia       | NORD STAGE 76     | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76       |                 |                 |
| Clavia       | NORD STAGE 88     | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Clavia       | RACK2X            | Digital Audio Gear | G-MIX-B 1815    | G-TOURCARRYONFO | G-TOURCARRYONFO |                 |                 |
| Clavia       | RACK3             | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411  | G-TOURCARRYONFO |
| CME          | UF5               | Keyboard           | GK-49           | GKC-1540        |                 |                 |                 |
| CME          | UF50              | Keyboard           | GK-49           | GKC-1540        |                 |                 |                 |
| CME          | UF6               | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| CME          | UF60              | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| CME          | UF7               | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76       |                 |                 |
| CME          | UF70              | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76       |                 |                 |
| CME          | UF8               | Keyboard           | GKPE-88SLXL-TSA |                 |                 |                 |                 |
| CME          | UF80              | Keyboard           | GKPE-88SLXL-TSA |                 |                 |                 |                 |
| CME          | VX5               | Digital Audio Gear | GK-49           | GKC-1540        | GMC-4221        |                 |                 |
| CME          | VX6               | Digital Audio Gear | GK-61           | GKC-1540        | GKPE-61-TSA     | GMC-4221        |                 |
| CME          | VX7               | Digital Audio Gear | GK-76           | GKPE-76-TSA     |                 |                 |                 |
| CME          | VX8               | Digital Audio Gear | GKPE-88SLXL-TSA |                 |                 |                 |                 |
| Community    | SBS12             | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| Cooper Sound | SYSTEM 6          | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Cooper Sound | SYSTEM 8          | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Cordoba      | 32E               | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Cordoba      | 32EF              | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Cordoba      | 45FM              | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Cordoba      | 45FP              | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Cordoba      | 55R               | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Cordoba      | C5                | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Cordoba      | Cadete            | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Cordoba      | Requinto          | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Cordoba      | Solista           | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Cordoba      | Solista Flamenca  | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Cordova      | 45R               | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Cortex       | DMIX-300          | Mixer              | GMC-2222        | G-MIX-L 1224    | G-MIX-L 1622    |                 |                 |
| Cortex       | DMIX-600          | Mixer              | GMC-2222        | G-MIX-L 1224    | G-MIX-L 1622    |                 |                 |
| Cortex       | HDTT-5000         | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Crate        | BT220             | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Crate        | BV120HB           | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |                 |
| Crate        | BV150HB           | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Crate        | BV215S            | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Crate        | BV300HB           | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |                 |
| Crate        | BV412RVB          | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Crate        | BV412SL           | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Crate        | BV412ST           | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Crate        | BV412SVB          | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Crate        | BV6212            | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Crate        | CA125DG           | Amp/Cabinet        | G-112A          | G-TOUR AMP2226  |                 |                 |                 |
| Crate        | CSX-12            | Mixer              | GMC-3333        |                 |                 |                 |                 |
| Crate        | CSX-16            | Mixer              | GMC-3333        | G-TOUR 24X36    |                 |                 |                 |
| Crate        | FW120             | Amp/Cabinet        | G-TOUR AMP2430  |                 |                 |                 |                 |
| Crate        | FW120H            | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Crate        | FW412A            | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Crate        | FW412B            | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Crate        | GLX 212           | Amp/Cabinet        | G-TOUR AMP2430  |                 |                 |                 |                 |
| Crate        | GLX1200H          | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Crate        | GLX212            | Amp/Cabinet        | G-TOUR AMP2430  |                 |                 |                 |                 |
| Crate        | GLX412SL          | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Crate        | GLX412ST          | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Crate        | GLX50             | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Crate        | GLX65             | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Crate        | GT112SL           | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |                 |
| Crate        | GT1200H           | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Crate        | GT212             | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |                 |
| Crate        | GT30              | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Crate        | GT3500H           | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Crate        | GT412SL           | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Crate        | GT65              | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Crate        | GTX212            | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |                 |
| Crate        | GTX65             | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |

| Manufacturer    | Model                       | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)         |
|-----------------|-----------------------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Crate           | PX700DLX                    | Mixer              | GPA-720         |                 |                 |                 |                 |
| Crate           | V18-112                     | Amp/Cabinet        | G-112A          | G-TOUR AMP2226  | G-TOUR AMP2430  |                 |                 |
| Crate           | V18-212                     | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Crate           | V212T                       | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Crate           | V3112                       | Amp/Cabinet        | G-112A          | G-TOUR AMP2226  |                 |                 |                 |
| Crate           | V-33                        | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Crate           | VFX5112                     | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226  |                 |                 |
| Crate           | VFX5212                     | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Crate           | VTX200S                     | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Crate           | VTX212B                     | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Crate           | VTX350 HEAD                 | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Crate           | VTX65B                      | Amp/Cabinet        | G-112A          | G-TOUR AMP2226  |                 |                 |                 |
| Crate           | XT120R                      | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |                 |
| Creative        | PRODIKEYS                   | Keyboard           | GK-2110         | GK-LT25W        | G-MULTIFX-2411  |                 |                 |
| Creative-Labs   | PROKEYS PD-MIDI             | Keyboard           | GK-2110         | GK-LT25W        | G-MEDIA PROBPXL | G-MULTIFX-2411  |                 |
| Crest Audio     | XR20                        | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1822    | G-TOUR 19X21    | GX-1921-7.5     |
| Crest Audio     | XR24                        | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1822    | G-TOUR 19X21    | GX-1921-7.5     |
| Crest Audio     | XRM                         | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1822    | G-TOUR 19X21    | GX-1921-7.5     |
| Daewoo          | DP-425M                     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Daewoo          | DSP-4210GM                  | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Daewoo          | PD-42520W                   | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |                 |                 |
| Daewoo          | PPM-4253                    | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Dave Smith      | POLY EVOLVER KEYBOARD       | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Dave Smith      | POLY EVOLVER RACK           | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411  | G-TOURCARRYONFO |
| Dave Smith      | PROPHET 08                  | Keyboard           | GK-49           | GKC-1540        | GKPE-49-TSA     |                 |                 |
| DB Technologies | OPERA LIVE 402              | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| Dean            | Edge 5                      | Bass Guitar        | GC-BASS         | GPE-BASS-TSA    | G-TOUR BASS     | GW-BASS         | GW-BASS-TW      |
| Dean            | Espana CS                   | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Dean            | Espana CSCR                 | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Dean            | Espana CSR                  | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                 |
| Dean            | Tradition AK48              | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Dell            | INSPIRON 1200               | Laptop             | GAV-1412-R      | GAV-PE-1412R    |                 |                 |                 |
| Dell            | INSPIRON 1300               | Laptop             | GAV-1813-UR     |                 |                 |                 |                 |
| Dell            | INSPIRON 6000               | Laptop             | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| Dell            | INSPIRON 9400               | Laptop             | GAV-1813-UR     |                 |                 |                 |                 |
| Dell            | INSPIRON B120               | Laptop             | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| Dell            | INSPIRON E1505              | Laptop             | GAV-1813-UR     |                 |                 |                 |                 |
| Dell            | INSPIRON E1705              | Laptop             | GAV-1813-UR     |                 |                 |                 |                 |
| Dell            | LATITUDE C610               | Laptop             | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| Dell            | W4200                       | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Dell            | XPS M1210                   | Laptop             | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| Dell            | XPS M1710                   | Laptop             | GAV-1813-UR     |                 |                 |                 |                 |
| Delphi          | DD42 EVOLUTION              | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Delphi          | DD42 PANACHE                | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |                 |
| Delphi          | PRO42 EVOLUTION             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Delphi          | PRO42 PANACHE               | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |                 |
| Delta Lab       | DGFX1                       | Digital Audio Gear | G-MEDIA PRO BP  | G-MIX-L 1618A   | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOUR 12X17    |
| Denon           | DN-F400                     | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |                 |
| Denon           | DN-HS5500                   | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Denon           | DN-S1000                    | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |                 |
| Denon           | DN-S3700                    | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Denon           | DN-X100                     | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Denon           | DNX1100                     | Mixer              | G-MIX 17X18     | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |
| Denon           | DN-X1500                    | Mixer              | G-MIX-B 1515    | G-MIX-L 1618A   |                 |                 |                 |
| Denon           | DN-X300                     | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    |                 |                 |                 |
| Denon           | DP29F                       | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Denon           | RC-F400S                    | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |                 |
| Digidesign      | 003 FACTORY CONTROL SURFACE | Digital Audio Gear | GMC-2222        | G-MIX-B 2020    | GP-PC309        |                 |                 |
| Digidesign      | COMMAND 8                   | Digital Audio Gear | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1822    | G-TOUR 19X21    |
| Digidesign      | DIGI002                     | Digital Audio Gear | G-MIX 19X21     | G-MIX-B 2519    | G-MIX-L 1822    | G-TOUR 19X21    | GX-1921-7.5     |
| Digidesign      | DIGI-003                    | Digital Audio Gear | GMC-2222        | G-MIX-B 2020    | GP-PC309        |                 |                 |
| Digidesign      | MBOX2                       | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Digidesign      | MBOX2 PRO                   | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Digidesign      | OO2R                        | Digital Audio Gear | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622    | G-MIX-L 1724    | G-MIX-L 1822    |
| Digitech        | GNX1                        | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOURCARRYONFO |                 |
| Digitech        | GNX2                        | Digital Audio Gear | GK-2110         | G-MEDIA PROBPXL | G-MIX-B 1815    | G-MULTIFX-2411  | G-TOURCARRYONFO |
| Digitech        | GNX3                        | Digital Audio Gear | GK-2110         | GK-LT25W        | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411  |
| Digitech        | GNX3000                     | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX 12X24     | G-MIX-B 1815    | G-MIX-L 1224    | G-MULTIFX-2411  |
| Digitech        | GNX4                        | Digital Audio Gear | GK-2110         | GK-LT25W        | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411  |
| DigiTech        | RG335                       | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOUR 12X17    |                 |
| Digitech        | RP-1000                     | Digital Audio Gear | GK-LT25W        | G-MEDIA PROBPXL | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411  |
| Digitech        | RP150                       | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Digitech        | RP155                       | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Digitech        | RP250                       | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| DigiTech        | RP255                       | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOUR 12X17    |                 |
| Digitech        | RP350                       | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOUR 12X17    |                 |
| Digitech        | RP500                       | Digital Audio Gear | GK-LT25W        | G-MEDIA PROBPXL | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411  |
| Digitech        | RP90                        | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Digitech        | VL2                         | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |

| Manufacturer     | Model                          | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)         |
|------------------|--------------------------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Digittech        | VL4                            | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOURCARRYONFO |                 |
| Digittech        | VOCAL 300                      | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    |                 |                 |
| Dr. Z            | Maz 38                         | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Dynacord         | PM 1000                        | Digital Audio Gear | GP-PC309        |                 |                 |                 |                 |
| Dynaudio         | BM14S                          | Speaker            | GPA-600         |                 |                 |                 |                 |
| Dynex            | DX-L42-10A                     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| EAW              | FR129Z                         | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| EAW              | FR153Z                         | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| EAW              | SB120ZP                        | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| EAW              | SB150Z                         | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| EAW              | SB180ZP                        | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| EAW              | SM109Z                         | Speaker            | GPA-600         |                 |                 |                 |                 |
| EAW              | SM159Z                         | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| Edirol           | M-100FX                        | Digital Audio Gear | G-MEDIA PRO BP  |                 |                 |                 |                 |
| Edirol           | M10DX                          | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Edirol           | M-10DX                         | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Edirol           | M-10E                          | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Edirol           | M16DX                          | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOUR 12X17    |                 |
| Edirol           | M-16DX                         | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX912  |                 |                 |
| Edirol           | PCR-1                          | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411  |                 |                 |
| Edirol           | PCR300                         | Keyboard           | G-MULTIFX-2411  |                 |                 |                 |                 |
| Edirol           | PCR500                         | Keyboard           | GK-4212         |                 |                 |                 |                 |
| Edirol           | PCR800                         | Keyboard           | GK-4212         |                 |                 |                 |                 |
| Edirol           | PCR-A30                        | Keyboard           | G-MULTIFX-2411  |                 |                 |                 |                 |
| Edirol           | PCR-M1                         | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411  |                 |                 |
| Edirol           | PCR-M30                        | Keyboard           | G-MULTIFX-2411  |                 |                 |                 |                 |
| Edirol           | PCR-M50                        | Keyboard           | GK-4212         |                 |                 |                 |                 |
| Edirol           | PCR-M80                        | Keyboard           | GK-4212         |                 |                 |                 |                 |
| Edirol           | R-44                           | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Edirol           | SD20                           | Keyboard           | G-MULTIFX-1110  |                 |                 |                 |                 |
| Edirol           | UA101                          | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Edirol           | UA-700                         | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Edirol           | UM-550                         | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Edirol           | UR-80                          | Digital Audio Gear | G-MEDIA PROBPXL | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOURCARRYONFO |                 |
| Edirol           | V-4                            | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                 |                 |                 |
| Egnater          | Tourmaster Series 4212         | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Eiki             | LC-XB28                        | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| Eiki             | PLD-42UE                       | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |                 |
| Eiki             | PLD-42XU                       | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Eizo             | P5070                          | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Eizo             | P5071                          | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Electro Harmonix | Holy Stain                     | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Electro Harmonix | XO HOLY STAIN                  | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Electro Voice    | FORCE I 12"                    | Speaker            | GPA-450-515     |                 |                 |                 |                 |
| Electro Voice    | SB112                          | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| Electro Voice    | SBA760                         | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| Electro Voice    | SX100                          | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| Electro Voice    | SX250                          | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| Electro Voice    | SxA360                         | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| Electrograph     | DTS42                          | LCD/Plasma         | G-LCD-4042      | G-TOURLCDLIFT52 |                 |                 |                 |
| Electrograph     | DTS42DD                        | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |                 |
| Electrograph     | E4203DD                        | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |                 |
| Electro-Voice    | RE2                            | Wireless System    | GM-1WP          | GM-1WP          | GM-2W           | GM-5W           |                 |
| Electro-Voice    | RE2 Handheld                   | Wireless System    | GM-1WP          | GM-1WP          | GM-2W           | GM-5W           |                 |
| Emes             | AMBER                          | Speaker            | GPA-600         |                 |                 |                 |                 |
| E-MU             | 0404 USB                       | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| E-MU             | X BOARD 61                     | Keyboard           | GK-4212         |                 |                 |                 |                 |
| E-MU             | XBOARD 25                      | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411  |                 |                 |
| E-MU             | XBOARD 49                      | Keyboard           | GKPE-49-TSA     |                 |                 |                 |                 |
| Engl             | Powerball                      | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |                 |
| Envision         | A42W64                         | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Epiphone         | 1963 AJ-45                     | Acoustic Guitar    | GC-DREAD        | GC-JUMBO        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 |
| Epiphone         | 1966 G-400                     | SG Guitar          | GC-SG           |                 |                 |                 |                 |
| Epiphone         | AJ-1                           | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Epiphone         | AJ-200S                        | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Epiphone         | BLUES CUSTOM 30                | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |                 |
| Epiphone         | Collegiate                     | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK     |
| Epiphone         | Dove                           | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Epiphone         | DR-100                         | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Epiphone         | DR-200S                        | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Epiphone         | DR-212                         | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Epiphone         | G-310 SG                       | SG Guitar          | GC-SG           |                 |                 |                 |                 |
| Epiphone         | G-400 Custom                   | SG Guitar          | GC-SG           |                 |                 |                 |                 |
| Epiphone         | G-400 SG                       | SG Guitar          | GC-SG           |                 |                 |                 |                 |
| Epiphone         | Hummingbird                    | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Epiphone         | Joe Perry Boneyard LP Standard | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK     |
| Epiphone         | Les Paul Black Beauty          | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK     |
| Epiphone         | Les Paul Custom                | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK     |
| Epiphone         | Les Paul Special II            | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK     |



| Manufacturer | Model                                   | Type            | Fit (1)         | Fit (2)         | Fit (3)        | Fit (4)         | Fit (5)     |
|--------------|---|-----------------|-----------------|-----------------|----------------|-----------------|-------------|
| Epiphone     | Les Paul Standard                       | Les Paul Guitar | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS     | GWE-LPS CAMO    | GWE-LPS-BLK |
| Epiphone     | Les Paul Standard Plus Top              | Les Paul Guitar | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS     | GWE-LPS CAMO    | GWE-LPS-BLK |
| Epiphone     | Les Paul Studio                         | Les Paul Guitar | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS     | GWE-LPS CAMO    | GWE-LPS-BLK |
| Epiphone     | Les Paul Ultra                          | Les Paul Guitar | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS     | GWE-LPS CAMO    | GWE-LPS-BLK |
| Epiphone     | LP-100                                  | Les Paul Guitar | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS     | GWE-LPS CAMO    | GWE-LPS-BLK |
| Epiphone     | Masterbilt AJ-500M                      | Acoustic Guitar | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD    |
| Epiphone     | Masterbilt AJ-500R                      | Acoustic Guitar | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD    |
| Epiphone     | Masterbilt DR-500RA                     | Acoustic Guitar | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD    |
| Epiphone     | Masterbilt EF-500RA                     | Acoustic Guitar | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD    |
| Epiphone     | Paul McCartney 1964 Texan               | Acoustic Guitar | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD    |
| Epiphone     | PR-150                                  | Acoustic Guitar | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD    |
| Epiphone     | SG Special                              | SG Guitar       | GC-SG           |                 |                |                 |             |
| Epiphone     | SG Standard                             | SG Guitar       | GC-SG           |                 |                |                 |             |
| Epiphone     | SO CAL                                  | Amp/Cabinet     | G-TOUR AMP HEAD |                 |                |                 |             |
| Epiphone     | SO CAL 412SL                            | Amp/Cabinet     | G-TOUR-4X12-CAB |                 |                |                 |             |
| Epiphone     | Vintage G-400                           | SG Guitar       | GC-SG           |                 |                |                 |             |
| Epiphone     | Zackk Wylde Les Paul Custom             | Les Paul Guitar | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS     | GWE-LPS CAMO    | GWE-LPS-BLK |
| Epson        | 730                                     | Projector       | GAV-20          |                 |                |                 |             |
| Epson        | 760                                     | Projector       | GAV-20          |                 |                |                 |             |
| Epson        | 730C                                    | Projector       | GAV-20          |                 |                |                 |             |
| Epson        | 73C                                     | Projector       | GAV-1412-R      | GAV-PE-1412R    |                |                 |             |
| Epson        | S3                                      | Projector       | GAV-1412-R      | GAV-PE-1412R    |                |                 |             |
| ESP          | LTD Deluxe EC-1000                      | Les Paul Guitar | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS     | GWE-LPS CAMO    | GWE-LPS-BLK |
| ESP          | LTD EC-400                              | Les Paul Guitar | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS     | GWE-LPS CAMO    | GWE-LPS-BLK |
| ESP          | LTD KH-202 Kirk Hammett                 | Electric Guitar | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA   | GWE-ELEC        | GW-ELECTRIC |
| ESP          | M-1000                                  | Electric Guitar | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA   | GWE-ELEC        | GW-ELECTRIC |
| ESP          | M-200FM                                 | Electric Guitar | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA   | GWE-ELEC        | GW-ELECTRIC |
| E VH         | Eddie Van Halen Frankenstein            | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| FBT          | JOLLY SUB12A                            | Speaker         | G-SUB2225-24BAG |                 |                |                 |             |
| FBT          | JOLLY12RA                               | Speaker         | GPA-700         |                 |                |                 |             |
| FBT          | MAXX 2                                  | Speaker         | GPA-450-515     | GPA-777         | GPA-E15        | GPA-SCVR450-515 |             |
| FBT          | MAXX 4                                  | Speaker         | GPA-700         | GPA-SCVR450-515 |                |                 |             |
| FBT          | MAXX9SA                                 | Speaker         | G-SUB2225-24BAG |                 |                |                 |             |
| FBT          | VERVE 18S                               | Speaker         | GPA-450-515     | GPA-777         | GPA-E15        | GPA-SCVR450-515 |             |
| Fender       | '50s Precession Bass                    | Bass Guitar     | GW-BASS         | GWE-BASS        | GWE-BASS-PINK  |                 |             |
| Fender       | '51 Precession Bass                     | Bass Guitar     | GW-BASS         | GWE-BASS        | GWE-BASS-PINK  |                 |             |
| Fender       | 57 AMP LTD                              | Amp/Cabinet     | G-112-ROTO      |                 |                |                 |             |
| Fender       | 57 DELUXE                               | Amp/Cabinet     | G-112-ROTO      |                 |                |                 |             |
| Fender       | 57 TWIN                                 | Amp/Cabinet     | G-212A          | G-TOUR AMP2226  | G-TOUR AMP2430 |                 |             |
| Fender       | 59 BASSMAN                              | Amp/Cabinet     | G-TOUR AMP2430  |                 |                |                 |             |
| Fender       | '64 Jazz Bass Closet Classic            | Bass Guitar     | G-COBRA-BASS    | G-TOUR BASS     |                |                 |             |
| Fender       | '64 Jazz Bass Relic                     | Bass Guitar     | G-COBRA-BASS    | G-TOUR BASS     |                |                 |             |
| Fender       | 64 Vibroverb                            | Amp/Cabinet     | G-212A          | G-TOUR AMP2226  | G-TOUR AMP2430 |                 |             |
| Fender       | 65 DELUXE REVERB                        | Amp/Cabinet     | G-112A          | G-TOUR AMP2226  |                |                 |             |
| Fender       | 65 PRINCETON REVERB                     | Amp/Cabinet     | G-112-ROTO      |                 |                |                 |             |
| Fender       | 65 SUPER REVERB                         | Amp/Cabinet     | G-TOUR-4X12-CAB |                 |                |                 |             |
| Fender       | 65 TWIN REVERB                          | Amp/Cabinet     | G-212A          | G-TOUR AMP2430  |                |                 |             |
| Fender       | ACOUSTASONIC JR                         | Amp/Cabinet     | G-112A          | G-212-ROTO      | G-TOUR AMP2226 |                 |             |
| Fender       | AERODYNE Jazz Bass                      | Bass Guitar     | G-COBRA-BASS    | G-TOUR BASS     |                |                 |             |
| Fender       | American Ash Telecaster                 | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | American Deluxe Ash Strat               | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | American Deluxe Jazz Bass               | Bass Guitar     | G-COBRA-BASS    | G-TOUR BASS     |                |                 |             |
| Fender       | American Deluxe Precession Bass         | Bass Guitar     | GW-BASS         | GWE-BASS        | GWE-BASS-PINK  |                 |             |
| Fender       | American Deluxe Series Telecaster       | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | American Deluxe Stratocaster            | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | American Deluxe Stratocaster HSS        | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | American Jazz Bass                      | Bass Guitar     | G-COBRA-BASS    | G-TOUR BASS     |                |                 |             |
| Fender       | American Precession Bass                | Bass Guitar     | GW-BASS         | GWE-BASS        | GWE-BASS-PINK  |                 |             |
| Fender       | American Series Stratocaster HSS        | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | American Special HSS Stratocaster       | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | American Stratocaster                   | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | American Vintage '57 Precession Bass    | Bass Guitar     | GW-BASS         | GWE-BASS        | GWE-BASS-PINK  |                 |             |
| Fender       | American Vintage '62 Stratocaster       | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | Artist Series Eric Johnson Strat        | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | Artist Series Yngwie Malmsteen Strat    | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | BASSMAN 300                             | Amp/Cabinet     | G-212-ROTO      |                 |                |                 |             |
| Fender       | BLONDE HOT ROD DELUXE                   | Amp/Cabinet     | G-112A          | G-212-ROTO      | G-TOUR AMP2226 | G-TOUR AMP2430  |             |
| Fender       | BLUES DELUXE                            | Amp/Cabinet     | G-112A          | G-212-ROTO      | G-TOUR AMP2226 | G-TOUR AMP2430  |             |
| Fender       | BLUES DEVILLE                           | Amp/Cabinet     | G-TOUR AMP2430  |                 |                |                 |             |
| Fender       | CD100                                   | Acoustic Guitar | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD    |
| Fender       | CD-140SCE                               | Acoustic Guitar | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD    |
| Fender       | CD220CE                                 | Acoustic Guitar | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD    |
| Fender       | CD220S                                  | Acoustic Guitar | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD    |
| Fender       | CD-60                                   | Acoustic Guitar | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD    |
| Fender       | Classic Series '50s Stratocaster        | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | Classic Series '72 Telecaster Deluxe    | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | Classic Series '72 Telecaster Thinline  | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | Artist Series Eric Clapton Strat        | Electric Guitar | GWE-ELEC        |                 |                |                 |             |
| Fender       | Artist Series Reggie Hamilton Jazz Bass | Bass Guitar     | G-COBRA-BASS    | G-TOUR BASS     |                |                 |             |

| Manufacturer    | Model                              | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)      |
|-----------------|------------------------------------|--------------------|-----------------|-----------------|-----------------|-----------------|--------------|
| Fender          | CYBER TWIN                         | Amp/Cabinet        | G-212-ROTO      |                 |                 |                 |              |
| Fender          | Deluxe Active Jazz Bass            | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Deluxe Active Jazz Bass V          | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Deluxe Player's Stratocaster       | Electric Guitar    | GWE-ELEC        |                 |                 |                 |              |
| Fender          | Deluxe Precession Bass Special     | Bass Guitar        | GW-BASS         | GWE-BASS        | GWE-BASS-PINK   |                 |              |
| Fender          | Deluxe Series Nashville Telecaster | Electric Guitar    | GWE-ELEC        |                 |                 |                 |              |
| Fender          | DG100                              | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD     |
| Fender          | DUAL PROFESSIONAL                  | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |              |
| Fender          | FM 100H                            | Amp/Cabinet        | G-901           |                 |                 |                 |              |
| Fender          | FM 212R                            | Amp/Cabinet        | G-212A          | G-TOUR AMP2226  | G-TOUR AMP2430  |                 |              |
| Fender          | FM212 DSP                          | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |              |
| Fender          | FM412 SL                           | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |              |
| Fender          | FRONTMAN 212R                      | Amp/Cabinet        | G-212A          | G-TOUR AMP2226  | G-TOUR AMP2430  |                 |              |
| Fender          | Geddy Lee Jazz Bass                | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Highway One Jazz Bass              | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Highway One P Bass                 | Bass Guitar        | GW-BASS         | GWE-BASS        | GWE-BASS-PINK   |                 |              |
| Fender          | HOT ROD DELUXE                     | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226  | G-TOUR AMP2430  |              |
| Fender          | HOT ROD DEVILLE 212                | Amp/Cabinet        | G-212A          | G-TOUR AMP2226  | G-TOUR AMP2430  |                 |              |
| Fender          | HOT ROD DEVILLE 410                | Amp/Cabinet        | G-TOUR AMP2430  |                 |                 |                 |              |
| Fender          | Jaco Pastorius Relic Jazz Bass     | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Jaguar Bass                        | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Jazz Bass 24 V 5-String            | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Maerican Series Jazz Bass V        | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Marcus Miller Jazz Bass            | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Mark Hoppus Signature Bass         | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | MH-412                             | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |              |
| Fender          | MH500                              | Amp/Cabinet        | G-901           |                 |                 |                 |              |
| Fender          | PROSONIC 412                       | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |              |
| Fender          | Quilt-Top Jazz Bass 24             | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Reggie Hamilton Jazz Bass          | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Sonoran S                          | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD     |
| Fender          | STAGE 1000                         | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226  |                 |              |
| Fender          | STAGE 1600                         | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |              |
| Fender          | Standard Fretless Jazz Bass        | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Standard HSS Stratocaster          | Electric Guitar    | GWE-ELEC        |                 |                 |                 |              |
| Fender          | Standard Jazz Bass                 | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Standard Jazz Bass 5 String        | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Standard Precession Bass           | Bass Guitar        | GW-BASS         | GWE-BASS        | GWE-BASS-PINK   |                 |              |
| Fender          | Standard Stratocaster              | Electric Guitar    | GWE-ELEC        |                 |                 |                 |              |
| Fender          | Standard Telecaster                | Electric Guitar    | GWE-ELEC        |                 |                 |                 |              |
| Fender          | SUPER SONIC HEAD                   | Amp/Cabinet        | G-901           |                 |                 |                 |              |
| Fender          | SUPER-SONIC 112                    | Amp/Cabinet        | G-212-ROTO      |                 |                 |                 |              |
| Fender          | SUPER-SONIC 412                    | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |              |
| Fender          | TONE MASTER 412                    | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |              |
| Fender          | TWIN AMP                           | Amp/Cabinet        | G-TOUR AMP2430  |                 |                 |                 |              |
| Fender          | ULTIMATE CHORUS                    | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |              |
| Fender          | US Vintage '62 Jazz Bass           | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | VG Stratocaster                    | Electric Guitar    | GWE-ELEC        |                 |                 |                 |              |
| Fender          | VIBRO KING                         | Amp/Cabinet        | G-212A          |                 |                 |                 |              |
| Fender          | VIBRO KING 212                     | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |              |
| Fender          | VIBRO KING 3 10                    | Amp/Cabinet        | G-212A          |                 |                 |                 |              |
| Fender          | Victor Bailey Fretless Jazz Bass   | Bass Guitar        | G-COBRA-BASS    | G-TOUR BASS     |                 |                 |              |
| Fender          | Vintage Hod Rod '52 Telecaster     | Electric Guitar    | GWE-ELEC        |                 |                 |                 |              |
| Fishman         | Loud Box                           | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |              |
| Floyd Rose      | Discovery Series DST-3             | Electric Guitar    | GWE-ELEC        |                 |                 |                 |              |
| Focusrite       | SAFFIRE                            | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |              |
| Focusrite       | SAFFIRE LE                         | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |              |
| Fostex          | FR2                                | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |              |
| Fostex          | FR-2                               | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |              |
| Fostex          | FR2TC                              | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |              |
| Fostex          | LR-16                              | Mixer              | GMC-3333        | G-MIX 20X30     | G-MIX-B 2519    | G-MIX-L 1926    |              |
| Fostex          | MR-16HD                            | Digital Audio Gear | G-MIX 19X21     | G-MIX-B 2519    | G-MIX-L 1822    | GP-PC309        | G-TOUR 19X21 |
| Fostex          | MR-16HD/CD                         | Digital Audio Gear | G-MIX 19X21     | G-MIX-B 2519    | G-MIX-L 1822    | GP-PC309        | G-TOUR 19X21 |
| Fostex          | MR-8                               | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                 |                 |              |
| Fostex          | MR8 MKII                           | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |              |
| Fostex          | MR8-8 MK11                         | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    |                 | G-TOUR CDMX1317 |              |
| Fostex          | MR-8HD                             | Digital Audio Gear | G-MEDIA PRO BP  | G-MIX-L 1618A   | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOUR 12X17 |
| Fostex          | MR8HDCD                            | Digital Audio Gear | G-MEDIA PRO BP  | G-MIX-L 1618A   | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOUR 12X17 |
| Fostex          | VF160                              | Digital Audio Gear | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1618A   | GX-1718-7       |              |
| Fostex          | VF160EX                            | Digital Audio Gear | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1618A   | GX-1718-7       |              |
| Fostex          | VF80                               | Digital Audio Gear | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    |                 |              |
| Fostex          | VF80EX                             | Digital Audio Gear | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    |                 |              |
| Fostex          | X12                                | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |              |
| Frontier Design | ALPHA TRACK                        | Mixer              | G-TOUR CDMX912  |                 |                 |                 |              |
| Fujitsu         | P42HHA10                           | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |              |
| Fujitsu         | P42VHA10                           | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |              |
| Fujitsu         | P50XHA10                           | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |              |
| Fujitsu         | PDS-4201                           | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |              |
| Fujitsu         | PDS-4203                           | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |              |

| Manufacturer  | Model                                | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)     |
|---------------|--------------------------------------|--------------------|-----------------|-----------------|-----------------|-----------------|-------------|
| Fujitsu       | PDS-4204                             | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |             |
| Fujitsu       | PDS-4207                             | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |             |
| Fujitsu       | PDS-4208                             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Fujitsu       | PDS-4209                             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Fujitsu       | PDS-4210                             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Fujitsu       | PDS-4211                             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Fujitsu       | PDS-4212                             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Fujitsu       | PDS-4213                             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Fujitsu       | PDS-4214                             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Fujitsu       | PDS-4221                             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Fujitsu       | PDS-4222                             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Fujitsu       | PDS-4233                             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Fujitsu       | PDS-5001                             | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |             |
| Galaxy        | AS-ALS-4                             | Wireless System    | GM-1W           | GM-2W           |                 |                 |             |
| Gateway       | 42 ED & 42 HD                        | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Gateway       | 50 ED & 50 HD                        | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |             |
| Gateway       | GTW-P42M102                          | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Gateway       | GTW-P42M103                          | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Gateway       | GTW-P46M103                          | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |             |
| Gemini        | CDJ SERIES                           | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |             |
| Gemini        | CFX-30                               | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |             |
| Gemini        | DJ-USB TURNTABLE                     | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |             |
| Gemini        | GT-USB TURNTABLE                     | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |             |
| Gemini        | ICDJ                                 | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |             |
| Gemini        | iTRAX                                | Mixer              | G-MIX 17X18     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR CDMX1317 |             |
| Gemini        | MPX-30                               | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |             |
| Gemini        | PDM SERIES                           | Mixer              | G-MIX 12X24     |                 |                 |                 |             |
| Gemini        | PMX SERIES                           | Mixer              | G-MIX-B 1212    |                 |                 |                 |             |
| Gemini        | PS SERIES                            | Mixer              | G-MIX-B 1212    |                 |                 |                 |             |
| Genelec       | 7050B                                | Speaker            | GPA-600         |                 |                 |                 |             |
| Genelec       | 7070A                                | Speaker            | G-SUB2225-24BAG |                 |                 |                 |             |
| Genelec       | 7270A                                | Speaker            | G-SUB2225-24BAG |                 |                 |                 |             |
| General Music | S2                                   | Keyboard           | GKC-1648        |                 |                 |                 |             |
| Genz-Benz     | Shenandoah 100                       | Amp/Cabinet        | G-TOUR AMP2430  |                 |                 |                 |             |
| Gibson        | Angus Young Signature SG             | SG Guitar          | GC-SG           |                 |                 |                 |             |
| Gibson        | Billie Joe Armstrong Les Paul Junior | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | John Lennon Les Paul Junior          | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Limited Edition Les Paul             | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Slash Les Paul Signature             | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Hummingbird Artist                   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD    |
| Gibson        | Les Paul Antique                     | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul Antique Deluxe              | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul BFG                         | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul Classic                     | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul Classic Custom              | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul Classic Quilt Top           | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul Deluxe                      | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul Junior                      | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul Menace                      | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul Standard                    | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul Standard 50s Neck           | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul Standard 60s Neck           | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul Standard Double Cut Plus    | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul Studio                      | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul Supreme Figured             | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Les Paul Vintage                     | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Melody Maker                         | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | Melody Maker Dual Pickup             | Les Paul Guitar    | GC-LPS          | GPE-LPS-TSA     | G-TOUR LPS      | GWE-LPS CAMO    | GWE-LPS-BLK |
| Gibson        | SG '61 Reissue                       | SG Guitar          | GC-SG           |                 |                 |                 |             |
| Gibson        | SG Classic                           | SG Guitar          | GC-SG           |                 |                 |                 |             |
| Gibson        | SG Menace                            | SG Guitar          | GC-SG           |                 |                 |                 |             |
| Gibson        | SG Special                           | SG Guitar          | GC-SG           |                 |                 |                 |             |
| Gibson        | SG Special 3 Pickup                  | SG Guitar          | GC-SG           |                 |                 |                 |             |
| Gibson        | SG Standard 3 Single Coil            | SG Guitar          | GC-SG           |                 |                 |                 |             |
| Gibson        | SG Supreme                           | SG Guitar          | GC-SG           |                 |                 |                 |             |
| Gibson        | SG-3                                 | SG Guitar          | GC-SG           |                 |                 |                 |             |
| Gibson        | Super Goldtone GA30RV                | Amp/Cabinet        | G-212A          |                 |                 |                 |             |
| Gretsch       | G4510 Showdown                       | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD    |
| Gretsch       | VARIETY G6164                        | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |             |
| Guild         | D55                                  | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD    |
| Guild         | GAD-30R                              | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD    |
| Guild         | GAD-40C                              | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD    |
| Guild         | GAD-C2                               | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD    |
| Guild         | GAD-C3                               | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD    |
| Haier         | HL47E                                | LCD/Plasma         | G-TOURLCDLIFT52 |                 |                 |                 |             |
| Hammond       | XB-1                                 | Digital Audio Gear | GK-76           | GKPE-76-TSA     |                 |                 |             |
| Hammond       | XK-1                                 | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76       |                 |             |
| Hammond       | XK-2                                 | Keyboard           | GK-76           | GKC-1648        | GKPE-76-TSA     | G-TOUR 76       |             |
| Hammond       | XK-3                                 | Keyboard           | GK-76           | GKC-1648        | GKPE-76-TSA     | G-TOUR 76       |             |

| Manufacturer     | Model                         | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)     |
|------------------|-------------------------------|--------------------|-----------------|-----------------|-----------------|-----------------|-------------|
| Hammond          | XM2                           | Digital Audio Gear | G-MEDIA PROBPXL | G-MULTIFX-2411  |                 |                 |             |
| Hartke           | VX3500                        | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |             |
| Hercules         | DJ CONSOLE MK2                | Mixer              | G-MIX-B 1212    |                 |                 |                 |             |
| Hercules         | DJ Console Rmx Controller     | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |             |
| Hercules         | RMX                           | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |             |
| Hewlett-Pckrd    | PPL-4245N                     | LCD/Plasma         | G-LCD-4042      |                 |                 |                 |             |
| Hitachi          | 401XU                         | LCD/Plasma         | G-TOURLCDLIFT52 |                 |                 |                 |             |
| Hitachi          | 402HDE                        | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Hitachi          | 402HDU                        | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Hitachi          | 4120HDU                       | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Hitachi          | 42PMA500E                     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Hitachi          | CMP4201U                      | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Hitachi          | CMP4202U                      | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Hitachi          | CMP4211U                      | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Hitachi          | CMP-5000                      | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |             |
| Hitachi          | CP-R555                       | Projector          | GAV-20          |                 |                 |                 |             |
| Hitachi          | CP-S235W                      | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |             |
| Hitachi          | CP-S318                       | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |             |
| Hitachi          | CP-S335                       | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |             |
| Hitachi          | CP-X340                       | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |             |
| Hitachi          | CP-X345                       | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |             |
| Hitachi          | CP-X401                       | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |             |
| Hitachi          | CP-X443                       | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |             |
| Hitachi          | CP-X445W                      | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |             |
| Hitachi          | UT47V702                      | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |             |
| Hughes & Kettner | ALEX LIFESON SIGNATURE        | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |             |
| Hughes & Kettner | CC412A                        | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |             |
| Hughes & Kettner | DUOTONE                       | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |             |
| Hughes & Kettner | MATRIX 100                    | Amp/Cabinet        | G-901           |                 |                 |                 |             |
| Hughes & Kettner | PURETONE                      | Amp/Cabinet        | G-901           |                 |                 |                 |             |
| Hughes & Kettner | SWITCHBLADE 100 2X12          | Amp/Cabinet        | G-212A          | G-TOUR AMP2226  | G-TOUR AMP2430  |                 |             |
| Hughes & Kettner | SWITCHBLADE 100 HEAD          | Amp/Cabinet        | G-901           |                 |                 |                 |             |
| Hughes & Kettner | SWITCHBLADE 50                | Amp/Cabinet        | G-212-ROTO      | G-TOUR AMP2430  |                 |                 |             |
| Hughes & Kettner | TRIAMP MKII                   | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |             |
| Hughes & Kettner | WARP X                        | Amp/Cabinet        | G-901           |                 |                 |                 |             |
| Ibanez           | 2005 S2720FM                  | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | ATK Series                    | Bass Guitar        | GC-BASS         | GPE-BASS-TSA    | G-TOUR BASS     | GW-BASS         | GW-BASS-TW  |
| Ibanez           | AW800RNT                      | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD    |
| Ibanez           | GA3                           | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |             |
| Ibanez           | Gio Black Night Double Cuts   | Electric Guitar    | GSLING-ELEC     |                 |                 |                 |             |
| Ibanez           | Gio GRG170 Double Cut         | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | GRG170DX                      | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | GRX20                         | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | IJX121                        | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | IJX40                         | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | IS412C                        | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |             |
| Ibanez           | JEM7V Steve Vai Signature     | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | JS1000 2002                   | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | JS1200 Joe Satriani Signature | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | RG Series GRG170              | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | RG120                         | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | RG1570                        | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | RG2EX1                        | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | RG350MGX                      | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | RG370DXGP                     | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | RG3EXQM1                      | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | RG4EXQM1                      | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | RG7321                        | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | S520EX                        | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC |
| Ibanez           | SGT120NT                      | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD    |
| Ibanez           | SR300DX Soundgear             | Bass Guitar        | GW-BASS         | GWE-BASS        | GWE-BASS-PINK   |                 |             |
| Ibanez           | SR405 Soundgear               | Bass Guitar        | GW-BASS         | GWE-BASS        | GWE-BASS-PINK   |                 |             |
| Ibanez           | SR500 Soundgear               | Bass Guitar        | GC-BASS         | GPE-BASS-TSA    | G-TOUR BASS     | GW-BASS         | GW-BASS-TW  |
| Ibanez           | SR505                         | Bass Guitar        | GW-BASS         | GWE-BASS        | GWE-BASS-PINK   |                 |             |
| Ibanez           | SR900 Soundgear               | Bass Guitar        | GC-BASS         | GPE-BASS-TSA    | G-TOUR BASS     | GW-BASS         | GW-BASS-TW  |
| Ibanez           | SRX2EX1                       | Bass Guitar        | GC-BASS         | GPE-BASS-TSA    | G-TOUR BASS     | GW-BASS         | GW-BASS-TW  |
| Ibanez           | SRX300                        | Bass Guitar        | GC-BASS         | GPE-BASS-TSA    | G-TOUR BASS     | GW-BASS         | GW-BASS-TW  |
| Ibanez           | SRX3EXQM1                     | Bass Guitar        | GC-BASS         | GPE-BASS-TSA    | G-TOUR BASS     | GW-BASS         | GW-BASS-TW  |
| Ibanez           | SRX705                        | Bass Guitar        | GW-BASS         | GWE-BASS        | GWE-BASS-PINK   |                 |             |
| Ibanez           | TB100H                        | Amp/Cabinet        | G-901           |                 |                 |                 |             |
| Ibanez           | TBX150H                       | Amp/Cabinet        | G-901           |                 |                 |                 |             |
| Ibanez           | TBX150R                       | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |             |
| Ibanez           | TBX65R                        | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |             |
| Infocus          | IN24                          | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |             |
| Infocus          | LP 530                        | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |             |
| Insignia         | NS-L37Q-10A                   | LCD/Plasma         | G-LCDCOVER-42   |                 |                 |                 |             |
| Insignia         | NS-L42Q-10A                   | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Insignia         | NS-LCD37-09                   | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |             |
| Insignia         | NS-LCD47HD-09                 | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |             |

| Manufacturer  | Model                | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)         |
|---------------|----------------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Insignia      | NS-P42Q10A           | LCD/Plasma         | G-LCD-4042      | G-TOURLCDLIFT52 |                 |                 |                 |
| Insignia      | NS-P501Q-10A         | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Insignia      | NS-P502Q-10A         | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Inter-M       | A120                 | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR CDMX1317 |
| Inter-M       | A60                  | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR CDMX1317 |
| Inter-M       | CA 5130D             | Mixer              | GX-1224-8       |                 |                 |                 |                 |
| Inter-M       | CA 8320              | Mixer              | GPA-720         |                 |                 |                 |                 |
| Inter-M       | NX1243               | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622    | G-MIX-L 1724    | G-MIX-L 1822    |
| Inter-M       | PA1000B              | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Inter-M       | PA1000BR             | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Inter-M       | PA2000               | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR CDMX1317 |
| Inter-M       | PA4000               | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   |                 |
| Inter-M       | PA920                | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Inter-M       | PA935                | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Inter-M       | PAM120               | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Inter-M       | PAM60                | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Inter-M       | PAMCDA               | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Inter-M       | PAMD                 | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Inter-M       | PMC-05 PRO D         | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |
| Inter-M       | RMX1426              | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622    | G-MIX-L 1724    | G-MIX-L 1822    |
| Inter-M       | SMX812               | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Jackson       | DK2 Dinky            | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC     |
| Jackson       | DK2G Dinky           | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC     |
| Jackson       | DKMG Dinky           | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC     |
| Jackson       | double cut           | Electric Guitar    | GC-ELECTRIC-A   | G-COM-ELEC      | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        |
| Jackson       | MG Series DXMG Dinky | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC     |
| Jackson       | SL1 USA Soloist      | Electric Guitar    | GC-ELECTRIC-A   | GL-ELECTRIC     | GPE-ELEC-TSA    | GWE-ELEC        | GW-ELECTRIC     |
| Jamo          | D 7SUB               | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| Jazzkat       | TWINKAT 210          | Amp/Cabinet        | G-112A          |                 |                 |                 |                 |
| JBL           | EON10 G2             | Speaker            | GPA-600         |                 |                 |                 |                 |
| JBL           | EON15 G2             | Speaker            | GPA-700         |                 |                 |                 |                 |
| JBL           | EON1500              | Speaker            | GPA-700         |                 |                 |                 |                 |
| JBL           | EON15P-1             | Speaker            | GPA-700         |                 |                 |                 |                 |
| JBL           | EON305               | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| JBL           | EON315               | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| JBL           | EON515               | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| JBL           | EON518S              | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| JBL           | EONSUB G2            | Speaker            | GPA-700         |                 |                 |                 |                 |
| JBL           | JRX112M              | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| JBL           | JRX118S              | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| JBL           | MP418S               | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| JBL           | MRX512               | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| JBL           | PRX512M              | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| JBL           | PRX518S              | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| JBL           | SRX712M              | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| JBL           | VP7210               | Speaker            | GPA-450-515     |                 |                 |                 |                 |
| JBL           | VP7212M              | Speaker            | GPA-600         | GPA-SCVR450-515 |                 |                 |                 |
| JBL           | VRX915M              | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| JBL           | VRX932LA             | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| JBL           | VRX932LAP            | Speaker            | GPA-700         |                 |                 |                 |                 |
| Jean Baptiste | BCS396SM             | Electric Guitar    | GSLING-ELEC     |                 |                 |                 |                 |
| Johnson       | JM150                | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Johnson       | JM250H               | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |                 |
| Johnson       | JM60                 | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226  |                 |                 |
| Johnson       | JT50                 | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226  |                 |                 |
| JVC           | GD-V4200PZW          | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| JVC           | GD-V4210PZW          | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| JVC           | GD-V4211PCE          | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| JVC           | GD-V425PZW           | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |                 |
| JVC           | GD-V500PZU           | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| JVC           | GD-V501U             | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| JVC           | GM-P420UG            | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| JVC           | GM-V42UG             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| JVC           | LT-47X788            | LCD/Plasma         | G-LCDCOVER-52   |                 |                 |                 |                 |
| JVC           | PD-42DV2             | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| JVC           | PD-42V475            | LCD/Plasma         | G-LCD-4042      |                 |                 |                 |                 |
| JVC           | PD-42WV74            | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| JVC           | PD-42WV84            | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| JVC           | PD-42WX84            | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Kam           | CD DJ PACK           | CD/DVD Player      | G-TOUR CD-13X17 |                 |                 |                 |                 |
| Kawai         | EP3Kawai             | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Kawai         | ES6                  | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Ketron        | AUDYA 76             | Keyboard           | GK-76           | GKC-1648        | GKPE-76-TSA     | G-TOUR 76       |                 |
| Ketron        | Solton SD-1          | Keyboard           | GK-76           | GKC-1648        | GKPE-76-TSA     | G-TOUR 76       |                 |
| Konka         | KDL32AT23U           | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T |                 |                 |                 |
| Korg          | AX10A                | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                 |                 |                 |
| Korg          | AX10B                | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                 |                 |                 |
| Korg          | AX10G                | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                 |                 |                 |
| Korg          | AX1500G              | Digital Audio Gear | G-MEDIA PROBPXL | G-MULTIFX-2411  | G-TOURCARRYONFO | G-TOURCARRYONFO |                 |

| Manufacturer | Model              | Type               | Fit (1)         | Fit (2)         | Fit (3)        | Fit (4)        | Fit (5)         |
|--------------|--------------------|--------------------|-----------------|-----------------|----------------|----------------|-----------------|
| Korg         | AX3000G            | Digital Audio Gear | GK-LT25W        | G-MEDIA PROBPXL | G-MIX 12X24    | G-MIX-L 1224   | G-MULTIFX-2411  |
| Korg         | CR-4               | Digital Audio Gear | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815   | G-MIX-L 1618A  |                 |
| Korg         | CX3                | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA    | G-TOUR 61      |                 |
| Korg         | D1200 MKII         | Digital Audio Gear | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1618A  | G-MULTIFX-2411 | G-TOUR 12X17    |
| Korg         | D1600              | Digital Audio Gear | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118   | G-MIX-L 1822   | G-TOUR 19X21    |
| Korg         | D1600 MKII         | Digital Audio Gear | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118   | G-MIX-L 1822   | G-TOUR 19X21    |
| Korg         | D3200              | Digital Audio Gear | GMC-2222        | G-MIX-B 2519    | G-MIX-L 1622   |                |                 |
| Korg         | D888               | Digital Audio Gear | GMC-2222        | G-MIX-B 1515    | G-MIX-L 1618A  |                |                 |
| Korg         | EMX1               | Digital Audio Gear | GMC-2222        | G-MIX-B 1515    | G-MIX-L 1618A  | G-MULTIFX-1510 | G-TOUR 12X17    |
| Korg         | ESX1               | Digital Audio Gear | GMC-2222        | G-MIX-B 1515    | G-MIX-L 1618A  | G-MULTIFX-1510 | G-TOUR 12X17    |
| Korg         | K61P               | Keyboard           | GK-4212         |                 |                |                |                 |
| Korg         | KAOSS PAD 3        | Digital Audio Gear | G-MIX-B 1212    |                 |                |                |                 |
| Korg         | KARMA              | Keyboard           | GK-76           | GKPE-61-TSA     | G-TOUR 61      |                |                 |
| Korg         | KONTROL49          | Keyboard           | GKC-1540        |                 |                |                |                 |
| Korg         | KORG M1            | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA    | G-TOUR 61      |                 |
| Korg         | M3 73              | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76      |                |                 |
| Korg         | M3 88              | Keyboard           | GK-88           | GKC-1648        | GKPE-88-TSA    | G-TOUR 88      |                 |
| Korg         | M3-61              | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA    | G-TOUR 61      |                 |
| Korg         | M50-61             | Keyboard           | GK-4212         |                 |                |                |                 |
| Korg         | M50-88             | Keyboard           | GKPE-88SLXL-TSA |                 |                |                |                 |
| Korg         | MICROKONTROL       | Keyboard           | GK-2110         | GK-LT25W        | G-MULTIFX-2411 |                |                 |
| Korg         | MICROKORG          | Keyboard           | GK-2110         | GK-LT25W        | G-MULTIFX-2411 |                |                 |
| Korg         | microKORG XL       | Keyboard           | GK-2110         | GK-LT25W        | G-MULTIFX-2411 |                |                 |
| Korg         | MICROX             | Keyboard           | G-MULTIFX-2411  |                 |                |                |                 |
| Korg         | MR-1000            | Digital Audio Gear | G-MIX-B 1212    |                 |                |                |                 |
| Korg         | MS2000             | Keyboard           | GKC-1540        |                 |                |                |                 |
| Korg         | MSR2000B           | Keyboard           | GKC-1540        |                 |                |                |                 |
| Korg         | OASYS 76           | Keyboard           | GKC-1648        |                 |                |                |                 |
| Korg         | OASYS 88           | Keyboard           | GKC-1648        | G-TOUR 88       |                |                |                 |
| Korg         | PA1X PRO           | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM |                |                 |
| Korg         | PA1X PRO ELITE     | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM |                |                 |
| Korg         | PA2XPRO            | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76      |                |                 |
| Korg         | PA50               | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA    | G-TOUR 61      |                 |
| Korg         | PA-588             | Keyboard           | GKC-1648        | G-TOUR 88       |                |                |                 |
| Korg         | PA80               | Keyboard           | GKC-1648        |                 |                |                |                 |
| Korg         | PA88               | Keyboard           | GKC-1648        | G-TOUR 88       |                |                |                 |
| Korg         | PADKONTROL         | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                |                |                 |
| Korg         | PAD-KONTROL        | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17   | G-TOUR 12X17   |                 |
| Korg         | PROPHECY           | Keyboard           | GKB-49          |                 |                |                |                 |
| Korg         | R3                 | Keyboard           | GK-LT25W        |                 |                |                |                 |
| Korg         | RADIAS 49-KEY      | Keyboard           | GKC-1540        |                 |                |                |                 |
| Korg         | RADIAS SYNTHESIZER | Keyboard           | GKC-1540        |                 |                |                |                 |
| Korg         | SP-200             | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM |                |                 |
| Korg         | SP-250             | Keyboard           | GK-76           | GKC-1648        | GKPE-76-TSA    | G-TOUR 76      |                 |
| Korg         | SP-300             | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM |                |                 |
| Korg         | SP-500             | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76      |                |                 |
| Korg         | SV1                | Keyboard           | GK-76           |                 |                |                |                 |
| Korg         | TR61               | Keyboard           | GK-4212         |                 |                |                |                 |
| Korg         | TR88               | Keyboard           | GKPE-88SLXL-TSA |                 |                |                |                 |
| Korg         | TRITON EXTREME 61  | Keyboard           | GK-76           | GKPE-61-TSA     | G-TOUR 61      |                |                 |
| Korg         | TRITON EXTREME 76  | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM |                |                 |
| Korg         | TRITON EXTREME 88  | Keyboard           | GK-88           | GKC-1648        | GKPE-88-TSA    | G-TOUR 88      |                 |
| Korg         | TRITON LE 61       | Keyboard           | GK-4212         |                 |                |                |                 |
| Korg         | TRITON LE 88       | Keyboard           | GKPE-88SLXL-TSA |                 |                |                |                 |
| Korg         | TRITON STUDIO 61   | Keyboard           | GK-76           | GKC-1648        | GKPE-61-TSA    | G-TOUR 61      |                 |
| Korg         | TRITON STUDIO 88   | Keyboard           | GKC-1648        | G-TOUR 88       |                |                |                 |
| Korg         | TRITON STUDIO 76   | Keyboard           | GK-88           | GKC-1648        | GKPE-88-TSA    | G-TOUR 88      |                 |
| Korg         | X3                 | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA    | G-TOUR 61      |                 |
| Korg         | X-50               | Keyboard           | GK-4212         |                 |                |                |                 |
| Korg         | X5D                | Keyboard           | GK-4212         |                 |                |                |                 |
| Korg         | ZERO 4             | Mixer              | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1618A  | G-TOUR 12X17   | G-TOUR CDMX1317 |
| Korg         | ZERO 8             | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815   | G-MIX-L 1618A  | G-TOUR 19X21    |
| Kurzweil     | K2600              | Keyboard           | GK-76           | GKC-1648        | GKPE-76-TSA    | G-TOUR 76      |                 |
| Kurzweil     | K2600S             | Keyboard           | GK-76           | GKC-1648        | GKPE-76-TSA    | G-TOUR 76      |                 |
| Kurzweil     | K2600X             | Keyboard           | GK-88           | GKC-1648        | GKPE-88-TSA    | G-TOUR 88      |                 |
| Kurzweil     | K2600XS            | Keyboard           | GK-88           | GKC-1648        | GKPE-88-TSA    | G-TOUR 88      |                 |
| Kurzweil     | K2661              | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA    | G-TOUR 61      |                 |
| Kurzweil     | PC161              | Keyboard           | GK-4212         | GKC-1540        |                |                |                 |
| Kurzweil     | PC1SE              | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76      |                |                 |
| Kurzweil     | PC-1X              | Keyboard           | GKPE-88SLXL-TSA |                 |                |                |                 |
| Kurzweil     | PC-1XL             | Keyboard           | GKPE-88SLXL-TSA |                 |                |                |                 |
| Kurzweil     | PC2X               | Keyboard           | GKPE-88SLXL-TSA |                 |                |                |                 |
| Kurzweil     | PC3                | Keyboard           | GKPE-88SLXL-TSA |                 |                |                |                 |
| Kurzweil     | PC3X               | Keyboard           | GKPE-88SLXL-TSA |                 |                |                |                 |
| Kurzweil     | PC88               | Keyboard           | GKPE-88SLXL-TSA |                 |                |                |                 |
| Kurzweil     | SP2                | Keyboard           | GKPE-88SLXL-TSA |                 |                |                |                 |
| Kurzweil     | SP3X               | Keyboard           | GKPE-88SLXL-TSA |                 |                |                |                 |
| Kurzweil     | SP-76              | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76      |                |                 |
| Kurzweil     | SP-88              | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM |                |                 |

| Manufacturer | Model                 | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)         |
|--------------|-----------------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Kurzweil     | SP-88X                | Keyboard           | GKPE-88SLXL-TSA |                 |                 |                 |                 |
| Kustom       | KPC12                 | Speaker            | GPA-777         |                 |                 |                 |                 |
| Kustom       | KPC12M                | Speaker            | GPA-777         |                 |                 |                 |                 |
| Kustom       | KPM8420               | Mixer              | GPA-720         |                 |                 |                 |                 |
| Kustom       | KPM8420T              | Mixer              | GPA-720         |                 |                 |                 |                 |
| L-Acoustics  | SB15P                 | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| Lexicon      | ALPHA                 | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Lexicon      | LAMBDA                | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Lexicon      | OMEGA                 | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| LG           | 32LC5DC               | LCD/Plasma         | G-TOURLCDP-2632 |                 |                 |                 |                 |
| LG           | 32LG70                | LCD/Plasma         | G-TOURLCDP-2632 |                 |                 |                 |                 |
| LG           | 32LH40                | LCD/Plasma         | G-TOURLCDP-2632 |                 |                 |                 |                 |
| LG           | 37LC-7D               | LCD/Plasma         | G-LCDCOVER-42   |                 |                 |                 |                 |
| LG           | 37LH20                | LCD/Plasma         | G-LCDCOVER-42   |                 |                 |                 |                 |
| LG           | 37LH30                | LCD/Plasma         | G-LCDCOVER-42   |                 |                 |                 |                 |
| LG           | 42LG50                | LCD/Plasma         | G-LCD-4042      | G-TOURLCDLIFT52 |                 |                 |                 |
| LG           | 42LG70                | LCD/Plasma         | G-LCD-4042      | G-TOURLCDLIFT52 |                 |                 |                 |
| LG           | 42LH30                | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| LG           | 42LH40                | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| LG           | 42PC3DV               | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| LG           | 42PC5D                | LCD/Plasma         | G-LCD-4042      |                 |                 |                 |                 |
| LG           | 42PQ30C               | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| LG           | 47LG50                | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| LG           | 47LG60                | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| LG           | 47LG70                | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| LG           | 47LG90                | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| LG           | 47LH30                | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| LG           | 47LH40                | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| LG           | 47LH50                | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| LG           | 50PM1M                | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| LG           | 50Pq20                | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| LG           | 50PQ30C               | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| LG           | 50PS60C               | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| LG           | 52LB5D                | LCD/Plasma         | G-LCDCOVER-52   |                 |                 |                 |                 |
| LG           | 52LG50                | LCD/Plasma         | G-LCDCOVER-52   |                 |                 |                 |                 |
| LG           | 60PS60C               | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |                 |
| LG           | DU42PX12              | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| LG           | M3702C-BA             | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |                 |
| LG           | M4210N-B21            | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| LG           | M4212C-BA             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| LG           | M4212T-BA             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| LG           | M4224C-BA             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T |                 |                 |                 |
| LG           | M4714C-BA             | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |                 |
| LG           | M4714T-BA             | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |                 |
| LG           | M5201C-BA             | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |                 |
| LG           | MU-40PA10B            | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |                 |                 |
| LG           | MU-42PM11             | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |                 |
| LG           | MU-42PZ11B            | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| LG           | MU-42PZ15B            | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| LG           | MU50PM10              | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| LG           | MU60P                 | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |                 |
| LG           | RU42DX11              | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Line 6       | 212S CAB              | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Line 6       | 412CB                 | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Line 6       | 412S CAB              | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Line 6       | AX2                   | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Line 6       | BASS FLOOR POD        | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOUR 12X17    |                 |
| Line 6       | BASS POD              | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Line 6       | BASS POD PRO          | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX-L 1224    | G-MULTIFX-2411  | G-TOURCARRYONFO | G-TOURCARRYONFO |
| Line 6       | BASS POD XT LIVE      | Digital Audio Gear | GK-2110         | GMC-2222        | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411  |
| Line 6       | BASS POD-PRO          | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX-L 1224    | G-MULTIFX-2411  | G-TOURCARRYONFO | G-TOURCARRYONFO |
| Line 6       | BASS XT PRO           | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX-L 1224    | G-MULTIFX-2411  | G-TOURCARRYONFO | G-TOURCARRYONFO |
| Line 6       | BOD                   | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Line 6       | BOD XT PRO            | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX-L 1224    | G-MULTIFX-2411  | G-TOURCARRYONFO | G-TOURCARRYONFO |
| Line 6       | CLASSIC 112 (FLEX 3)  | Amp/Cabinet        | G-TOUR AMP2226  |                 |                 |                 |                 |
| Line 6       | CLASSIC 212 (FLEX 3)  | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Line 6       | CLASSIC PLUS (FLEX 3) | Amp/Cabinet        | G-TOUR AMP2226  |                 |                 |                 |                 |
| Line 6       | DL4                   | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Line 6       | DM4                   | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Line 6       | DUOVERB 212           | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Line 6       | DUOVERB HEAD          | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Line 6       | FBC                   | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411  | G-TOURCARRYONFO |
| Line 6       | FLEXTONE II           | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226  |                 |                 |
| Line 6       | FLEXTONE II HD        | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Line 6       | FLEXTONE II PLUS      | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226  |                 |                 |
| Line 6       | FLEXTONE II XL        | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Line 6       | FLEXTONE III 112      | Amp/Cabinet        | G-112A          | G-TOUR AMP2226  |                 |                 |                 |
| Line 6       | FLEXTONE III PLUS 112 | Amp/Cabinet        | G-112A          | G-TOUR AMP2226  |                 |                 |                 |
| Line 6       | FLEXTONE III XL       | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |

| Manufacturer | Model                   | Type               | Fit (1)         | Fit (2)         | Fit (3)        | Fit (4)         | Fit (5)         |
|--------------|-------------------------|--------------------|-----------------|-----------------|----------------|-----------------|-----------------|
| Line 6       | FLOOR POD               | Digital Audio Gear | GK-LT25W        | GMC-2222        | G-MIX 12X24    | G-MIX-L 1224    | G-MULTIFX-2411  |
| Line 6       | Floor POD Plus          | Digital Audio Gear | GMC-2222        | G-MEDIA PROBPXL | G-MIX 12X24    | G-MIX-L 1224    | G-MULTIFX-2411  |
| Line 6       | FM4                     | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                |                 |                 |
| Line 6       | HD 147                  | Amp/Cabinet        | G-901           |                 |                |                 |                 |
| Line 6       | LD15                    | Amp/Cabinet        | G-112-ROTO      |                 |                |                 |                 |
| Line 6       | M 13 STOMPBOX           | Digital Audio Gear | GMC-2222        | G-MIX 17X18     | G-MIX-B 1815   | G-MIX-L 1618A   | G-TOUR 12X17    |
| Line 6       | MM4                     | Digital Audio Gear | G-MIX-B 1212    |                 |                |                 |                 |
| Line 6       | POD 2.0                 | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                |                 |                 |
| Line 6       | POD PRO                 | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX-L 1224    | G-MULTIFX-2411 | G-TOURCARRYNFO  |                 |
| Line 6       | POD PRO XT              | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX-L 1224    | G-MULTIFX-2411 | G-TOURCARRYNFO  |                 |
| Line 6       | POD STUDIO UX2          | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                |                 |                 |
| Line 6       | POD X3                  | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                |                 |                 |
| Line 6       | POD X3 LIVE             | Digital Audio Gear | GK-2110         | G-MIX 12X24     | G-MIX-L 1224   | G-MULTIFX-2411  |                 |
| Line 6       | POD XT (SHARC POD)      | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                |                 |                 |
| Line 6       | POD XT LIVE             | Digital Audio Gear | GK-2110         | GMC-2222        | G-MIX 12X24    | G-MIX-L 1224    | G-MULTIFX-2411  |
| Line 6       | POD XT PRO              | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX-L 1224    | G-MULTIFX-2411 | G-TOURCARRYNFO  |                 |
| Line 6       | POD-Pro                 | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX-L 1224    | G-MULTIFX-2411 | G-TOURCARRYNFO  |                 |
| Line 6       | SPIDER 212              | Amp/Cabinet        | G-212A          |                 |                |                 |                 |
| Line 6       | SPIDER II 112           | Amp/Cabinet        | G-112A          | G-TOUR AMP2226  |                |                 |                 |
| Line 6       | SPIDER II 210           | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226 |                 |                 |
| Line 6       | SPIDER II 212           | Amp/Cabinet        | G-901           |                 |                |                 |                 |
| Line 6       | SPIDER II 412           | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                |                 |                 |
| Line 6       | SPIDER II HD            | Amp/Cabinet        | G-901           |                 |                |                 |                 |
| Line 6       | SPIDER II HD75          | Amp/Cabinet        | G-901           |                 |                |                 |                 |
| Line 6       | SPIDER III 120          | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226 |                 |                 |
| Line 6       | SPIDER III 150          | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                |                 |                 |
| Line 6       | SPIDER III 75           | Amp/Cabinet        | G-112A          | G-TOUR AMP2226  |                |                 |                 |
| Line 6       | SPIDER III HD150        | Amp/Cabinet        | G-901           |                 |                |                 |                 |
| Line 6       | SPIDER III HD75         | Amp/Cabinet        | G-901           |                 |                |                 |                 |
| Line 6       | SPIDER VALVE 212        | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                |                 |                 |
| Line 6       | SPIDER VALVE MKII HD100 | Amp/Cabinet        | G-901           |                 |                |                 |                 |
| Line 6       | STONEPORT GX1           | Digital Audio Gear | G-MIX-B 1212    |                 |                |                 |                 |
| Line 6       | STONEPORT KB37          | Keyboard           | GK-2110         | GK-LT25W        | G-MULTIFX-2411 |                 |                 |
| Line 6       | STONEPORT UX1           | Digital Audio Gear | G-MIX-B 1212    |                 |                |                 |                 |
| Line 6       | VETTA HEAD              | Amp/Cabinet        | G-901           |                 |                |                 |                 |
| Line 6       | VETTA II CAB            | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                |                 |                 |
| Line 6       | VETTA II HEAD           | Amp/Cabinet        | G-901           |                 |                |                 |                 |
| Ltd          | ESP double cut          | Electric Guitar    | GC-ELECTRIC-A   | G-TOUR ELEC     | GW-ELECTRIC    | GW-ELECTRIC-TW  | GW-ELECT-VIN    |
| Ltd          | ESP single cut          | Les Paul Guitar    | GC-LPS          | G-TOUR LPS      |                |                 |                 |
| Mackie       | 1501                    | Speaker            | GPA-700         |                 |                |                 |                 |
| Mackie       | 1202 VLZ PRO            | Mixer              | G-MIX-B 1212    |                 |                |                 |                 |
| Mackie       | 1202-VLZ3               | Mixer              | G-MIX-B 1212    |                 |                |                 |                 |
| Mackie       | 1402 VLZ PRO            | Mixer              | G-MIX 17X18     | G-MIX-B 1818    | G-MIX-L 1618A  | G-TOUR CDMX1317 |                 |
| Mackie       | 1402-VLZ3               | Mixer              | G-MIX 17X18     | G-MIX-B 1818    | G-MIX-L 1618A  | G-TOUR CDMX1317 |                 |
| Mackie       | 1604 VLZ PRO            | Mixer              | GMC-2222        | G-MIX-B 1818    | G-MIX-L 1822   | G-TOUR 19X21    | GX-1921-7.5     |
| Mackie       | 1604-VLZ3               | Mixer              | GMC-2222        | G-MIX-B 1818    | G-MIX-L 1822   | G-TOUR 19X21    | GX-1921-7.5     |
| Mackie       | 1642 VLZ Pro            | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818   | G-MIX-L 1822    | G-TOUR 19X21    |
| Mackie       | 1642-VLZ3               | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818   | G-MIX-L 1822    | G-TOUR 19X21    |
| Mackie       | 24E                     | Mixer              | GMC-3333        |                 |                |                 |                 |
| Mackie       | 24X4                    | Mixer              | GMC-3333        |                 |                |                 |                 |
| Mackie       | 802-VLZ3                | Mixer              | G-MIX-B 1212    |                 |                |                 |                 |
| Mackie       | C200                    | Speaker            | GPA-450-515     | GPA-777         | GPA-E15        |                 |                 |
| Mackie       | C300Z                   | Speaker            | GPA-450-515     | GPA-777         | GPA-E15        | GPA-SCVR450-515 |                 |
| Mackie       | CFX 12                  | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818   | G-MIX-L 1618A   | G-TOUR 19X21    |
| Mackie       | CFX 16                  | Mixer              | GMC-2222        | G-MIX-B 2519    | G-MIX-L 1622   |                 |                 |
| Mackie       | CFX 20                  | Mixer              | G-MIX 20X30     | G-TOUR 20X30    |                |                 |                 |
| Mackie       | CFX12mk2                | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622   | G-TOUR 19X21    | GX-1921-7.5     |
| Mackie       | CFX16mk2                | Mixer              | G-MIX 20X25     | G-MIX-B 2519    | G-MIX-L 1724   |                 |                 |
| Mackie       | CFX20mk2                | Mixer              | G-MIX 20X30     |                 |                |                 |                 |
| Mackie       | CONTROL UNIVERSAL PRO   | Digital Audio Gear | GMC-2222        | G-MIX-B 1818    | G-MIX-L 1822   | G-TOUR 19X21    | GX-1921-7.5     |
| Mackie       | D2                      | Mixer              | G-MIX-B 1815    | G-TOUR 12X17    | GX-1           | GX-2            | GX-3            |
| Mackie       | d4 Pro                  | Mixer              | GMC-2222        | G-MIX-B 1515    | G-MIX-L 1618A  |                 |                 |
| Mackie       | HR624                   | Speaker            | GPA-600         |                 |                |                 |                 |
| Mackie       | HR626                   | Speaker            | GPA-450-515     |                 |                |                 |                 |
| Mackie       | HRS120                  | Speaker            | G-SUB2225-24BAG |                 |                |                 |                 |
| Mackie       | HUI                     | Mixer              | GMC-2222        | G-MIX-B 1818    | G-MIX-L 1822   | G-TOUR 19X21    | GX-1921-7.5     |
| Mackie       | LINK USB                | Digital Audio Gear | G-MIX-B 1212    |                 |                |                 |                 |
| Mackie       | MS1402-VLZ              | Mixer              | G-MIX 17X18     | G-MIX-B 1818    | G-MIX-L 1618A  | G-TOUR CDMX1317 |                 |
| Mackie       | ONYX 1220i              | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815   | G-MIX-L 1618A   | G-TOUR CDMX1317 |
| Mackie       | ONYX 1620               | Mixer              | G-MIX 19X21     | G-MIX-B 2118    | G-MIX-L 1822   | G-TOUR 19X21    | GX-1921-7.5     |
| Mackie       | ONYX 1620i              | Mixer              | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118   | G-MIX-L 1724    | G-TOUR 19X21    |
| Mackie       | ONYX 1640               | Mixer              | G-MIX 20X25     |                 |                |                 |                 |
| Mackie       | ONYX 820i               | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    |                |                 |                 |
| Mackie       | PPM1008                 | Mixer              | GPA-720         |                 |                |                 |                 |
| Mackie       | PPM1012                 | Mixer              | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118   | G-MIX-L 1822    | G-TOUR 19X21    |
| Mackie       | PPM608                  | Mixer              | GPA-720         |                 |                |                 |                 |
| Mackie       | PRO FX12                | Mixer              | GMC-2222        | G-MIX-B 1515    | G-MIX-L 1618A  | GX-1718-7       |                 |
| Mackie       | PRO FX8                 | Mixer              | G-MIX 20X25     | G-MIX-B 2519    | G-MIX-L 1926   | G-TOUR 20X30    |                 |
| Mackie       | SATELLITE BASE          | Digital Audio Gear | G-MIX-B 1212    |                 |                |                 |                 |



| Manufacturer | Model            | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)         |
|--------------|------------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Mackie       | SR32.4 VLZ PRO   | Mixer              | GMC-4221        |                 |                 |                 |                 |
| Mackie       | SRM350           | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         |                 |                 |
| Mackie       | SRM450           | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| Mackie       | SRM450-V2        | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| Mackie       | SWA1501          | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| Mackie       | TAPCO 6306       | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Mackie       | U.420            | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Mackie       | DFX 12           | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Mackie       | DFX 6            | Mixer              | GMC-2222        | G-MIX-B 1515    | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR CDMX1317 |
| Mackie       | ONYX 1220        | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   | GX-1718-7       |
| Mackie       | SR24.4 VLZ PRO   | Mixer              | GMC-3333        |                 |                 |                 |                 |
| Marantz      | CDR310           | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Marantz      | PD4293D          | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Marantz      | PD5010D          | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Marantz      | PMD671           | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Marshall     | 1912             | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Marshall     | 1922             | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |                 |
| Marshall     | 1936             | Amp/Cabinet        | G-TOUR AMP2430  |                 |                 |                 |                 |
| Marshall     | 2203             | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | 2245             | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | 2266             | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | 2466             | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | 4100             | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |                 |
| Marshall     | 1959SLPX         | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | 1962BLUESBREAKER | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Marshall     | 1982 AJH         | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Marshall     | 1987X            | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | 2061 CX          | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Marshall     | 2061X            | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Marshall     | 2203K            | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | 2266C            | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Marshall     | 425A             | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Marshall     | 425B             | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Marshall     | AS50D            | Amp/Cabinet        | G-112A          | G-TOUR AMP2226  |                 |                 |                 |
| Marshall     | AVT100X          | Amp/Cabinet        | G-TOUR AMP2226  |                 |                 |                 |                 |
| Marshall     | AVT112X          | Amp/Cabinet        | G-TOUR AMP2226  |                 |                 |                 |                 |
| Marshall     | AVT150           | Amp/Cabinet        | G-112-ROTO      | G-TOUR AMP2226  | G-TOUR AMP2430  |                 |                 |
| Marshall     | AVT150H          | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | AVT150HX         | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | AVT150X          | Amp/Cabinet        | G-TOUR AMP2226  |                 |                 |                 |                 |
| Marshall     | AVT20X           | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Marshall     | AVT275X          | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |                 |
| Marshall     | AVT412A          | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Marshall     | AVT412B          | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Marshall     | AVT412XA         | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Marshall     | AVT412XB         | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Marshall     | AVT50H           | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | AVT50HX          | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | AVT50X           | Amp/Cabinet        | G-112-ROTO      | G-TOUR AMP2226  |                 |                 |                 |
| Marshall     | AVT-50X          | Amp/Cabinet        | G-112-ROTO      | G-TOUR AMP2226  |                 |                 |                 |
| Marshall     | B65              | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Marshall     | DSL100           | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | DSL401           | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226  |                 |                 |
| Marshall     | DSL50            | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | JCM800           | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | JCM800 2203X     | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | JCM900           | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | JCM-900          | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | JTM100           | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | JTM45            | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | JVM410C          | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Marshall     | JVM410H          | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | LEAD 100 MOSFET  | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | MA100H           | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | MA50C            | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | MA50H            | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | MB4210           | Amp/Cabinet        | G-212A          | G-TOUR AMP2226  | G-TOUR AMP2430  |                 |                 |
| Marshall     | MB60             | Amp/Cabinet        | G-TOUR AMP2226  |                 |                 |                 |                 |
| Marshall     | MBC115           | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Marshall     | MBC410           | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Marshall     | MC412A           | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Marshall     | MF350            | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | MG100DFX         | Amp/Cabinet        | G-TOUR AMP2226  |                 |                 |                 |                 |
| Marshall     | MG250 DFX        | Amp/Cabinet        | G-212A          | G-TOUR AMP2226  | G-TOUR AMP2430  |                 |                 |
| Marshall     | MG250DFX         | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |                 |
| Marshall     | MG412            | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                 |
| Marshall     | MG50DFX          | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Marshall     | SUPER100JH       | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Marshall     | TSL100           | Amp/Cabinet        | G-901           |                 |                 |                 |                 |

| Manufacturer | Model                  | Type               | Fit (1)         | Fit (2)         | Fit (3)        | Fit (4)         | Fit (5)      |
|--------------|------------------------|--------------------|-----------------|-----------------|----------------|-----------------|--------------|
| Marshall     | TSL122                 | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                |                 |              |
| Marshall     | TSL60                  | Amp/Cabinet        | G-901           |                 |                |                 |              |
| Marshall     | TSL601                 | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226 |                 |              |
| Marshall     | TSL602                 | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                |                 |              |
| Marshall     | VBA400                 | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                |                 |              |
| Marshall     | VM2266C                | Amp/Cabinet        | G-TOUR AMP2430  |                 |                |                 |              |
| Marshall     | VM2266H                | Amp/Cabinet        | G-901           |                 |                |                 |              |
| Marshall     | VM2466H                | Amp/Cabinet        | G-901           |                 |                |                 |              |
| Martin       | Cowboy V               | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | D12-28                 | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | D12X1                  | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | D-15                   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | D-16GT                 | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | D-16RGT                | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | D-18VE                 | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | D-28                   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | D-35                   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | D-42                   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DC-15E                 | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DC-16RE Aura           | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DC-16RGTE Aura         | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DC-28E                 | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DCME                   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DCX1E                  | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DCX1KE                 | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DM                     | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DM12                   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DR                     | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DSR                    | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DX1                    | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DX1E                   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DX1K                   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | DXM                    | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | HD-16R LSH             | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | HD-28                  | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | HD-28V                 | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | HD-28VE                | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | M-42                   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | MMW                    | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| Martin       | SWDGT                  | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD     |
| M-Audio      | 2                      | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411 |                 |              |
| M-Audio      | AXIOM 25               | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411 |                 |              |
| M-Audio      | AXIOM 49               | Keyboard           | GK-49           | GKB-49          | GKB-49         | GKPE-49-TSA     | GKPE-49-TSA  |
| M-Audio      | AXIOM 61               | Keyboard           | GK-4212         |                 |                |                 |              |
| M-Audio      | BLACK BOX              | Digital Audio Gear | G-MIX-B 1212    |                 |                |                 |              |
| M-Audio      | FIREWIRE 1814          | Digital Audio Gear | G-MIX-B 1212    |                 |                |                 |              |
| M-Audio      | FIREWIRE 410           | Digital Audio Gear | G-MIX-B 1212    |                 |                |                 |              |
| M-Audio      | FIREWIRE SOLO          | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17   | G-TOUR 12X17    |              |
| M-Audio      | KEYSTATION 61ES        | Keyboard           | GK-4212         |                 |                |                 |              |
| M-Audio      | MICROTRACK II          | Mixer              | G-TOUR CDMX912  |                 |                |                 |              |
| M-Audio      | MIDAIR 25 KEY          | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411 |                 |              |
| M-Audio      | MIDAIR 37              | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411 |                 |              |
| M-Audio      | NRV10                  | Mixer              | GMC-2222        | G-MIX-L 1618A   | G-TOUR 12X17   | G-TOUR CDMX1317 | GX-1         |
| M-Audio      | O2 25 KEY              | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411 |                 |              |
| M-Audio      | OXYGEN 49              | Keyboard           | GKPE-49-TSA     |                 |                |                 |              |
| M-Audio      | OXYGEN 61              | Keyboard           | GK-4212         |                 |                |                 |              |
| M-Audio      | OXYGEN 8 V2            | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411 |                 |              |
| M-Audio      | OXYGEN8                | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411 |                 |              |
| M-Audio      | OZONE                  | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411 |                 |              |
| M-Audio      | PRO88                  | Keyboard           | GKPE-88SLXL-TSA |                 |                |                 |              |
| M-Audio      | PROJECT MIN I/O        | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                |                 |              |
| M-Audio      | PROJECT MIX I/O        | Digital Audio Gear | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118   | G-MIX-L 1926    | G-TOUR 19X21 |
| M-Audio      | PROJECTMIX I/O         | Digital Audio Gear | GP-PC301        |                 |                |                 |              |
| M-Audio      | RADIUM49               | Keyboard           | GKPE-49-TSA     |                 |                |                 |              |
| M-Audio      | RADIUM61               | Keyboard           | GK-4212         |                 |                |                 |              |
| M-Audio      | SONO61                 | Keyboard           | GK-4212         |                 |                |                 |              |
| M-Audio      | TORQ XPONENT           | Mixer              | GMC-2222        | G-MIX-L 1618A   | G-MIX-L 1622   |                 |              |
| M-Audio      | TRIGGERFINGER          | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                |                 |              |
| Maxent       | MX-42VM10              | LCD/Plasma         | G-LCD-4647      |                 |                |                 |              |
| mesa boogie  | Mark V                 | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226 |                 |              |
| Mesaboogie   | 112 LONESTAR 23        | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226 |                 |              |
| Mesaboogie   | 112 LONESTAR 27        | Amp/Cabinet        | G-212-ROTO      |                 |                |                 |              |
| Mesaboogie   | 112 THREE-QUARTER BACK | Amp/Cabinet        | G-212A          |                 |                |                 |              |
| Mesaboogie   | 112 WIDE BODY          | Amp/Cabinet        | G-112A          | G-212-ROTO      | G-TOUR AMP2226 |                 |              |
| Mesaboogie   | 212 LONESTAR           | Amp/Cabinet        | G-212-ROTO      |                 |                |                 |              |
| Mesaboogie   | 212 THREE-QUARTER BACK | Amp/Cabinet        | G-212-ROTO      |                 |                |                 |              |
| Mesaboogie   | 410 LONESTAR           | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                |                 |              |
| Mesaboogie   | 412 LONESTAR           | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                |                 |              |
| Mesaboogie   | 412 STILETTO           | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                |                 |              |

| Manufacturer | Model                     | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)         |
|--------------|---------------------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Mesaboogie   | NOMAD 45 112              | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                 |
| Mesaboogie   | Triple Rectifier Head     | Amp/Cabinet        | G-901           |                 |                 |                 |                 |
| Meyer Sound  | M1D SUB                   | Speaker            | GPA-777         |                 |                 |                 |                 |
| Meyer Sound  | UMS-1P                    | Speaker            | GPA-777         |                 |                 |                 |                 |
| Mitsubishi   | LT-46149                  | LCD/Plasma         | G-TOURLCDLIFT52 |                 |                 |                 |                 |
| Microboards  | COPYWRITER 1052           | Digital Audio Gear | G-MIX 20X25     |                 |                 |                 |                 |
| Microboards  | DVD RPM 1016              | Digital Audio Gear | G-MIX 20X25     |                 |                 |                 |                 |
| Microboards  | GX1                       | Digital Audio Gear | GP-PC308        |                 |                 |                 |                 |
| Microtek     | MHP1                      | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Microtek     | VS1                       | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |                 |
| Midas        | VENICE-1608               | Mixer              | G-MIX 20X25     |                 |                 |                 |                 |
| Misubishi    | XD450U                    | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |                 |
| Mitchell     | MD100                     | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Mitchell     | MD100S                    | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Mitchell     | MD100S12                  | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Mitsubishi   | LEONARDO                  | LCD/Plasma         | G-LCD-4042      |                 |                 |                 |                 |
| Mitsubishi   | LT46231                   | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Mitsubishi   | LT-52133                  | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Mitsubishi   | LT-52144                  | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Mitsubishi   | LT-52244                  | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Mitsubishi   | PD-5010                   | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Mitsubishi   | XD430U                    | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| Motu         | TRAVELER                  | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOURCARRYONFO |                 |
| Motu         | ULTRALITE                 | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Musicxpc     | M4                        | Laptop             | GAV-1813-UR     |                 |                 |                 |                 |
| Musicxpc     | M4X                       | Laptop             | GAV-1813-UR     |                 |                 |                 |                 |
| Musicxpc     | M6                        | Laptop             | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                 |
| Nady         | 6600                      | Mixer              | GPA-720         |                 |                 |                 |                 |
| Nady         | CMX16A                    | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Nady         | DKW-DUO                   | Wireless System    | GM-1W           | GM-2W           | GM-5W           |                 |                 |
| Nady         | E03                       | Wireless System    | GM-4WR          |                 |                 |                 |                 |
| Nady         | Encore Duet Dual Headset  | Wireless System    | GM-1W           | GM-2W           |                 |                 |                 |
| Nady         | Encore Duet Dual Lavalier | Wireless System    | GM-1W           | GM-2W           |                 |                 |                 |
| Nady         | MC12                      | Speaker            | GPA-777         |                 |                 |                 |                 |
| Nady         | MC15                      | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| Nady         | MM 4                      | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Nady         | MPM4130                   | Mixer              | GMC-2222        |                 |                 |                 |                 |
| Nady         | MPM8175                   | Mixer              | GPA-720         |                 |                 |                 |                 |
| Nady         | MXE1212                   | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Nady         | MXE612                    | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Nady         | MXE812                    | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Nady         | PFW12                     | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| Nady         | PRM400                    | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 2118    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Nady         | PS112                     | Speaker            | GPA-777         |                 |                 |                 |                 |
| Nady         | PSW15                     | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| Nady         | PTS 1015                  | Speaker            | GPA-700         |                 |                 |                 |                 |
| Nady         | PTS515                    | Speaker            | GPA-700         |                 |                 |                 |                 |
| Nady         | SPM6600                   | Mixer              | GPA-720         |                 |                 |                 |                 |
| Nady         | SPM8600                   | Mixer              | GPA-720         |                 |                 |                 |                 |
| Nady         | SRM10X                    | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Nady         | SRM12X                    | Mixer              | G-MIX 17X18     | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |
| Nady         | SRM-14X                   | Mixer              | G-MIX 17X18     | G-MIX-B 1818    | G-MIX-L 1618A   |                 |                 |
| Nady         | UHF-3                     | Wireless System    | GM-1W           | GM-2W           |                 |                 |                 |
| Nec          | 3300                      | LCD/Plasma         | G-TOURLCDP-2632 |                 |                 |                 |                 |
| Nec          | 4000                      | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |                 |
| Nec          | 4200                      | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Nec          | 4205                      | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Nec          | 4210                      | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Nec          | 5000                      | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Nec          | 42MP1                     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Nec          | 42MP2                     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Nec          | 42MP4                     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Nec          | 42PD1                     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Nec          | 42PD2                     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Nec          | 42VM5                     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T |                 |                 |                 |
| Nec          | 42VP4                     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Nec          | 42VP5 & 42VP5A            | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Nec          | 42XM3                     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Nec          | 42XM3A                    | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Nec          | 50MP1                     | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Nec          | 50MP2                     | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Nec          | 50MP3                     | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Nec          | 50PD1                     | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Nec          | 50XM3                     | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Nec          | 50XM4A                    | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Nec          | 50XM5                     | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Nec          | 50XR4A                    | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Nec          | 61 XMA                    | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |                 |
| Nec          | 61 XR4                    | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |                 |

| Manufacturer | Model               | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5) |
|--------------|---------------------|--------------------|-----------------|-----------------|-----------------|-----------------|---------|
| Nec          | LCD2335 WXM         | LCD/Plasma         | G-TOURLCDP-2023 |                 |                 |                 |         |
| Nec          | LCD4010             | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |         |
| Nec          | LCD4020             | LCD/Plasma         | G-LCDCOVER-42   |                 |                 |                 |         |
| Nec          | LCD4215             | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |         |
| Nec          | LCD4610             | LCD/Plasma         | G-LCDCOVER-52   |                 |                 |                 |         |
| Nec          | LCD4615             | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |         |
| Nec          | LCD4620             | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |         |
| Nec          | LCD46202AV          | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |         |
| Nec          | LCD5220             | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |         |
| Nec          | LCD5710-2-AV        | LCD/Plasma         | G-TOURLCDLIFT65 |                 |                 |                 |         |
| Nec          | LCD5710-2-IT        | LCD/Plasma         | G-TOURLCDLIFT65 |                 |                 |                 |         |
| Nec          | M40B-AV             | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |         |
| Nec          | M46B-AV             | LCD/Plasma         | G-LCDCOVER-52   |                 |                 |                 |         |
| NEC          | NP300               | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |         |
| Nec          | P42XC10             | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |         |
| Nec          | P42XP10-BK          | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |         |
| Nec          | P50XC10             | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |         |
| Nec          | P50XP10             | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |         |
| Nec          | P60XC10             | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |         |
| Nec          | P60XP10-BK          | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |         |
| Nec          | PX-42V5RA           | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |         |
| Nec          | PX-42VMA            | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |         |
| Nec          | PX-42VP4A           | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |         |
| Nec          | PX-42XM2A           | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |         |
| Nec          | VT-37               | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |         |
| Nec          | VT-47               | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |         |
| Nec          | VT-470              | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |         |
| Nec          | VT-570              | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |         |
| Nec          | VT-575              | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |         |
| Nec          | VT-670              | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |         |
| Nec          | VT-676              | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |         |
| Nec          | X461UN              | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |         |
| Nord         | ELECTRO 2 61        | Keyboard           | GK-4212         | GKB-49          | GKC-1540        | GKPE-49-TSA     |         |
| Nord         | ELECTRO 3 61        | Keyboard           | GK-4212         | GKB-49          | GKC-1540        | GKPE-49-TSA     |         |
| Nord         | NC1                 | Keyboard           | GKB-61          |                 |                 |                 |         |
| Nord         | STAGE 73            | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76       |                 |         |
| Nord         | STAGE 76            | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76       |                 |         |
| Nord         | STAGE 88            | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76       |                 |         |
| Novation     | REMOTE ZERO SL      | Digital Audio Gear | G-MEDIA PROBPXL | G-MULTIFX-2411  |                 |                 |         |
| Novation     | REMOTE25 SL         | Keyboard           | GK-2110         | G-MEDIA PROBPXL |                 |                 |         |
| Novation     | REMOTE25 SLC        | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411  |                 |         |
| Novation     | REMOTE-25LE         | Keyboard           | G-MEDIA PROBPXL |                 |                 |                 |         |
| Novation     | REMOTE37 SL         | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411  |                 |         |
| Novation     | REMOTE49            | Keyboard           | GK-49           | GKPE-49-TSA     |                 |                 |         |
| Novation     | REMOTE49 SLC        | Keyboard           | GK-49           | GKPE-49-TSA     |                 |                 |         |
| Novation     | REMOTE61            | Keyboard           | GK-4212         |                 |                 |                 |         |
| Novation     | XIO-SYNTH25         | Keyboard           | G-MEDIA PROBPXL |                 |                 |                 |         |
| Novation     | XSTATION 25         | Keyboard           | GK-2110         | G-MEDIA PROBPXL | G-MULTIFX-2411  |                 |         |
| Novation     | XSTATION 49         | Keyboard           | GK-49           | GKPE-49-TSA     |                 |                 |         |
| Novation     | XSTATION 61         | Keyboard           | GK-4212         |                 |                 |                 |         |
| Numark       | 5000FX              | Mixer              | G-MIX 17X18     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR CDMX1317 |         |
| Numark       | AXIS 8              | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |         |
| Numark       | AXIS 9              | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |         |
| Numark       | CD2CD               | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |         |
| Numark       | DM1001X             | Mixer              | G-MIX-B 1212    |                 |                 |                 |         |
| Numark       | DM1002 MKII         | Mixer              | G-MIX-B 1212    |                 |                 |                 |         |
| Numark       | DM1050              | Mixer              | G-MIX-B 1212    |                 |                 |                 |         |
| Numark       | DM2050              | Mixer              | G-MIX-B 1212    |                 |                 |                 |         |
| Numark       | DM3001X             | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    |                 |                 |         |
| Numark       | DM3002X             | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    |                 |                 |         |
| Numark       | DM3050              | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |         |
| Numark       | DM950               | Mixer              | G-MIX-B 1212    |                 |                 |                 |         |
| Numark       | DM950 USB           | Mixer              | G-MIX-B 1212    |                 |                 |                 |         |
| Numark       | DMX01               | Mixer              | G-MIX-B 1212    |                 |                 |                 |         |
| Numark       | DMX03               | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 | GX-1            | GX-2    |
| Numark       | DMX06               | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 | GX-1            | GX-2    |
| Numark       | DXM01 USB           | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 | GX-1            | GX-2    |
| Numark       | DXM06               | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 | GX-1            | GX-2    |
| Numark       | DXM09               | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 | GX-1            | GX-2    |
| Numark       | DXMPRO              | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1822    |                 |         |
| Numark       | HDX                 | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |         |
| Numark       | iDJ                 | Mixer              | G-MIX-B 1212    |                 |                 |                 |         |
| Numark       | IDJ2                | Mixer              | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR CDMX1317 |         |
| Numark       | M3                  | Mixer              | G-MIX-B 1212    |                 |                 |                 |         |
| Numark       | MATRIX 2            | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    |                 |                 |         |
| Numark       | MATRIX 3            | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    |                 |                 |         |
| Numark       | MIX MEISTER CONTROL | Mixer              | GMC-2222        | G-MIX-L 1224    | G-MIX-L 1622    | G-MIX-L 1724    |         |
| Numark       | NUVJ                | Mixer              | G-MIX 20X25     |                 |                 |                 |         |
| Numark       | PPD01               | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 | GX-1            |         |

| Manufacturer | Model          | Type       | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)      | Fit (5) |
|--------------|----------------|------------|-----------------|-----------------|-----------------|--------------|---------|
| Numark       | TT1600MKII     | Turntable  | G-TOUR T-TABLE  |                 |                 |              |         |
| Numark       | TT1650         | Turntable  | G-TOUR T-TABLE  |                 |                 |              |         |
| Numark       | TT500          | Turntable  | G-TOUR T-TABLE  |                 |                 |              |         |
| Numark       | TTUSB          | Turntable  | G-TOUR T-TABLE  |                 |                 |              |         |
| Numark       | TTX            | Turntable  | G-TOUR T-TABLE  |                 |                 |              |         |
| Open Labs    | NEKO 64 61     | Keyboard   | GKC-1648        |                 |                 |              |         |
| Open Labs    | NEKO 64 76     | Keyboard   | GKC-1648        |                 |                 |              |         |
| Open Labs    | NEKO LE 61     | Keyboard   | GKC-1648        |                 |                 |              |         |
| Open Labs    | NEKO LE 76     | Keyboard   | GKC-1648        |                 |                 |              |         |
| Optoma       | EZ PRO 747     | Projector  | GAV-1412-R      | GAV-PE-1412R    |                 |              |         |
| Panasonic    | 46PZ80U        | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | 46PZ85U        | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | PT-37PD1       | LCD/Plasma | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |              |         |
| Panasonic    | PT-42P1        | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | PT-50PD3-P     | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | PT-AE700U      | Projector  | GAV-1412-R      | GAV-PE-1412R    |                 |              |         |
| Panasonic    | PTLB10SVU      | Projector  | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |         |
| Panasonic    | PT-LB10U       | Projector  | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |         |
| Panasonic    | PTLB10VU       | Projector  | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |         |
| Panasonic    | PT-LB20NTU     | Projector  | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |         |
| Panasonic    | PTLB20SU       | Projector  | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |         |
| Panasonic    | PTLB20U        | Projector  | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |         |
| Panasonic    | PTLB20VU       | Projector  | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |         |
| Panasonic    | PT-LB30        | Projector  | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |         |
| Panasonic    | PTLB30NTU      | Projector  | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |         |
| Panasonic    | PTLB50NTU      | Projector  | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |         |
| Panasonic    | PTLB50SU       | Projector  | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |         |
| Panasonic    | PTLB50U        | Projector  | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |         |
| Panasonic    | PTLB60NTU      | Projector  | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |         |
| Panasonic    | PTLB60U        | Projector  | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |         |
| Panasonic    | TC23LX50       | LCD/Plasma | G-TOURLCDP-2023 |                 |                 |              |         |
| Panasonic    | TC-32LX60      | LCD/Plasma | G-TOURLCDP-2632 |                 |                 |              |         |
| Panasonic    | TC-37P1F       | LCD/Plasma | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |              |         |
| Panasonic    | TC-50PX14      | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | TC-L32C12      | LCD/Plasma | G-TOURLCDP-2632 |                 |                 |              |         |
| Panasonic    | TC-L37X1       | LCD/Plasma | G-LCDCOVER-42   |                 |                 |              |         |
| Panasonic    | TC-L42U12      | LCD/Plasma | G-LCD-4042      | G-TOURLCDLIFT52 |                 |              |         |
| Panasonic    | TC-P42C1       | LCD/Plasma | G-LCD-4042      | G-TOURLCDLIFT52 |                 |              |         |
| Panasonic    | TCP42S1        | LCD/Plasma | G-LCD-4042      | G-TOURLCDLIFT52 |                 |              |         |
| Panasonic    | TC-P42U1       | LCD/Plasma | G-LCD-4042      | G-TOURLCDLIFT52 |                 |              |         |
| Panasonic    | TC-P42X1       | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | TCP46G10       | LCD/Plasma | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |         |
| Panasonic    | TCP46S1        | LCD/Plasma | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |         |
| Panasonic    | TCP46U1        | LCD/Plasma | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |         |
| Panasonic    | TC-P50G10      | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | TC-P50S1       | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | TC-P50U1       | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | TC-P50X1       | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | TC-P54S1       | LCD/Plasma | G-LCDCOVER-52   |                 |                 |              |         |
| Panasonic    | TH37PH9UK      | LCD/Plasma | G-LCDCOVER-42   |                 |                 |              |         |
| Panasonic    | TH-37PR11UK/UH | LCD/Plasma | G-LCDCOVER-42   |                 |                 |              |         |
| Panasonic    | TH-37PWD5UX    | LCD/Plasma | G-LCDCOVER-42   |                 |                 |              |         |
| Panasonic    | TH-37PWD6      | LCD/Plasma | G-LCDCOVER-42   |                 |                 |              |         |
| Panasonic    | TH-37PWD7UY    | LCD/Plasma | G-LCDCOVER-42   |                 |                 |              |         |
| Panasonic    | TH-42PD60U     | LCD/Plasma | G-TOURLCD-3743T |                 |                 |              |         |
| Panasonic    | TH-42PDD3B     | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | TH-42PF11UK    | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | TH-42PH11UK    | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | TH-42PH9UK     | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | TH-42PHD5UY    | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | TH-42PHD6      | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | TH-42PHD6UY    | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | TH-42PHD7UY    | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | TH-42PHD8UK    | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | TH-42PR11UK/UH | LCD/Plasma | G-LCD-4042      | G-TOURLCDLIFT52 |                 |              |         |
| Panasonic    | TH42PS9UK      | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | TH-42PWD3U     | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | TH-42PWD5UY    | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | TH-42PWD6UY    | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |         |
| Panasonic    | TH42PX25U      | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | TH-42PX600U    | LCD/Plasma | G-TOURLCD-3743T |                 |                 |              |         |
| Panasonic    | TH-42PX60U     | LCD/Plasma | G-LCD-4042      | G-TOURLCDLIFT52 |                 |              |         |
| Panasonic    | TH46PZ80U      | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | TH46PZ85U      | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | TH-50PF11UK    | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | TH50PF9UK      | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | TH-50PH11UK    | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | TH-50PH9       | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |
| Panasonic    | TH-50PH9UK     | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |         |

| Manufacturer | Model              | Type            | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)      |
|--------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|--------------|
| Panasonic    | TH-50PHD3U         | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |              |
| Panasonic    | TH-50PHD5UY        | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |              |
| Panasonic    | TH-50PHD7UY        | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |              |
| Panasonic    | TH-50PX            | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |              |
| Panasonic    | TH-50PX25U/P       | LCD/Plasma      | G-LCDCOVER-65   |                 |                 |                 |              |
| Panasonic    | TH-50PX6           | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |              |
| Panasonic    | TH-50THD6UI        | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |              |
| Panasonic    | TH-50THD6UY        | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |              |
| Panasonic    | TH-58PF11UK        | LCD/Plasma      | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |              |
| Panasonic    | TH-58PH10UKA       | LCD/Plasma      | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |              |
| Panasonic    | TH58PX6            | LCD/Plasma      | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |              |
| Panasonic    | TH-58PZ800U        | LCD/Plasma      | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |              |
| Panasonic    | TH-65PF11UK        | LCD/Plasma      | G-LCDCOVER-65   |                 |                 |                 |              |
| Panasonic    | TH65PF9UK          | LCD/Plasma      | G-LCDCOVER-65   |                 |                 |                 |              |
| Parkwood     | PW310M             | Acoustic Guitar | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD     |
| Peavey       | 3120               | Amp/Cabinet     | G-TOUR AMP HEAD |                 |                 |                 |              |
| Peavey       | 16FX               | Mixer           | G-MIX-B 2519    |                 |                 |                 |              |
| Peavey       | 24FX               | Mixer           | G-MIX 20X25     |                 |                 |                 |              |
| Peavey       | 5150 HEAD          | Amp/Cabinet     | G-901           |                 |                 |                 |              |
| Peavey       | 6505 212 COMBO     | Amp/Cabinet     | G-TOUR-4X12-CAB |                 |                 |                 |              |
| Peavey       | 6505 HEAD          | Amp/Cabinet     | G-901           |                 |                 |                 |              |
| Peavey       | 6505 PLUS HEAD     | Amp/Cabinet     | G-901           |                 |                 |                 |              |
| Peavey       | BANDIT 112         | Amp/Cabinet     | G-212-ROTO      | G-TOUR AMP2430  |                 |                 |              |
| Peavey       | CLASSIC 212        | Amp/Cabinet     | G-TOUR-4X12-CAB |                 |                 |                 |              |
| Peavey       | CLASSIC 30         | Amp/Cabinet     | G-112-ROTO      |                 |                 |                 |              |
| Peavey       | CLASSIC 50/212     | Amp/Cabinet     | G-212A          | G-TOUR AMP2430  |                 |                 |              |
| Peavey       | CLASSIC 50/410     | Amp/Cabinet     | G-212A          |                 |                 |                 |              |
| Peavey       | DELTA BLUES 115    | Amp/Cabinet     | G-112-ROTO      | G-TOUR AMP2226  |                 |                 |              |
| Peavey       | DELTA BLUES 210    | Amp/Cabinet     | G-112-ROTO      | G-TOUR AMP2226  |                 |                 |              |
| Peavey       | JSX 212COMBO       | Amp/Cabinet     | G-212A          | G-TOUR AMP2430  |                 |                 |              |
| Peavey       | JSX HEAD           | Amp/Cabinet     | G-TOUR AMP HEAD |                 |                 |                 |              |
| Peavey       | JSX412             | Amp/Cabinet     | G-TOUR-4X12-CAB |                 |                 |                 |              |
| Peavey       | MAX 112            | Amp/Cabinet     | G-112A          | G-TOUR AMP2226  |                 |                 |              |
| Peavey       | MAX 115            | Amp/Cabinet     | G-TOUR AMP2226  |                 |                 |                 |              |
| Peavey       | NASHVILLE 1000     | Amp/Cabinet     | G-212A          | G-TOUR AMP2430  |                 |                 |              |
| Peavey       | NASHVILLE 112      | Amp/Cabinet     | G-112A          | G-TOUR AMP2226  |                 |                 |              |
| Peavey       | PENTA 412          | Amp/Cabinet     | G-TOUR-4X12-CAB |                 |                 |                 |              |
| Peavey       | PENTA HEAD         | Amp/Cabinet     | G-TOUR AMP HEAD |                 |                 |                 |              |
| Peavey       | PR 10 NEO          | Speaker         | GPA-600         |                 |                 |                 |              |
| Peavey       | PR 12 NEO          | Speaker         | GPA-700         | GPA-SCVR450-515 |                 |                 |              |
| Peavey       | PV 12M             | Speaker         | GPA-600         |                 |                 |                 |              |
| Peavey       | PV 15M             | Speaker         | GPA-700         | GPA-SCVR450-515 |                 |                 |              |
| Peavey       | PV10               | Mixer           | GMC-2222        | G-MIX-B 1515    | G-MIX-L 1618A   | G-TOUR CDMX1317 | GX-1         |
| Peavey       | PV14               | Mixer           | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR 19X21 |
| Peavey       | PV20               | Mixer           | GMC-2222        | G-MIX-B 2519    | G-MIX-L 1622    |                 |              |
| Peavey       | PV20 USB           | Mixer           | GMC-2222        | G-MIX-B 2519    | G-MIX-L 1622    |                 |              |
| Peavey       | PV6                | Mixer           | G-MIX-B 1212    |                 |                 |                 |              |
| Peavey       | PV8                | Mixer           | G-MIX-B 1212    |                 |                 |                 |              |
| Peavey       | RQ 1606M           | Mixer           | GMC-3333        | G-MIX 24X36     | G-TOUR 20X30    | G-TOUR 24X36    |              |
| Peavey       | RQ 200             | Mixer           | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |              |
| Peavey       | RQ 2310            | Mixer           | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1724    | G-TOUR 19X21    | GX-1921-7.5  |
| Peavey       | RQ 2314            | Mixer           | GMC-2222        | G-MIX 20X25     | G-MIX-B 2519    | G-MIX-L 1926    | G-TOUR 19X21 |
| Peavey       | RQ 2318            | Mixer           | GMC-3333        | G-MIX 20X30     | G-MIX-B 2519    | G-MIX-L 1926    | G-TOUR 20X30 |
| Peavey       | RQ 2326            | Mixer           | G-MIX 24X36     |                 |                 |                 |              |
| Peavey       | STUDIO PRO 112     | Amp/Cabinet     | G-112A          | G-212-ROTO      | G-TOUR AMP2226  |                 |              |
| Peavey       | SUPREME XL         | Amp/Cabinet     | G-212-ROTO      |                 |                 |                 |              |
| Peavey       | SUPREME XL HEAD    | Amp/Cabinet     | G-TOUR AMP HEAD |                 |                 |                 |              |
| Peavey       | TRANSTUBE 112 EFX  | Amp/Cabinet     | G-112A          | G-212-ROTO      | G-TOUR AMP2226  |                 |              |
| Peavey       | TRIPLE XXX         | Amp/Cabinet     | G-212A          | G-TOUR AMP2430  |                 |                 |              |
| Peavey       | TRIPLE XXX 112     | Amp/Cabinet     | G-112A          | G-212-ROTO      | G-TOUR AMP2226  |                 |              |
| Peavey       | TRIPLE XXX 212     | Amp/Cabinet     | G-212A          | G-TOUR AMP2430  |                 |                 |              |
| Peavey       | TRIPLE XXX 412     | Amp/Cabinet     | G-TOUR-4X12-CAB |                 |                 |                 |              |
| Peavey       | TRIPLE XXX HEAD    | Amp/Cabinet     | G-TOUR AMP HEAD |                 |                 |                 |              |
| Peavey       | UNITY 1002-8 RQ    | Mixer           | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1822    | G-TOUR 19X21 |
| Peavey       | VALVE KING 412     | Amp/Cabinet     | G-TOUR-4X12-CAB |                 |                 |                 |              |
| Peavey       | VALVEKING 100 HEAD | Amp/Cabinet     | G-901           |                 |                 |                 |              |
| Peavey       | VALVEKING 112      | Amp/Cabinet     | G-112A          | G-TOUR AMP2226  |                 |                 |              |
| Peavey       | VALVEKING 212      | Amp/Cabinet     | G-212A          | G-TOUR AMP2430  |                 |                 |              |
| Peavey       | Vypyr Tube 120     | Amp/Cabinet     | G-112A          | G-TOUR AMP2226  |                 |                 |              |
| Peavey       | WIGGY 212          | Amp/Cabinet     | G-TOUR-4X12-CAB |                 |                 |                 |              |
| Peavey       | WINDSOR 412        | Amp/Cabinet     | G-TOUR-4X12-CAB |                 |                 |                 |              |
| Peavey       | WINDSOR HD         | Amp/Cabinet     | G-TOUR AMP HEAD |                 |                 |                 |              |
| Peavey       | X XL               | Amp/Cabinet     | G-212A          |                 |                 |                 |              |
| Peavey       | XR 1212            | Mixer           | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1822    | G-TOUR 19X21 |
| Peavey       | XR 684F            | Mixer           | GPA-720         |                 |                 |                 |              |
| Peavey       | XR 800F            | Mixer           | G-MIX-B 2519    |                 |                 |                 |              |
| Peavey       | XR 800F PLUS       | Mixer           | G-MIX 19X21     | G-MIX-B 2118    | G-MIX-L 1822    | G-TOUR 19X21    | GX-1921-7.5  |
| Peavey       | XR1220             | Mixer           | G-MIX 20X25     | G-MIX-B 2519    | G-MIX-L 1926    | G-TOUR 20X30    |              |
| Peavey       | XR600G             | Mixer           | GPA-720         |                 |                 |                 |              |

| Manufacturer | Model                    | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)         |
|--------------|--------------------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Peavey       | XR696F                   | Mixer              | GPA-720         |                 |                 |                 |                 |
| Peavey       | XXL                      | Amp/Cabinet        | G-212A          |                 |                 |                 |                 |
| Peavey       | XXL HEAD                 | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |                 |
| Philips      | 20PF5120                 | LCD/Plasma         | G-TOURLCDP-2023 |                 |                 |                 |                 |
| Philips      | 37PF9631D                | LCD/Plasma         | G-LCD-4042      | G-TOURLCDLIFT52 |                 |                 |                 |
| Philips      | 42FD9932                 | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |                 |
| Philips      | 42FD9934                 | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |                 |
| Philips      | 42FD9935                 | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |                 |
| Philips      | 42FD9954                 | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Philips      | 42FD9955                 | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Philips      | 42PW9962                 | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Philips      | 42PW9982                 | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Philips      | 47PFL3603D/27            | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Philips      | 47PFL7403D/27            | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Philips      | 50FD9955                 | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Philips      | 50PF7321                 | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |                 |
| Philips      | 50PF9630A                | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |                 |
| Philips      | 50PF9830                 | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |                 |
| Philips      | 52PFL7422D/37            | LCD/Plasma         | G-LCDCOVER-52   |                 |                 |                 |                 |
| Philips      | 52PFL7432D/37            | LCD/Plasma         | G-LCDCOVER-52   |                 |                 |                 |                 |
| Phonic       | HELIX 18FW               | Mixer              | GMC-2222        | G-MIX-B 1815    | G-MIX-B 1818    | G-MIX-B 2118    | G-MIX-L 1618A   |
| Phonic       | HELIX BOARD 12           | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Phonic       | HELIX BOARD 17           | Mixer              | G-MIX 17X18     | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |
| Phonic       | IMPACT 24.4              | Mixer              | GMC-4221        |                 |                 |                 |                 |
| Phonic       | MM1002                   | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Phonic       | MM1202                   | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Phonic       | MM1705                   | Mixer              | G-MIX 17X18     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR CDMX1317 |                 |
| Phonic       | MM1805(X)                | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Phonic       | MM502                    | Mixer              | G-TOUR CDMX912  |                 |                 |                 |                 |
| Phonic       | MR 1843X                 | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Phonic       | MR3243                   | Mixer              | G-MIX 24X36     |                 |                 |                 |                 |
| Phonic       | MR4243(D)                | Mixer              | G-MIX 22X46     |                 |                 |                 |                 |
| Phonic       | MR4283                   | Mixer              | G-MIX 22X46     |                 |                 |                 |                 |
| Phonic       | MR4283D                  | Mixer              | G-MIX 22X46     |                 |                 |                 |                 |
| Phonic       | MRS 1-20                 | Mixer              | G-MIX 24X36     |                 |                 |                 |                 |
| Phonic       | MRS 1-30                 | Mixer              | G-MIX 22X46     |                 |                 |                 |                 |
| Phonic       | MU1002                   | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Phonic       | MU1202                   | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Phonic       | MU502                    | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Phonic       | MU802                    | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Phonic       | PAA3                     | Digital Audio Gear | GP-PC301        |                 |                 |                 |                 |
| Phonic       | POWERPOD 1840            | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-B 2519    | G-TOUR 19X21    | GX-1921-7.5     |
| Phonic       | POWERPOD 1860II          | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-B 2519    | G-TOUR 19X21    | GX-1921-7.5     |
| Phonic       | POWERPOD 2280            | Mixer              | GMC-2222        | G-MIX-B 2519    | G-MIX-L 1926    |                 |                 |
| Phonic       | POWERPOD 620             | Mixer              | GPA-720         |                 |                 |                 |                 |
| Phonic       | POWERPOD 740             | Mixer              | GPA-720         |                 |                 |                 |                 |
| Phonic       | POWERPOD 780+            | Mixer              | GPA-720         |                 |                 |                 |                 |
| Phonic       | Powerpod Series 885 plus | Mixer              | GPA-720         |                 |                 |                 |                 |
| Pioneer      | 614MX                    | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |                 |
| Pioneer      | CDJ-1000 MK III          | CD/DVD Player      | G-TOUR CD-13X17 |                 |                 |                 |                 |
| Pioneer      | CDJ-1000 MK3             | CD/DVD Player      | G-TOUR CD-13X17 |                 |                 |                 |                 |
| Pioneer      | CDJ-1000 MKII            | CD/DVD Player      | G-TOUR CD-13X17 |                 |                 |                 |                 |
| Pioneer      | CDJ-1005                 | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |                 |
| Pioneer      | CDJ-200                  | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |                 |
| Pioneer      | CDJ2000                  | CD/DVD Player      | G-TOUR CD-13X17 |                 |                 |                 |                 |
| Pioneer      | CDJ-400                  | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |                 |
| Pioneer      | DJC3000RV                | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Pioneer      | DJM-1000                 | Mixer              | G-MIX-B 2519    |                 |                 |                 |                 |
| Pioneer      | DJM-300                  | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    |                 |                 |                 |
| Pioneer      | DJM-3000                 | Mixer              | G-MIX-L 1224    |                 |                 |                 |                 |
| Pioneer      | DJM-3005                 | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    |                 |                 |                 |
| Pioneer      | DJM-400                  | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Pioneer      | DJM-500                  | Mixer              | GMC-2222        | G-MIX-B 1515    | G-MIX-B 1818    | G-MIX-B 2118    | G-MIX-L 1618A   |
| Pioneer      | DJM-600                  | Mixer              | GMC-2222        | G-MIX-B 1515    | G-MIX-B 1818    | G-MIX-B 2118    | G-MIX-L 1618A   |
| Pioneer      | DJM-707                  | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 | GX-1            | GX-2            |
| Pioneer      | DJM-800                  | Mixer              | GMC-2222        | G-MIX-B 1515    | G-MIX-L 1618A   | G-TOUR CDMX1317 |                 |
| Pioneer      | DJM-909                  | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 | GX-1            | GX-2            |
| Pioneer      | DMP-555                  | CD/DVD Player      | G-TOUR CD-13X17 |                 |                 |                 |                 |
| Pioneer      | DVD-V7300D               | Mixer              | G-MIX-B 1815    | G-TOUR 12X17    |                 |                 |                 |
| Pioneer      | DVJ-1000                 | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Pioneer      | EFX1000                  | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |                 |
| Pioneer      | EFX500                   | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Pioneer      | PDP 505CMX               | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Pioneer      | PDP 5070HD               | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Pioneer      | PDP 6070                 | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |                 |
| Pioneer      | PDP 6100                 | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |                 |
| Pioneer      | PDP-4050HD               | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |                 |
| Pioneer      | PDP-4304                 | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |                 |
| Pioneer      | PDP-4330HD               | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |                 |

| Manufacturer | Model                    | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5) |
|--------------|--------------------------|--------------------|-----------------|-----------------|-----------------|-----------------|---------|
| Pioneer      | PDP-4330HD W/SPKS        | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |         |
| Pioneer      | PDP-433CMX               | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |         |
| Pioneer      | PDP-4340HD               | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |         |
| Pioneer      | PDP-501                  | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |         |
| Pioneer      | PDP-502                  | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |         |
| Pioneer      | PDP-5020FD               | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |         |
| Pioneer      | PDP-502MX                | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |         |
| Pioneer      | PDP-5030HD               | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |         |
| Pioneer      | PDP-503CMX               | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |         |
| Pioneer      | PDP-5040HD               | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |         |
| Pioneer      | PDP-505HD                | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |         |
| Pioneer      | PDP-50MXE                | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |         |
| Pioneer      | PDP-6020FD               | LCD/Plasma         | G-LCDCOVER-65   |                 |                 |                 |         |
| Pioneer      | PDP-910HD                | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |         |
| Pioneer      | PRO-1110HD               | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |         |
| Pioneer      | SVM1000                  | Mixer              | G-MIX 20X25     |                 |                 |                 |         |
| Planar       | PDP42B                   | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |         |
| Planar       | PDP42HD                  | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |                 |         |
| Plasmasync   | 4210W                    | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |         |
| Plus         | U2-1200                  | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |         |
| Polycom      | SOUNDSTATION2            | Digital Audio Gear | GMC-2222        | G-MIX-B 1515    | G-MIX-L 1618A   | G-TOURCARRYONFO |         |
| Polycom      | VSX 3000                 | LCD/Plasma         | G-TOURLCDP-2023 |                 |                 |                 |         |
| Presonus     | STUDIOLIVE 16.4.2        | Mixer              | G-MIX 20X25     |                 |                 |                 |         |
| Proel        | EX185A Sub               | Speaker            | G-SUB2225-24BAG |                 |                 |                 |         |
| PROEL        | M20USB 20                | Mixer              | G-MIX 20X30     | G-TOUR 20X30    |                 |                 |         |
| Proscan      | 40LC45S                  | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |         |
| Pyle Pro     | PYD-710                  | Mixer              | G-MIX-B 1212    |                 |                 |                 |         |
| Pyle-Pro     | PYD1010                  | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |         |
| Pyle-Pro     | PYD1015                  | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |         |
| Pyle-Pro     | PYD1020                  | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |         |
| Pyle-Pro     | PYD1910                  | Mixer              | G-MIX 12X24     |                 |                 |                 |         |
| Pyle-Pro     | PYD1920                  | Mixer              | G-MIX 12X24     |                 |                 |                 |         |
| Pyle-Pro     | PYD720                   | Mixer              | G-MIX-B 1212    |                 |                 |                 |         |
| QSC          | HPR122i                  | Digital Audio Gear | GP-PC301        |                 |                 |                 |         |
| QSC          | K10                      | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         |                 |         |
| QSC          | K12                      | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |         |
| Raimundo     | Model 125                | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Raimundo     | Model 128                | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Raimundo     | Model 130                | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Raimundo     | Model 146                | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Raimundo     | Model 148                | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Ramirez      | 125 Anos                 | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Ramirez      | 1E                       | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Ramirez      | 2E                       | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Ramirez      | 4E                       | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Ramirez      | AE                       | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Ramirez      | FL2                      | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Ramirez      | GH George Harrison Model | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Ramirez      | R1                       | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Ramirez      | R2                       | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Ramirez      | R4                       | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Ramirez      | S1                       | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |         |
| Randall      | R412CB                   | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |         |
| Randall      | R412CX                   | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |         |
| Randall      | RA412XLT                 | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |         |
| Randall      | RH150DG3                 | Amp/Cabinet        | G-901           |                 |                 |                 |         |
| Randall      | RM100M1                  | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |         |
| Randall      | RM100M2                  | Amp/Cabinet        | G-TOUR AMP HEAD |                 |                 |                 |         |
| Randall      | TITAN 412                | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |         |
| Rane         | GRANDMASTER FLASH        | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |         |
| Rane         | TTM56                    | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |         |
| Rane         | TTM57SL                  | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |         |
| RCA          | L46FHD37                 | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |         |
| RCA          | PH50300                  | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |         |
| RCA          | PH50400                  | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |         |
| RCA          | PH50500                  | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |         |
| RCA          | PR42300                  | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |         |
| RCF          | ART 310A                 | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |         |
| RCF          | ART 312A                 | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |         |
| RCF          | ART 322A                 | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |         |
| RCF          | ART 522-A                | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |         |
| RCF          | ART 525-A                | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |         |
| RCF          | ART 705-AS               | Speaker            | G-SUB2225-24BAG |                 |                 |                 |         |
| RCF          | CW3110                   | Speaker            | GPA-450-515     |                 |                 |                 |         |
| RCF          | CW5212                   | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |         |
| RCF          | CW5215                   | Speaker            | GPA-700         |                 |                 |                 |         |
| RCF          | SW4012                   | Speaker            | GPA-450-515     | GPA-E15         |                 |                 |         |
| RCF          | TT25-SMA                 | Speaker            | GPA-700         |                 |                 |                 |         |
| RCF          | TTL31-A                  | Speaker            | GPA-777         |                 |                 |                 |         |



| Manufacturer | Model         | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)         |
|--------------|---------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Revox        | E-642         | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                 |
| Revox        | E-650         | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| RMS          | 10-400S       | Mixer              | GPA-720         |                 |                 |                 |                 |
| Rocktron     | UTOPIA G100   | Digital Audio Gear | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1618A   |                 |                 |
| Rocktron     | UTOPIA G200   | Digital Audio Gear | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1618A   |                 |                 |
| Rogue        | Herringbone   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Rogue        | Honduran      | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Rogue        | RA-100        | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Rogue        | USA Flagh     | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Roland       | CD2           | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                 |                 |                 |
| Roland       | CD2E          | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Roland       | D 2           | Keyboard           | G-MEDIA PRO BP  |                 |                 |                 |                 |
| Roland       | DJ-2000       | Digital Audio Gear | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622    | G-TOURCARRYONFO |                 |
| Roland       | DR3           | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Roland       | DR670         | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |                 |
| Roland       | DR880         | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Roland       | E09           | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Roland       | E80           | Keyboard           | GKPE-76D-TSA    |                 |                 |                 |                 |
| Roland       | EP880         | Keyboard           | GK-88           | GKC-1648        | GKPE-88-TSA     | G-TOUR 88       |                 |
| Roland       | EXR-3         | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Roland       | EXR46-OR      | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Roland       | EXR-5         | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Roland       | EXR-7         | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76       |                 |                 |
| Roland       | FANTOM G6     | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Roland       | FANTOM G7     | Keyboard           | GK-76           | GKC-1648        | GKPE-76-TSA     | G-TOUR 76       |                 |
| Roland       | FANTOM X6     | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Roland       | FANTOM X7     | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76       |                 |                 |
| Roland       | FANTOM X8     | Keyboard           | GKC-1648        | G-TOUR 88       |                 |                 |                 |
| Roland       | FANTOM XA 61  | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Roland       | FP-4          | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Roland       | FP4BK         | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Roland       | FP4C-BK       | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Roland       | FP4C-WT       | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Roland       | FP4WH         | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Roland       | FP-5          | Keyboard           | GK-76           | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Roland       | FP-5C         | Keyboard           | GK-76           | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Roland       | FP-7          | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Roland       | G-1000        | Keyboard           | GK-76           | GKC-1648        | GKPE-76-TSA     | G-TOUR 76       |                 |
| Roland       | G-70          | Keyboard           | GK-76           | GKC-1648        |                 |                 |                 |
| Roland       | GR20          | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOUR 12X17    |                 |
| Roland       | GR20S         | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOUR 12X17    |                 |
| Roland       | GR-33         | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX 17X18     | G-MIX-B 1815    | G-MIX-L 1618A   | G-MULTIFX-2411  |
| Roland       | GW-7          | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Roland       | GW8           | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Roland       | Handsonic HPD | Digital Audio Gear | GMC-2222        | G-MIX-B 1818    | G-MIX-B 2118    | G-MIX-L 1618A   | GX-1718-7       |
| Roland       | JP-8000       | Keyboard           | GK-49           | GKC-1540        | G-TOUR 61       |                 |                 |
| Roland       | JUNO D 61     | Keyboard           | GK-4212         |                 |                 |                 |                 |
| Roland       | JUNO STAGE    | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76       |                 |                 |
| Roland       | JUNO-D        | Keyboard           | GK-4212         |                 |                 |                 |                 |
| Roland       | JUNO-G        | Keyboard           | GK-4212         |                 |                 |                 |                 |
| Roland       | JV30          | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Roland       | MC-307        | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX-B 1815    | G-MIX-L 1618A   | G-MULTIFX-2411  | G-TOUR 12X17    |
| Roland       | MC-808        | Digital Audio Gear | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   |                 |
| Roland       | MC-909        | Digital Audio Gear | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118    | G-MIX-L 1622    | G-TOUR 19X21    |
| Roland       | MV-8000       | Digital Audio Gear | GMC-2222        | G-MIX-B 2020    | GP-PC309        |                 |                 |
| Roland       | MV-8800       | Digital Audio Gear | GMC-2222        | G-MIX-B 2020    | GP-PC309        | G-TOUR 19X21    | GX-1921-7.5     |
| Roland       | PD105WT       | Digital Audio Gear | GMC-2222        | G-MIX-B 1515    | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOURCARRYONFO |
| Roland       | PK-5A         | Digital Audio Gear | G-MIX 20X25     | G-MIX-B 2519    | G-MIX-L 1724    | G-MIX-L 1926    |                 |
| Roland       | RD150         | Keyboard           | GKPE-88SLXL-TSA |                 |                 |                 |                 |
| Roland       | RD-170        | Keyboard           | GKPE-88SLXL-TSA |                 |                 |                 |                 |
| Roland       | RD-300GX      | Keyboard           | GKPE-88SLXL-TSA |                 |                 |                 |                 |
| Roland       | RD-300SX      | Keyboard           | GKPE-88SLXL-TSA |                 |                 |                 |                 |
| Roland       | RD-70         | Keyboard           | GKC-1648        | G-TOUR 88       |                 |                 |                 |
| Roland       | RD-700GX      | Keyboard           | GKPE-88SLXL-TSA |                 |                 |                 |                 |
| Roland       | RD-700SX      | Keyboard           | GKPE-88SLXL-TSA |                 |                 |                 |                 |
| Roland       | RS-50         | Keyboard           | GK-4212         |                 |                 |                 |                 |
| Roland       | RS-70         | Keyboard           | GK-4212         |                 |                 |                 |                 |
| Roland       | SH-201        | Keyboard           | GK-49           | GKC-1540        |                 |                 |                 |
| Roland       | SH-32         | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                 |                 |                 |
| Roland       | SONIC CELL    | Keyboard           | G-MEDIA PRO BP  |                 |                 |                 |                 |
| Roland       | SP-404        | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Roland       | SP-555        | Digital Audio Gear | G-MEDIA PRO BP  |                 |                 |                 |                 |
| Roland       | SP-606        | Digital Audio Gear | GMC-2222        | G-MIX-B 1515    | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOURCARRYONFO |
| Roland       | SPD 20        | Digital Audio Gear | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   |                 |
| Roland       | SPD-S         | Digital Audio Gear | G-MEDIA PRO BP  | G-MIX-B 1515    | G-MIX-L 1618A   | G-TOUR 12X17    |                 |
| Roland       | TD-20         | Digital Audio Gear | G-MIX-B 1515    | G-MULTIFX-1510  | G-TOUR 12X17    |                 |                 |
| Roland       | V SYNTH       | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Roland       | V SYNTH GT    | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Roland       | VA-76         | Keyboard           | GK-76           | GKC-1648        | GKPE-76-TSA     | G-TOUR 76       |                 |

| Manufacturer | Model       | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)       | Fit (5)      |
|--------------|-------------|--------------------|-----------------|-----------------|-----------------|---------------|--------------|
| Roland       | V-BASS      | Digital Audio Gear | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622    |               |              |
| Roland       | VG-88       | Digital Audio Gear | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622    |               |              |
| Roland       | VK-7        | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76       |               |              |
| Roland       | VK8         | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76       |               |              |
| Roland       | VP-550      | Keyboard           | GK-49           | GKC-1540        |                 |               |              |
| Roland       | VR760       | Keyboard           | GK-76           | GKC-1648        | GKPE-76-TSA     | G-TOUR 76     |              |
| Roland       | VS-2000CD   | Digital Audio Gear | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1622    | G-TOUR 19X21  |              |
| Roland       | VS-2400CD   | Digital Audio Gear | GMC-2222        | G-MIX-B 2020    | GP-PC309        | G-TOUR 19X21  | GX-1921-7.5  |
| Roland       | VS2480CD    | Digital Audio Gear | GMC-3333        |                 |                 |               |              |
| Roland       | VS2480DVD   | Digital Audio Gear | GMC-3333        |                 |                 |               |              |
| Roland       | VS2480M     | Digital Audio Gear | GMC-3333        | G-MIX 20X30     | G-TOUR 20X30    |               |              |
| Roland       | XP30        | Keyboard           | GK-4212         |                 |                 |               |              |
| Roland       | XP-50       | Keyboard           | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61     |              |
| Roland       | XP80        | Keyboard           | GK-76           | GKPE-76-TSA     | G-TOUR 76       |               |              |
| Roland       | XV-88       | Keyboard           | GK-88           | GKC-1648        | GKPE-88-TSA     | G-TOUR 88     |              |
| Roland       | VS-1824CD   | Digital Audio Gear | GMC-2222        | G-MIX-B 2519    | G-MIX-L 1622    |               |              |
| RSS          | M-48        | Mixer              | G-MIX-B 1212    |                 |                 |               |              |
| Runco        | PL-42       | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |               |              |
| Runco        | PL-42C      | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |               |              |
| Runco        | PL-50C      | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |               |              |
| Sampo        | PME-42S6    | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |               |              |
| Sampo        | PME-42X6    | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |               |              |
| Sampo        | PME-50X6    | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |               |              |
| Samson       | DB1500A     | Speaker            | G-SUB2225-24BAG |                 |                 |               |              |
| Samson       | L1200       | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622    | G-TOUR 19X21  | GX-1921-7.5  |
| Samson       | L2000       | Mixer              | G-MIX 20X30     |                 |                 |               |              |
| Samson       | L2400       | Mixer              | G-MIX 24X36     |                 |                 |               |              |
| Samson       | L3200       | Mixer              | G-MIX 22X46     |                 |                 |               |              |
| Samson       | MDR 6       | Mixer              | G-MIX-B 1212    |                 |                 |               |              |
| Samson       | MDR 624     | Mixer              | G-MIX-B 1212    |                 |                 |               |              |
| Samson       | MDR10       | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1822  | G-TOUR 19X21 |
| Samson       | MDR1064     | Mixer              | G-MIX-B 1515    | G-MIX-L 1618A   | G-TOUR CDMX1317 |               |              |
| Samson       | MDR16       | Mixer              | G-MIX 20X25     | G-MIX-B 2519    | G-MIX-L 1724    | G-MIX-L 1926  |              |
| Samson       | MDR1688     | Mixer              | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1618A | G-TOUR 19X21 |
| Samson       | MDR6        | Mixer              | G-MIX-B 1212    |                 |                 |               |              |
| Samson       | MDR8        | Mixer              | G-MIX-B 1212    |                 |                 |               |              |
| Samson       | MIXPAD 12   | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    |                 |               |              |
| Samson       | MIXPAD 4    | Mixer              | G-MIX-B 1212    |                 |                 |               |              |
| Samson       | MIXPAD 9    | Mixer              | G-MIX-B 1212    |                 |                 |               |              |
| Samson       | RESOLV 120A | Speaker            | GPA-600         |                 |                 |               |              |
| Samson       | RS155       | Speaker            | G-SUB2225-24BAG |                 |                 |               |              |
| Samson       | RS185       | Speaker            | G-SUB2225-24BAG |                 |                 |               |              |
| Samson       | Stage 5     | Wireless System    | GM-5W           |                 |                 |               |              |
| Samson       | Stage 55    | Wireless System    | GM-5W           |                 |                 |               |              |
| Samson       | TM 300      | Mixer              | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118    | G-MIX-B 2519  | G-MIX-L 1822 |
| Samson       | TM 500      | Mixer              | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118    | G-MIX-B 2519  | G-MIX-L 1822 |
| Samson       | TXM16       | Mixer              | G-MIX 20X25     |                 |                 |               |              |
| Samsung      | 400CX       | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |               |              |
| Samsung      | 400CXN      | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |               |              |
| Samsung      | 400DX       | LCD/Plasma         | G-LCDCOVER-42   |                 |                 |               |              |
| Samsung      | 400DXN      | LCD/Plasma         | G-LCDCOVER-42   |                 |                 |               |              |
| Samsung      | 400FP-2     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |               |              |
| Samsung      | 400FPN-2    | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |               |              |
| Samsung      | 400TSN-2    | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |               |              |
| Samsung      | 403T        | LCD/Plasma         | G-LCD-4042      | G-TOURLCDLIFT52 |                 |               |              |
| Samsung      | 460CX       | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |               |              |
| Samsung      | 460CXN      | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |               |              |
| Samsung      | 460DR       | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |               |              |
| Samsung      | 460DRN      | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |               |              |
| Samsung      | 460DX       | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |               |              |
| Samsung      | 460DXN      | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |               |              |
| Samsung      | 460FP-2     | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |               |              |
| Samsung      | 460FPN-2    | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |               |              |
| Samsung      | 460TSN-2    | LCD/Plasma         | G-LCDCOVER-52   |                 |                 |               |              |
| Samsung      | 460UT       | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |               |              |
| Samsung      | 460UTN      | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |               |              |
| Samsung      | 460UTN-UD   | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |               |              |
| Samsung      | 520DX       | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |               |              |
| Samsung      | 520DXN      | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |               |              |
| Samsung      | 570DX       | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |               |              |
| Samsung      | 570DXN      | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |               |              |
| Samsung      | HPL-5025    | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |               |              |
| Samsung      | HPN-4239    | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |               |              |
| Samsung      | HPN5039     | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |               |              |
| Samsung      | HP-P4271    | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |               |              |
| Samsung      | HP-R5052    | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |               |              |
| Samsung      | HP-S5053    | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |               |              |
| Samsung      | LN32A550    | LCD/Plasma         | G-TOURLCDP-2632 |                 |                 |               |              |
| Samsung      | LN32B360    | LCD/Plasma         | G-TOURLCDP-2632 |                 |                 |               |              |

| Manufacturer | Model           | Type            | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)  |
|--------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|----------|
| Samsung      | LN37B550        | LCD/Plasma      | G-LCDCOVER-42   |                 |                 |                 |          |
| Samsung      | LN37B650        | LCD/Plasma      | G-LCDCOVER-42   |                 |                 |                 |          |
| Samsung      | LN40A550        | LCD/Plasma      | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Samsung      | LN40A650        | LCD/Plasma      | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Samsung      | LN40A750        | LCD/Plasma      | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Samsung      | LN40B530        | LCD/Plasma      | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Samsung      | LN40B550        | LCD/Plasma      | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Samsung      | LN40B630        | LCD/Plasma      | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Samsung      | LN46A550        | LCD/Plasma      | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Samsung      | LN46A650        | LCD/Plasma      | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Samsung      | LN46A750        | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Samsung      | LN46B530        | LCD/Plasma      | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Samsung      | LN46B550        | LCD/Plasma      | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |          |
| Samsung      | LN46B640        | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Samsung      | LN46B650        | LCD/Plasma      | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Samsung      | LN46B750        | LCD/Plasma      | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |          |
| Samsung      | LN52A580        | LCD/Plasma      | G-LCDCOVER-65   |                 |                 |                 |          |
| Samsung      | LN52A750        | LCD/Plasma      | G-LCD-5052      | G-LCDCOVER-65   | G-TOURLCDLIFT52 |                 |          |
| Samsung      | LN52A850        | LCD/Plasma      | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |          |
| Samsung      | LN52B550        | LCD/Plasma      | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Samsung      | LN52B750        | LCD/Plasma      | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Samsung      | LN55B640        | LCD/Plasma      | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |          |
| Samsung      | LN55296D        | LCD/Plasma      | G-LCDCOVER-52   |                 |                 |                 |          |
| Samsung      | LN-S5296D       | LCD/Plasma      | G-LCDCOVER-52   |                 |                 |                 |          |
| Samsung      | LN-T5265F       | LCD/Plasma      | G-LCDCOVER-65   |                 |                 |                 |          |
| Samsung      | LN-T5265FX      | LCD/Plasma      | G-LCDCOVER-65   |                 |                 |                 |          |
| Samsung      | LNT5271F        | LCD/Plasma      | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |          |
| Samsung      | P42H            | LCD/Plasma      | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Samsung      | P42HP           | LCD/Plasma      | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Samsung      | P50FP           | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Samsung      | P50H            | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Samsung      | P50HP           | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Samsung      | P63FP           | LCD/Plasma      | G-LCDCOVER-65   |                 |                 |                 |          |
| Samsung      | PDP-42HD        | LCD/Plasma      | G-TOURLCD-3743T |                 |                 |                 |          |
| Samsung      | PDP-50VG        | LCD/Plasma      | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Samsung      | PN42B450        | LCD/Plasma      | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |          |
| Samsung      | PN50B450        | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Samsung      | PN50B550        | LCD/Plasma      | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Samsung      | PN50B650        | LCD/Plasma      | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Samsung      | PN58B550T2      | LCD/Plasma      | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |          |
| Samsung      | PPM 42S3        | LCD/Plasma      | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Samsung      | PPM-42M5S       | LCD/Plasma      | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Samsung      | PPM-50H2        | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Samsung      | PPM-50H3        | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Samsung      | PPM50M5H        | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Samsung      | SPD-42P1        | LCD/Plasma      | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |          |
| Samsung      | SPD-50P2        | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Samsung      | SPK-4215        | LCD/Plasma      | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |          |
| Samsung      | SPL-4225        | LCD/Plasma      | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Samsung      | SPN-4235        | LCD/Plasma      | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Samsung      | SPP4251         | LCD/Plasma      | G-TOURLCDLIFT52 |                 |                 |                 |          |
| Samsung      | UN46B6000       | LCD/Plasma      | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |          |
| Samsung      | UN46B8000       | LCD/Plasma      | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Samsung      | UN55B7100       | LCD/Plasma      | G-LCD-5052      | G-LCDCOVER-65   | G-TOURLCDLIFT52 |                 |          |
| Samsung      | UN55B8000       | LCD/Plasma      | G-LCD-5052      | G-LCDCOVER-65   | G-TOURLCDLIFT52 |                 |          |
| Sanyo        | DP50749         | LCD/Plasma      | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Sanyo        | PDP-42H1AN      | LCD/Plasma      | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Sanyo        | PDP-42WE        | LCD/Plasma      | G-LCD-4042      | G-TOURLCDLIFT52 |                 |                 |          |
| Sanyo        | PLC-SU51        | Projector       | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |          |
| Sanyo        | PLC-X25A        | Projector       | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |          |
| Sanyo        | PLC-XU100       | Projector       | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |          |
| Sanyo        | PLC-XU41        | Projector       | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |          |
| Sanyo        | PLC-XU47        | Projector       | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |          |
| Sanyo        | PLC-XU48        | Projector       | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |          |
| Sanyo        | PLC-XU51        | Projector       | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |          |
| Sanyo        | PLC-XU55A       | Projector       | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |          |
| Sanyo        | PLC-XU56        | Projector       | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |          |
| Sanyo        | PLC-XU58        | Projector       | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |          |
| Sanyo        | PLC-XU73        | Projector       | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |          |
| Sanyo        | PLC-XU83        | Projector       | GAV-1412-R      | GAV-PE-1412R    |                 |                 |          |
| Sanyo        | PLC-XU86        | Projector       | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |          |
| Sanyo        | PLCXW55         | Projector       | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |          |
| Sanyo        | PLV-ZZ          | Projector       | GAV-1813-UR     |                 |                 |                 |          |
| Sceptre      | X37SV-NAGA      | LCD/Plasma      | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Seagull      | S6              | Acoustic Guitar | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD |
| Seagull      | The Original S6 | Acoustic Guitar | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD |
| Selti        | MPD-5010A       | LCD/Plasma      | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Sennheiser   | ew112G2 ME2     | Wireless System | GM-4WR          |                 |                 |                 |          |
| Sennheiser   | ew122G2         | Wireless System | GM-4WR          |                 |                 |                 |          |

| Manufacturer | Model                | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)  |
|--------------|----------------------|--------------------|-----------------|-----------------|-----------------|-----------------|----------|
| Sennheiser   | EW135G2 E835         | Wireless System    | GM-1W           | GM-2W           | GM-5W           |                 |          |
| Sennheiser   | ew152G2              | Wireless System    | GM-4WR          |                 |                 |                 |          |
| Sennheiser   | ew172G2              | Wireless System    | GM-4WR          |                 |                 |                 |          |
| Sennheiser   | ew300IEM G2          | Wireless System    | GM-4WR          |                 |                 |                 |          |
| Sennheiser   | EW345G2              | Wireless System    | GM-4WR          |                 |                 |                 |          |
| Sharp        | 46D64U               | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |          |
| Sharp        | AQUOS LC-32D40U      | LCD/Plasma         | G-TOURLCDP-2632 |                 |                 |                 |          |
| Sharp        | AQUOS LC-52D62U      | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Sharp        | AQUOS LC52D64U       | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Sharp        | AQUOS LC-52D82U      | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Sharp        | LC-32SB24U           | LCD/Plasma         | G-TOURLCDP-2632 |                 |                 |                 |          |
| Sharp        | LC-37HV4U            | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |          |
| Sharp        | LC-40E67U            | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Sharp        | LC-42D64U            | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Sharp        | LC-45GD4U            | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |          |
| Sharp        | LC-45GD6U            | LCD/Plasma         | G-LCD-4647      |                 |                 |                 |          |
| Sharp        | LC-46D64U            | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |          |
| Sharp        | LC46D65U             | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |          |
| Sharp        | LC46D85U             | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |          |
| Sharp        | LC-52D62U            | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Sharp        | LC-52D64U            | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Sharp        | LC52D85U             | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Sharp        | LC-52D92U            | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |          |
| Sharp        | LCC4655U             | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |          |
| Sharp        | LC-M3700             | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |          |
| Sharp        | LC-PD50U             | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Sharp        | PG-A20X              | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |          |
| Sharp        | PG-B10S              | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |          |
| Sharp        | PG-MB60X             | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |          |
| Sharp        | PN 465               | LCD/Plasma         | G-LCDCOVER-52   |                 |                 |                 |          |
| Sharp        | PN455RU              | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |          |
| Sharp        | PN465U               | LCD/Plasma         | G-LCDCOVER-52   |                 |                 |                 |          |
| Sharp        | PN525U               | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Sharp        | PN655U               | LCD/Plasma         | G-LCDCOVER-65   |                 |                 |                 |          |
| Sharp        | PNG655               | LCD/Plasma         | G-LCDCOVER-65   |                 |                 |                 |          |
| Sharp        | PNS525               | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Sharp        | PNS655               | LCD/Plasma         | G-LCDCOVER-65   |                 |                 |                 |          |
| Shure        | M367                 | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |          |
| Shure        | PG1288/PG185         | Wireless System    | GM-4WR          |                 |                 |                 |          |
| Shure        | PG14/PG185           | Wireless System    | GM-4WR          |                 |                 |                 |          |
| Shure        | PG14/PG30            | Wireless System    | GM-4WR          |                 |                 |                 |          |
| Shure        | PG188/PG185          | Wireless System    | GM-4WR          |                 |                 |                 |          |
| Shure        | PG24/PG58            | Wireless System    | GM-4WR          |                 |                 |                 |          |
| Shure        | PG288/PG58           | Wireless System    | GM-4WR          |                 |                 |                 |          |
| Shure        | PGX14                | Wireless System    | GM-5W           |                 |                 |                 |          |
| Shure        | PGX14 Clip-on mic    | Wireless System    | GM-5W           |                 |                 |                 |          |
| Shure        | PGX24/Beta58         | Wireless System    | GM-5W           |                 |                 |                 |          |
| Shure        | PGX24/PG58           | Wireless System    | GM-5W           |                 |                 |                 |          |
| Shure        | PGX24/SM58           | Wireless System    | GM-5W           |                 |                 |                 |          |
| Shure        | SCM262               | Mixer              | G-MIX-B 1212    |                 |                 |                 |          |
| Shure        | SCM268               | Mixer              | G-MIX-B 1212    |                 |                 |                 |          |
| Shure        | SLX                  | Wireless System    | GM-1W           | GM-1WP          | GM-2W           | GM-5W           |          |
| Shure        | SLX Beta58           | Wireless System    | GM-1W           | GM-1WP          | GM-2W           | GM-5W           |          |
| Shure        | SLX SM58             | Wireless System    | GM-1W           | GM-1WP          | GM-2W           | GM-5W           |          |
| Shure        | SLX Wireless Headset | Wireless System    | GM-1W           | GM-1WP          | GM-2W           | GM-5W           |          |
| Shure        | SLX Wireless System  | Wireless System    | GM-1W           | GM-1WP          | GM-2W           | GM-5W           |          |
| Shure        | SLX1                 | Wireless System    | GM-1W           | GM-1WP          | GM-2W           | GM-5W           |          |
| Shure        | SLX24/Beta87A        | Wireless System    | GM-1W           | GM-1WP          | GM-2W           | GM-5W           |          |
| Silver Creek | D-160                | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD |
| Silver Creek | D-170                | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD |
| SM Pro Audio | DI4                  | Mixer              | G-MIX-B 1212    |                 |                 |                 |          |
| SM Pro Audio | DI8                  | Mixer              | G-MIX-B 1212    |                 |                 |                 |          |
| Softboard    | 502                  | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Softboard    | 503                  | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Softboard    | 512                  | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |          |
| Softboard    | 513                  | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Softboard    | 522                  | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |          |
| Softboard    | 532                  | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Soldano      | 4X12 SL CAB          | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |          |
| Soldano      | SLO100 HEAD          | Amp/Cabinet        | G-901           |                 |                 |                 |          |
| Sony         | 40V4100              | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Sony         | Anycast AWS-G500     | Digital Audio Gear | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   |          |
| Sony         | BRAVIA KDL-46V2500   | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |          |
| Sony         | Bravia KDL-52S5100   | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |          |
| Sony         | BRAVIA KDL-52XBR3    | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |                 |          |
| Sony         | BRAVIA KDL-V32XBR2   | LCD/Plasma         | G-TOURLCDP-2632 |                 |                 |                 |          |
| Sony         | DMXP01               | Mixer              | G-MIX-B 1212    |                 |                 |                 |          |
| Sony         | FWD40LX2F/B          | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |
| Sony         | FWD40LX2F/S          | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |          |

| Manufacturer  | Model         | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)      | Fit (5)  |
|---------------|---------------|--------------------|-----------------|-----------------|-----------------|--------------|----------|
| Sony          | FWD50PX2/B    | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |          |
| Sony          | FWD-50PX2/B   | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |          |
| Sony          | FWD50PX2/S    | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |          |
| Sony          | FWD-50PX2/S   | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |          |
| Sony          | KDL-40D26     | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |              |          |
| Sony          | KDL-40D27     | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |              |          |
| Sony          | KDL-40D28     | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |              |          |
| Sony          | KDL-40D30     | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |              |          |
| Sony          | KDL-40S130    | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |              |          |
| Sony          | KDL-40S28     | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |              |          |
| Sony          | KDL-40S30     | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |              |          |
| Sony          | KDL-40S504    | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |          |
| Sony          | KDL-40S5100   | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |          |
| Sony          | KDL-40T26     | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |              |          |
| Sony          | KDL-40T28     | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |              |          |
| Sony          | KDL-40T30     | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |              |          |
| Sony          | KDL-40V4100   | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |          |
| Sony          | KDL40XBR6     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |          |
| Sony          | KDL-46D27     | LCD/Plasma         | G-TOURLCDLIFT52 |                 |                 |              |          |
| Sony          | KDL-46D28     | LCD/Plasma         | G-TOURLCDLIFT52 |                 |                 |              |          |
| Sony          | KDL-46D30     | LCD/Plasma         | G-TOURLCDLIFT52 |                 |                 |              |          |
| Sony          | KDL-46S2000   | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |              |          |
| Sony          | KDL-46S30     | LCD/Plasma         | G-TOURLCDLIFT52 |                 |                 |              |          |
| Sony          | KDL-46S4100   | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |          |
| Sony          | KDL-46S5100   | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |          |
| Sony          | KDL-46T30     | LCD/Plasma         | G-TOURLCDLIFT52 |                 |                 |              |          |
| Sony          | KDL-46V300A   | LCD/Plasma         | G-TOURLCDLIFT52 |                 |                 |              |          |
| Sony          | KDL-46V4100   | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |              |          |
| Sony          | KDL46V5100    | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |          |
| Sony          | KDL-46V5100   | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |          |
| Sony          | KDL-46XBR4    | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |          |
| Sony          | KDL-46Z4100/B | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |              |          |
| Sony          | KDL-52S5100   | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |          |
| Sony          | KDL-52V5100   | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |              |          |
| Sony          | KDL-52W3000   | LCD/Plasma         | G-LCDCOVER-52   |                 |                 |              |          |
| Sony          | KDL-52XBR4    | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |              |          |
| Sony          | KDL-52XBR5    | LCD/Plasma         | G-LCDCOVER-65   | G-TOURLCDP60    |                 |              |          |
| Sony          | KDL-52XBR7    | LCD/Plasma         | G-LCDCOVER-52   |                 |                 |              |          |
| Sony          | KDL-52XBR9    | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |          |
| Sony          | KDL-55XBR8    | LCD/Plasma         | G-LCDCOVER-65   |                 |                 |              |          |
| Sony          | KE42TS2U      | LCD/Plasma         | G-LCD-4042      |                 |                 |              |          |
| Sony          | KVL-40V300A   | LCD/Plasma         | G-TOURLCD-3743T |                 |                 |              |          |
| Sony          | PFM-42B1      | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |          |
| Sony          | PFM-42B2H     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |          |
| Sony          | PFM-42B2U     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |          |
| Sony          | PFM-42V1      | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |          |
| Sony          | PFM-42V1-B    | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |          |
| Sony          | PFM-42X1      | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |          |
| Sony          | PFM500A2WU    | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |              |          |
| Sony          | PFM500A3WU    | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |              |          |
| Sony          | PFM-50C1      | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |          |
| Sony          | PFM510A2WU    | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |              |          |
| Sony          | PSLX250H      | Turntable          | G-TOUR T-TABLE  |                 |                 |              |          |
| Sony          | PWD-42LX1/B   | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |              |          |
| Sony          | SRP-X700      | Digital Audio Gear | GMC-2222        | G-MIX-B 2118    | G-MIX-B 2519    | G-MIX-L 1822 | GP-PC308 |
| Sony          | SWD-50PX1-B   | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50    |              |          |
| Sony          | VAIO A140     | Laptop             | GAV-1813-UR     |                 |                 |              |          |
| Sony          | VAIO A250     | Laptop             | GAV-1813-UR     |                 |                 |              |          |
| Sony          | VAIO AR       | Laptop             | GAV-1813-UR     |                 |                 |              |          |
| Sony          | VAIO C        | Laptop             | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |          |
| Sony          | VAIO FE       | Laptop             | GAV-1813-UR     |                 |                 |              |          |
| Sony          | VAIO FJ       | Laptop             | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |          |
| Sony          | VAIO FS       | Laptop             | GAV-1813-UR     |                 |                 |              |          |
| Sony          | VAIO K35      | Laptop             | GAV-1813-UR     |                 |                 |              |          |
| Sony          | VAIO K37      | Laptop             | GAV-1813-UR     |                 |                 |              |          |
| Sony          | VAIO S150     | Laptop             | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |          |
| Sony          | VAIO S360P    | Laptop             | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |          |
| Sony          | VAIO VGN      | Laptop             | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |          |
| Sony          | VPL-CS7       | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |          |
| Sony          | VPL-CX70      | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |          |
| Sony          | VPL-CX75      | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |          |
| Sony          | VPL-CX80      | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |              |          |
| Sony          | VPL-CX85      | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |              |          |
| Sony          | VPL-DS100     | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |          |
| Sony          | VPL-ES2       | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |          |
| Sony          | VPL-EX1       | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R |          |
| Sound Devices | 442           | Mixer              | G-MIX-B 1212    |                 |                 |              |          |
| Sound Devices | 788T          | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |              |          |
| Soundcraft    | COMPACT 10    | Mixer              | G-MIX-B 1815    |                 |                 |              |          |

| Manufacturer | Model                              | Type            | Fit (1)         | Fit (2)       | Fit (3)         | Fit (4)         | Fit (5)         |
|--------------|------------------------------------|-----------------|-----------------|---------------|-----------------|-----------------|-----------------|
| Soundcraft   | COMPACT 4                          | Mixer           | G-MIX-B 1212    |               |                 |                 |                 |
| Soundcraft   | EFX12                              | Mixer           | GMC-2222        | G-MIX 19X21   | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Soundcraft   | EFX8                               | Mixer           | GMC-2222        | G-MIX-B 1515  | G-MIX-L 1618A   | G-TOUR CDMX1317 |                 |
| Soundcraft   | EPM12                              | Mixer           | G-MIX 20X25     |               |                 |                 |                 |
| Soundcraft   | EPM6                               | Mixer           | G-MIX-B 2519    |               |                 |                 |                 |
| Soundcraft   | EPM8                               | Mixer           | G-MIX-B 2519    |               |                 |                 |                 |
| Soundcraft   | FX16                               | Mixer           | GMC-2222        | G-MIX-B 2118  | G-MIX-L 1822    | G-TOUR 19X21    | GX-1921-7.5     |
| Soundcraft   | FX8                                | Mixer           | GMC-2222        | G-MIX 19X21   | G-MIX-B 1818    | G-MIX-L 1822    | G-TOUR 19X21    |
| Soundcraft   | GIGRAC 1000                        | Mixer           | GPA-720         |               |                 |                 |                 |
| Soundcraft   | GIGRAC 1000ST                      | Mixer           | GPA-720         |               |                 |                 |                 |
| Soundcraft   | K1-8                               | Mixer           | G-MIX 20X25     |               |                 |                 |                 |
| Soundcraft   | LX7                                | Mixer           | G-MIX 24X36     |               |                 |                 |                 |
| Soundcraft   | M 4                                | Mixer           | GMC-2222        | G-MIX 20X25   | G-MIX-B 2118    | G-MIX-L 1622    | G-TOUR 19X21    |
| Soundcraft   | M8                                 | Mixer           | GMC-3333        | G-MIX 20X30   | G-TOUR 20X30    |                 |                 |
| Soundcraft   | MFX 12                             | Mixer           | GMC-2222        | G-MIX-B 2118  | G-MIX-L 1622    | G-TOUR 19X21    | GX-1921-7.5     |
| Soundcraft   | MFX12                              | Mixer           | GMC-2222        | G-MIX-B 1818  | G-MIX-L 1618A   | GX-1718-7       |                 |
| Soundcraft   | MFXi12                             | Mixer           | GMC-2222        | G-MIX-B 2118  | G-MIX-L 1622    | G-TOUR 19X21    |                 |
| Soundcraft   | MFXi20                             | Mixer           | G-MIX 20X30     |               |                 |                 |                 |
| Soundcraft   | MFXi8                              | Mixer           | GMC-2222        | G-MIX-B 1818  | G-MIX-L 1618A   | GX-1718-7       |                 |
| Soundcraft   | MPM12                              | Mixer           | GMC-2222        | G-MIX 19X21   | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Soundcraft   | MPM20                              | Mixer           | G-MIX 20X30     |               |                 |                 |                 |
| Soundcraft   | NOTEPAD                            | Mixer           | G-MIX-B 1212    |               |                 |                 |                 |
| Soundcraft   | POWERPAD                           | Mixer           | G-MIX-B 1212    |               |                 |                 |                 |
| Soundcraft   | SPIRIT E12                         | Mixer           | GMC-2222        | G-MIX 20X25   | G-MIX-B 2118    | G-MIX-L 1822    | G-TOUR 19X21    |
| Soundcraft   | SPIRIT E6                          | Mixer           | GMC-2222        | G-MIX-B 1815  | G-MIX-L 1618A   | G-TOUR 19X21    | GX-1718-7       |
| Soundcraft   | SPIRIT E8                          | Mixer           | GMC-2222        | G-MIX-B 1818  | G-MIX-L 1822    | G-TOUR 19X21    | GX-1718-7       |
| Soundcraft   | SPIRIT ES                          | Mixer           | GMC-2222        | G-MIX 20X25   | G-MIX-B 2118    | G-MIX-L 1822    | G-TOUR 19X21    |
| Soundcraft   | SPIRIT FX16                        | Mixer           | GMC-2222        | G-MIX-B 2118  | G-MIX-L 1822    | G-TOUR 19X21    | GX-1921-7.5     |
| Soundcraft   | SPIRIT FX8                         | Mixer           | GMC-2222        | G-MIX 19X21   | G-MIX-B 1818    | G-MIX-L 1822    | G-TOUR 19X21    |
| Soundcraft   | SPIRIT M12                         | Mixer           | GMC-2222        | G-MIX 20X25   | G-MIX-B 2020    | G-TOUR 19X21    | GX-1921-7.5     |
| Soundcraft   | SPIRIT M4                          | Mixer           | GMC-2222        | G-MIX 20X25   | G-MIX-B 2118    | G-MIX-L 1622    | G-TOUR 19X21    |
| Soundcraft   | SPIRIT M8                          | Mixer           | GMC-2222        | G-MIX 20X25   | G-MIX-B 2020    | G-TOUR 19X21    | GX-1921-7.5     |
| Soundcraft   | SX 12                              | Mixer           | GMC-2222        | G-MIX 20X25   | G-MIX-B 2519    | G-MIX-L 1926    | G-TOUR 19X21    |
| Soundcraft   | UREI 1601                          | Mixer           | GMC-2222        | G-MIX-L 1618A | G-TOUR 12X17    | G-TOUR CDMX1317 | GX-1            |
| Soundtech    | 1604                               | Mixer           | GMC-2222        | G-MIX-B 1815  | G-MIX-L 1618A   | G-TOUR CDMX1317 |                 |
| Squier       | Affinity 5-String Jazz Bass        | Bass Guitar     | G-COBRA-BASS    | G-TOUR BASS   |                 |                 |                 |
| Squier       | Affinity Series Jazz Bass          | Bass Guitar     | G-COBRA-BASS    | G-TOUR BASS   |                 |                 |                 |
| Squier       | Affinity Series Precession Bass    | Bass Guitar     | GW-BASS         | GWE-BASS      |                 |                 |                 |
| Squier       | Affinity Series Telecaster Special | Electric Guitar | GWE-ELEC        |               |                 |                 |                 |
| Squier       | Affinity Stratocaster              | Electric Guitar | GWE-ELEC        |               |                 |                 |                 |
| Squier       | Deluxe Jazz Bass Active V 5-String | Bass Guitar     | G-COBRA-BASS    | G-TOUR BASS   |                 |                 |                 |
| Squier       | Mike Dirnt P Bass                  | Bass Guitar     | GW-BASS         | GWE-BASS      |                 |                 |                 |
| Squier       | Pete Wentz Precession Bass         | Bass Guitar     | GW-BASS         | GWE-BASS      |                 |                 |                 |
| Squier       | SA100                              | Acoustic Guitar | GC-DREAD        | G-COM-DREAD   | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Squier       | SE Speacial Stratocaster           | Electric Guitar | GWE-ELEC        |               |                 |                 |                 |
| Squier       | Standard Jazz Bass                 | Bass Guitar     | G-COBRA-BASS    | G-TOUR BASS   |                 |                 |                 |
| Squier       | Standard P Bass Special Edition    | Bass Guitar     | GW-BASS         | GWE-BASS      | GWE-BASS-PINK   |                 |                 |
| Squier       | Vintage Fretless Jazz Bass         | Bass Guitar     | G-COBRA-BASS    | G-TOUR BASS   |                 |                 |                 |
| Squier       | Vintage '70s Jazz Bass             | Bass Guitar     | G-COBRA-BASS    | G-TOUR BASS   |                 |                 |                 |
| Squier       | Vintage Fretless Jazz Bass         | Bass Guitar     | G-COBRA-BASS    | G-TOUR BASS   |                 |                 |                 |
| Squier       | Vintage Precession Bass            | Bass Guitar     | GW-BASS         | GWE-BASS      | GWE-BASS-PINK   |                 |                 |
| Squier       | Vintage TB Precession Bass         | Bass Guitar     | GW-BASS         | GWE-BASS      | GWE-BASS-PINK   |                 |                 |
| Stanton      | C.324                              | CD/DVD Player   | G-TOUR CD-13X17 |               |                 |                 |                 |
| Stanton      | C-302                              | CD/DVD Player   | G-TOUR CD-13X17 |               |                 |                 |                 |
| Stanton      | C-303                              | CD/DVD Player   | G-TOUR CD-13X17 |               |                 |                 |                 |
| Stanton      | C313                               | CD/DVD Player   | G-TOUR CD-13X17 |               |                 |                 |                 |
| Stanton      | C314                               | CD/DVD Player   | G-TOUR CD-13X17 |               |                 |                 |                 |
| Stanton      | CM-203                             | Mixer           | GMC-2222        | G-MIX-L 1618A | GX-1            | GX-2            | GX-3            |
| Stanton      | CM-205                             | Mixer           | GMC-2222        | G-MIX-L 1618A | GX-1            | GX-2            | GX-3            |
| Stanton      | M-201                              | Mixer           | G-MIX-B 1212    |               |                 |                 |                 |
| Stanton      | M-202                              | Mixer           | G-MIX-B 1212    |               |                 |                 |                 |
| Stanton      | M-303                              | Mixer           | G-MIX-L 1618A   | G-TOUR 12X17  |                 |                 |                 |
| Stanton      | M-304                              | Mixer           | G-MIX-L 1618A   | G-TOUR 12X17  |                 |                 |                 |
| Stanton      | M-505                              | Mixer           | G-MIX 17X18     | G-MIX-L 1618A | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |
| Stanton      | RM-3                               | Mixer           | G-MIX-B 1515    | G-TOUR 12X17  | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |
| Stanton      | RM-3S                              | Mixer           | G-MIX-B 1515    | G-TOUR 12X17  | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |
| Stanton      | S.252                              | CD/DVD Player   | G-TOUR CD-9X12  |               |                 |                 |                 |
| Stanton      | S-250                              | CD/DVD Player   | G-TOUR CD-9X12  |               |                 |                 |                 |
| Stanton      | S300                               | CD/DVD Player   | G-TOUR CD-9X12  |               |                 |                 |                 |
| Stanton      | SA-12                              | Mixer           | GMC-2222        | G-MIX-L 1618A | G-TOUR 12X17    | GX-1            | GX-2            |
| Stanton      | SA-3                               | Mixer           | G-MIX-B 1515    | G-TOUR 12X17  |                 |                 |                 |
| Stanton      | SA-5                               | Mixer           | G-MIX-B 1515    | G-TOUR 12X17  | G-TOUR CDMX1317 |                 |                 |
| Stanton      | SA-8                               | Mixer           | G-MIX-B 1515    | G-TOUR 12X17  |                 |                 |                 |
| Stanton      | SCS3                               | Mixer           | G-MIX-B 1515    | G-TOUR 12X17  |                 |                 |                 |
| Stanton      | SK-2                               | Mixer           | G-MIX-B 1515    | G-TOUR 12X17  | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |
| Stanton      | SK-2F                              | Mixer           | G-MIX-B 1515    | G-TOUR 12X17  | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |
| Stanton      | SK-5                               | Mixer           | G-MIX-B 1212    |               |                 |                 |                 |
| Stanton      | SK-6                               | Mixer           | G-MIX-B 1515    | G-TOUR 12X17  | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |
| Stanton      | SK-6F                              | Mixer           | G-MIX-B 1515    | G-TOUR 12X17  | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |

| Manufacturer | Model         | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)         |
|--------------|---------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Stanton      | SK-ONE        | Mixer              | G-MIX-B 1515    |                 |                 |                 |                 |
| Stanton      | SMX-201       | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Stanton      | SMX-211       | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Stanton      | SMX-301       | Mixer              | GMC-2222        | G-MIX-L 1618A   | G-TOUR 12X17    | GX-1            | GX-2            |
| Stanton      | SMX-401       | Mixer              | GMC-2222        | G-MIX-L 1618A   | G-TOUR 12X17    | GX-1            | GX-2            |
| Stanton      | SMX-501       | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    |                 |                 |
| Stanton      | ST-100        | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Stanton      | ST-90         | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Stanton      | STR8-100      | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Stanton      | STR8-20       | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Stanton      | STR8-30       | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Stanton      | STR8-50       | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Stanton      | STR8-60       | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Stanton      | STR8-80       | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Stanton      | STR8-90       | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Stanton      | T50           | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Stanton      | T60           | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Stanton      | T80           | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Stanton      | T90           | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |                 |
| Studio Logic | SL 990XP      | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Studio Logic | VMK149        | Keyboard           | GK-49           | GKC-1540        |                 |                 |                 |
| Studio Logic | VMK188        | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Studiologic  | SL161PRO      | Keyboard           | GK-4212         | GKB-49          | GKPE-49-TSA     |                 |                 |
| Studiologic  | SL880PRO      | Keyboard           | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |                 |
| Studiomaster | C1            | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR CDMX1317 |                 |                 |
| Studiomaster | CSX           | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622    | G-TOUR 19X21    |                 |
| Studiomaster | PAX10         | Speaker            | GPA-600         |                 |                 |                 |                 |
| Studiomaster | PAX12         | Speaker            | GPA-777         |                 |                 |                 |                 |
| Studiomaster | VPX12         | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                 |
| Studiomaster | VX12          | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                 |
| Studiomaster | VX15          | Speaker            | GPA-700         |                 |                 |                 |                 |
| Studiomaster | VX15SUB       | Speaker            | GPA-700         |                 |                 |                 |                 |
| Sunn         | T50C          | Amp/Cabinet        | G-212A          | G-TOUR AMP2430  |                 |                 |                 |
| Suzuki       | SP-37         | Keyboard           | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| Suzuki       | SP-67         | Keyboard           | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |                 |
| SVA          | HD4208T11     | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                 |
| Sylvania     | LC320SS9      | LCD/Plasma         | G-TOURLCDP-2632 |                 |                 |                 |                 |
| Takamine     | EAN10C        | Acoustic Guitar    | GL-JUMBO        | GW-JUMBO-TW     |                 |                 |                 |
| Takamine     | EF340SC       | Acoustic Guitar    | GL-JUMBO        | GW-JUMBO-TW     |                 |                 |                 |
| Takamine     | EF3415C       | Acoustic Guitar    | GL-JUMBO        | GW-JUMBO-TW     |                 |                 |                 |
| Takamine     | EG334SC       | Acoustic Guitar    | GL-JUMBO        | GW-JUMBO-TW     |                 |                 |                 |
| Takamine     | EGS235C       | Acoustic Guitar    | GL-JUMBO        | GW-JUMBO-TW     |                 |                 |                 |
| Takamine     | G320          | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Takamine     | G340          | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Takamine     | G360S         | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Takamine     | GS330-S       | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Takamine     | Jasmine S35   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD        |
| Takamine     | TAN15C        | Acoustic Guitar    | GL-JUMBO        | GW-JUMBO-TW     |                 |                 |                 |
| Takamine     | TAN16 Koa     | Acoustic Guitar    | GL-JUMBO        | GW-JUMBO-TW     |                 |                 |                 |
| Tannoy       | ELLIPSE212ID  | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| Tapco        | 6918S         | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                 |
| Tapco        | BLEND 6       | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Tapco        | MIX100        | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Tapco        | MIX120        | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Tapco        | MIX220FX      | Mixer              | GMC-2222        | G-MIX-B 1515    | G-MIX-L 1618A   | G-TOUR 12X17    | GX-1            |
| Tapco        | MIX260FX      | Mixer              | GMC-2222        | G-MIX-B 1515    | G-MIX-L 1618A   | GX-1718-7       |                 |
| Tapco        | MIX50         | Mixer              | G-TOUR CDMX912  |                 |                 |                 |                 |
| Tapco        | MIX60         | Mixer              | G-MIX-B 1212    |                 |                 |                 |                 |
| Tapco        | TH-15A        | Speaker            | GPA-700         |                 |                 |                 |                 |
| Tascam       | 2488          | Digital Audio Gear | GMC-2222        | G-MIX-B 2519    | G-MIX-L 1822    | G-MIX-L 1926    | GP-PC308        |
| Tascam       | 2488 MK2      | Mixer              | GMC-2222        | G-MIX-B 2519    | G-MIX-L 1822    | G-MIX-L 1926    |                 |
| Tascam       | 2488 NEO      | Mixer              | GMC-2222        | G-MIX-B 2519    | G-MIX-L 1822    | G-MIX-L 1926    |                 |
| Tascam       | 2488MKII      | Digital Audio Gear | GMC-2222        | G-MIX-B 2519    | G-MIX-L 1822    | G-MIX-L 1926    | GP-PC308        |
| Tascam       | 414 MKII      | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOURCARRYONFO |                 |
| Tascam       | 424 MKII      | Digital Audio Gear | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR 19X21    |
| Tascam       | CD-D4000 MKII | CD/DVD Player      | G-TOUR CD-9X12  |                 |                 |                 |                 |
| Tascam       | CD-DJ1        | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Tascam       | DM24          | Mixer              | GMC-3333        |                 |                 |                 |                 |
| Tascam       | DP-01         | Digital Audio Gear | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOURCARRYONFO |                 |
| Tascam       | DP01FX        | Digital Audio Gear | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1622    |                 |                 |
| Tascam       | DP-01FXCD     | Digital Audio Gear | GMC-2222        | G-MIX-B 1815    | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOURCARRYONFO |
| Tascam       | DP-02         | Digital Audio Gear | GMC-2222        | G-MIX 17X18     | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR 12X17    |
| Tascam       | DP-02CF       | Digital Audio Gear | GMC-2222        | G-MIX 17X18     | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR 12X17    |
| Tascam       | DP-02FX/CD    | Digital Audio Gear | GMC-2222        | G-MIX 17X18     | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR 12X17    |
| Tascam       | FIREONE       | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |                 |
| Tascam       | FW-1082       | Digital Audio Gear | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118    | G-MIX-L 1622    | G-TOUR 19X21    |
| Tascam       | FW-1884       | Digital Audio Gear | GMC-3333        | G-MIX 20X30     | G-MIX-B 2519    | G-MIX-L 1926    | GP-PC309        |
| Tascam       | MD-301RMKII   | Digital Audio Gear | GMC-2222        | G-MEDIA PROBPXL | G-MIX 12X24     | G-MIX-L 1224    | G-TOURCARRYONFO |
| Tascam       | MF-P01        | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                 |                 |                 |

| Manufacturer  | Model                  | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)      |
|---------------|------------------------|--------------------|-----------------|-----------------|-----------------|-----------------|--------------|
| Tascam        | P11 PRINTER            | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |              |
| Tascam        | PORTA 02               | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                 |                 |              |
| Tascam        | PORTA 02MKII           | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                 |                 |              |
| Tascam        | US-428                 | Digital Audio Gear | G-MEDIA PRO BP  | G-MIX-B 1515    | G-MIX-L 1618A   | G-TOUR 12X17    | G-TOUR 12X17 |
| Tatun         | P42B5MT                | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |              |
| Tatun         | P46T                   | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 | G-TOURLCDP50    |                 |              |
| Taylor        | 110                    | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD     |
| Taylor        | 210                    | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD     |
| Taylor        | 310                    | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD     |
| Taylor        | 110e                   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD     |
| Taylor        | 210e                   | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD     |
| Taylor        | 410Ce                  | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD     |
| Taylor        | Big Baby               | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD     |
| TC Electronic | Desktop Konnekt 6      | Digital Audio Gear | G-MIX-B 1212    |                 |                 |                 |              |
| TC Electronic | G-SYSTEM               | Digital Audio Gear | GMC-2222        | G-MIX-L 1224    | G-MIX-L 1622    | G-MULTIFX-2411  | GX-1224-8    |
| TC Electronic | NOVA SYSTEM            | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1110  |                 |                 |              |
| Technics      | SH-EX1200              | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |              |
| Technics      | SH-MZ1200              | Mixer              | G-MIX-B 1515    | G-TOUR 12X17    | G-TOUR 12X17    | G-TOUR CDMX1317 |              |
| THD           | 2X12 CAB               | Amp/Cabinet        | G-212-ROTO      |                 |                 |                 |              |
| Thomson       | 42HT93PU               | LCD/Plasma         | G-LCD-4647      |                 |                 |                 |              |
| Thomson       | 42WS90E3               | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |              |
| Thomson       | 42WS93E                | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |              |
| TL Audio      | FAT TRACK              | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1618A   |                 |              |
| TL Audio      | M416                   | Mixer              | GMC-3333        |                 |                 |                 |              |
| Toft Audio    | ATB16                  | Mixer              | GMC-3333        |                 |                 |                 |              |
| Tone King     | COMET 40B              | Amp/Cabinet        | G-TOUR AMP2430  |                 |                 |                 |              |
| Topaz         | S18-4                  | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1724    | G-TOUR 19X21    |              |
| Topaz         | S28-4                  | Mixer              | G-MIX 24X36     |                 |                 |                 |              |
| Toshiba       | 32AV502U               | LCD/Plasma         | G-TOURLCDP-2632 |                 |                 |                 |              |
| Toshiba       | 37AV502R/U             | LCD/Plasma         | G-LCDCOVER-42   |                 |                 |                 |              |
| Toshiba       | 40RV525U               | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |              |
| Toshiba       | 40XV645U               | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |              |
| Toshiba       | 42WP27B                | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |              |
| Toshiba       | 46XV540U               | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |              |
| Toshiba       | 46XV645U               | LCD/Plasma         | G-LCD-4647      | G-TOURLCDLIFT52 |                 |                 |              |
| Toshiba       | 47ZV650U               | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |              |
| Toshiba       | 50HP66                 | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |              |
| Toshiba       | 50WP27B                | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |              |
| Toshiba       | 52HL167                | LCD/Plasma         | G-TOURLCDLIFT52 |                 |                 |                 |              |
| Toshiba       | 52LX177                | LCD/Plasma         | G-LCDCOVER-52   |                 |                 |                 |              |
| Toshiba       | PORTEGE R100           | Laptop             | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |              |
| Toshiba       | QOSMIO G20             | Laptop             | GAV-1813-UR     |                 |                 |                 |              |
| Toshiba       | SATELLITE M35X         | Laptop             | GAV-1813-UR     |                 |                 |                 |              |
| Toshiba       | SATELLITE 2435-S255    | Laptop             | GAV-1412-R      | GAV-PE-1412R    |                 |                 |              |
| Toshiba       | SATELLITE A105         | Laptop             | GAV-1813-UR     |                 |                 |                 |              |
| Toshiba       | SATELLITE A25          | Laptop             | GAV-1412-R      | GAV-PE-1412R    |                 |                 |              |
| Toshiba       | SATELLITE A45          | Laptop             | GAV-1412-R      | GAV-PE-1412R    |                 |                 |              |
| Toshiba       | SATELLITE A75          | Laptop             | GAV-1813-UR     |                 |                 |                 |              |
| Toshiba       | SATELLITE M35          | Laptop             | GAV-1813-UR     |                 |                 |                 |              |
| Toshiba       | SATELLITE P25          | Laptop             | GAV-1813-UR     |                 |                 |                 |              |
| Toshiba       | SATELLITE PRO M15-S405 | Laptop             | GAV-1412-R      | GAV-PE-1412R    |                 |                 |              |
| Toshiba       | SATELLITE R15          | Laptop             | GAV-1412-R      | GAV-PE-1412R    |                 |                 |              |
| Toshiba       | TDP-S20U               | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |              |
| Toshiba       | TDP-SW80U              | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |              |
| Turbosound    | TXD115                 | Speaker            | G-SUB2225-24BAG |                 |                 |                 |              |
| Turbosound    | TXD-118                | Speaker            | G-SUB2225-24BAG |                 |                 |                 |              |
| Universal     | 42                     | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |              |
| Universal     | MVP 2420               | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |              |
| Vestax        | CDX-05                 | Mixer              | G-MIX-B 1212    |                 |                 |                 |              |
| Vestax        | PCV-275                | Mixer              | G-MIX 12X24     |                 |                 |                 |              |
| Vestax        | PMC-007                | Mixer              | GMC-2222        | G-MIX-L 1618A   | G-TOUR 12X17    | GX-1            |              |
| Vestax        | PMC-05PRO III          | Mixer              | GMC-2222        | G-MIX-L 1618A   | G-TOUR 12X17    | GX-1            | GX-2         |
| Vestax        | PMC-05PRO SL           | Mixer              | GMC-2222        | G-MIX-L 1618A   | G-TOUR 12X17    | GX-1            | GX-2         |
| Vestax        | PMC-07                 | Mixer              | GMC-2222        | G-MIX-L 1618A   | G-TOUR 12X17    | GX-1            | GX-2         |
| Vestax        | PMC-37 PRO             | Mixer              | GMC-2222        | G-MIX-L 1618A   | G-TOUR 12X17    | GX-1            | GX-2         |
| Vestax        | VCM-600                | Digital Audio Gear | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622    | G-TOURCARRYONFO |              |
| Vestax        | VMC-002                | Mixer              | G-MIX-B 1212    |                 |                 |                 |              |
| Vestax        | VMC-185                | Mixer              | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1618A   | G-TOUR 12X17    | GX-1         |
| Vestax        | HANDY TRAX             | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |              |
| Vestax        | PCV150                 | Mixer              | G-MIX-L 1224    |                 |                 |                 |              |
| Vestax        | PMC06PROA              | Mixer              | G-MIX-B 1815    |                 |                 |                 |              |
| Vestax        | PMC07PRO               | Mixer              | GMC-2222        | G-MIX-L 1618A   | G-TOUR 12X17    | GX-1            | GX-2         |
| Vestax        | VCI-100                | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |              |
| Vestax        | VCI-300                | Turntable          | G-TOUR T-TABLE  |                 |                 |                 |              |
| Viewsonic     | CINE1000               | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |              |
| Viewsonic     | N3751W                 | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |              |
| Viewsonic     | N4290P                 | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |              |
| Viewsonic     | N4785P                 | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |              |
| Viewsonic     | PJ400                  | Projector          | GAV-20          |                 |                 |                 |              |



| Manufacturer | Model                           | Type               | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)        |
|--------------|---------------------------------|--------------------|-----------------|-----------------|-----------------|-----------------|----------------|
| Viewsonic    | PJ452                           | Projector          | GAV-20          |                 |                 |                 |                |
| Viewsonic    | PJ656                           | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |                |
| Viewsonic    | PJ658                           | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |                |
| Viewsonic    | PJ766D                          | Projector          | GAV-1412-R      | GAV-DLX-1412R   | GAV-DLX-20      | GAV-PE-1412R    |                |
| Viewsonic    | PJ862                           | Projector          | GAV-1412-R      | GAV-PE-1412R    |                 |                 |                |
| Viewsonic    | VPW-425                         | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                |
| Viewsonic    | VPW-4255                        | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                |
| Viewsonic    | VPW-450WD                       | LCD/Plasma         | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |                |
| Viewsonic    | VPW-505                         | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                |
| Vizio        | P50HDM                          | LCD/Plasma         | G-TOURLCDLIFT52 |                 |                 |                 |                |
| Vox          | AC100CPH                        | Amp/Cabinet        | G-901           |                 |                 |                 |                |
| Vox          | AC15H1TV LTD                    | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                |
| Vox          | AC15H1TVL                       | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                |
| Vox          | AC30BM                          | Amp/Cabinet        | G-212A          |                 |                 |                 |                |
| Vox          | AC30CC1                         | Amp/Cabinet        | G-TOUR AMP2226  |                 |                 |                 |                |
| Vox          | AC30CC2                         | Amp/Cabinet        | G-212A          |                 |                 |                 |                |
| Vox          | AC30CC2X                        | Amp/Cabinet        | G-212A          |                 |                 |                 |                |
| Vox          | AC30CCH                         | Amp/Cabinet        | G-901           |                 |                 |                 |                |
| Vox          | AC50CP2                         | Amp/Cabinet        | G-212A          |                 |                 |                 |                |
| Vox          | AD100VT                         | Amp/Cabinet        | G-212A          |                 |                 |                 |                |
| Vox          | AD120VTH                        | Amp/Cabinet        | G-212A          |                 |                 |                 |                |
| Vox          | AD120VTX NEODOG                 | Amp/Cabinet        | G-212A          |                 |                 |                 |                |
| Vox          | AD212                           | Amp/Cabinet        | G-212A          |                 |                 |                 |                |
| Vox          | AD50VT                          | Amp/Cabinet        | G-112-ROTO      | G-TOUR AMP2226  |                 |                 |                |
| Vox          | AD60VTX NEODOG                  | Amp/Cabinet        | G-112-ROTO      | G-TOUR AMP2226  |                 |                 |                |
| Vox          | DA20                            | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                |
| Vox          | TONELAB                         | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  | G-TOUR 12X17    | G-TOUR 12X17    |                |
| Vox          | TONELAB LE                      | Digital Audio Gear | GK-2110         | G-MEDIA PROBPXL | G-MIX 12X24     | G-MIX-L 1224    | G-MULTIFX-2411 |
| Vox          | V112HTV                         | Amp/Cabinet        | G-112-ROTO      |                 |                 |                 |                |
| Vox          | V212BN                          | Amp/Cabinet        | G-212A          |                 |                 |                 |                |
| Vox          | V212BNX                         | Amp/Cabinet        | G-212A          |                 |                 |                 |                |
| Vox          | V412BK                          | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                |
| Vox          | V412BN                          | Amp/Cabinet        | G-TOUR-4X12-CAB |                 |                 |                 |                |
| Warwick      | Corvette \$\$ Double Buck       | Bass Guitar        | GW-BASS         | GWE-BASS        | GWE-BASS-PINK   |                 |                |
| Warwick      | Corvette Standard Bass          | Bass Guitar        | GW-BASS         | GWE-BASS        | GWE-BASS-PINK   |                 |                |
| Warwick      | Corvette Standard Fretless Bass | Bass Guitar        | GW-BASS         | GWE-BASS        | GWE-BASS-PINK   |                 |                |
| Warwick      | Rock Bass                       | Bass Guitar        | GW-BASS         | GWE-BASS        | GWE-BASS-PINK   |                 |                |
| Warwick      | Thumb Bass                      | Bass Guitar        | GW-BASS         | GWE-BASS        | GWE-BASS-PINK   |                 |                |
| Washburn     | C40N                            | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                |
| Washburn     | C40S                            | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                |
| Washburn     | C80S                            | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                |
| Washburn     | D10QSB                          | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD       |
| Washburn     | D10S12                          | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD       |
| Washburn     | D30S                            | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD       |
| Washburn     | D52SW                           | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD       |
| Washburn     | WD10                            | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD       |
| Washburn     | WD32SW                          | Acoustic Guitar    | GC-DREAD        | G-COM-DREAD     | GL-DREAD        | G-TOUR DREAD-12 | GW-DREAD       |
| Westinghouse | LTV-20V4                        | LCD/Plasma         | G-TOURLCDP-2023 |                 |                 |                 |                |
| Westinghouse | LTV-32W4                        | LCD/Plasma         | G-TOURLCDP-2632 |                 |                 |                 |                |
| Westinghouse | TX-52F480S                      | LCD/Plasma         | G-TOURLCDLIFT52 |                 |                 |                 |                |
| Westinghouse | VM-47F140S                      | LCD/Plasma         | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |                |
| Wharfedale   | R-1604FX                        | Digital Audio Gear | G-MIX 17X18     | G-MIX-B 1818    | G-MIX-L 1618A   |                 |                |
| Wharfedale   | R-2004FX                        | Digital Audio Gear | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR 19X21   |
| Wharfedale   | SW300                           | Speaker            | GPA-777         |                 |                 |                 |                |
| Wharfedale   | SW380                           | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                |
| Wharfedale   | TITAN 12                        | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                |
| Williams     | ENCORE                          | Keyboard           | GKPE-88SLXL-TSA |                 |                 |                 |                |
| Yamaha       | 01V                             | Mixer              | GMC-2222        | G-MIX-B 2519    | G-MIX-L 1822    | G-MIX-L 1926    |                |
| Yamaha       | 01X                             | Digital Audio Gear | GMC-2222        | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR 19X21    | GX-1718-7      |
| Yamaha       | 9000 Pro                        | Keyboard           | GK-76           | GKC-1648        | GKPE-76-TSA     | G-TOUR 76       |                |
| Yamaha       | A12M                            | Speaker            | GPA-600         | GPA-SCVR450-515 |                 |                 |                |
| Yamaha       | A15W                            | Speaker            | G-SUB2225-24BAG |                 |                 |                 |                |
| Yamaha       | AW1600                          | Digital Audio Gear | GMC-2222        | G-MIX-B 1815    | G-MIX-L 1622    |                 |                |
| Yamaha       | AW16G                           | Digital Audio Gear | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   |                |
| Yamaha       | AW2400                          | Mixer              | GMC-2222        |                 |                 |                 |                |
| Yamaha       | AW4416HDCD                      | Digital Audio Gear | GMC-3333        | G-MIX 20X30     | G-MIX-B 2519    | G-MIX-L 1926    | GP-PC309       |
| Yamaha       | BR10                            | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         |                 |                |
| Yamaha       | BR12                            | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                |
| Yamaha       | BR12M                           | Speaker            | GPA-600         | GPA-SCVR450-515 |                 |                 |                |
| Yamaha       | C112V                           | Speaker            | GPA-700         | GPA-SCVR450-515 |                 |                 |                |
| Yamaha       | CG Series                       | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                |
| Yamaha       | CG101A                          | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                |
| Yamaha       | CG111C                          | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                |
| Yamaha       | CG111S                          | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                |
| Yamaha       | CG151C                          | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                |
| Yamaha       | CG171S                          | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                |
| Yamaha       | CG171SF                         | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                |
| Yamaha       | CGS102                          | Acoustic Guitar    | GWE-CLASSIC     |                 |                 |                 |                |
| Yamaha       | CM10V                           | Speaker            | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |                |

| Manufacturer | Model      | Type               | Fit (1)      | Fit (2)         | Fit (3)        | Fit (4)         | Fit (5)         |
|--------------|------------|--------------------|--------------|-----------------|----------------|-----------------|-----------------|
| Yamaha       | CM12V      | Speaker            | GPA-700      | GPA-SCVR450-515 |                |                 |                 |
| Yamaha       | CP300      | Keyboard           | GKC-1648     |                 |                |                 |                 |
| Yamaha       | CP33       | Keyboard           | GK-88 SLIM   | GKPE-88SLIM-TSA | G-TOUR 88 SLIM |                 |                 |
| Yamaha       | CSX1       | Keyboard           | GK-4212      |                 |                |                 |                 |
| Yamaha       | DD65       | Digital Audio Gear | G-MIX 20X25  | GP-PC309        |                |                 |                 |
| Yamaha       | DG-60      | Amp/Cabinet        | G-112-ROTO   |                 |                |                 |                 |
| Yamaha       | DG-80      | Amp/Cabinet        | G-112-ROTO   |                 |                |                 |                 |
| Yamaha       | DGX203     | Keyboard           | GK-76        | GKC-1648        | GKPE-76-TSA    | G-TOUR 76       |                 |
| Yamaha       | DGX230     | Keyboard           | GK-76        | GKC-1648        | GKPE-76-TSA    | G-TOUR 76       |                 |
| Yamaha       | DGX305     | Keyboard           | GKC-1648     |                 |                |                 |                 |
| Yamaha       | DGX505     | Keyboard           | GKC-1648     |                 |                |                 |                 |
| Yamaha       | DGX620     | Keyboard           | GK-88        | GKC-1648        | GKPE-88-TSA    | G-TOUR 88       |                 |
| Yamaha       | DJX 203    | Keyboard           | GKB-61       |                 |                |                 |                 |
| Yamaha       | EMX 212S   | Mixer              | GPA-720      |                 |                |                 |                 |
| Yamaha       | EMX 312S   | Mixer              | GPA-720      |                 |                |                 |                 |
| Yamaha       | EMX 312SC  | Mixer              | GPA-720      |                 |                |                 |                 |
| Yamaha       | EMX 5014C  | Mixer              | G-MIX 19X21  | G-MIX-B 2118    | G-MIX-L 1822   | G-TOUR 19X21    | GX-1921-7.5     |
| Yamaha       | EMX 5016CF | Mixer              | G-MIX 19X21  | G-MIX-B 2118    | G-MIX-L 1822   | G-TOUR 19X21    | GX-1921-7.5     |
| Yamaha       | EMX 512S   | Mixer              | GPA-720      |                 |                |                 |                 |
| Yamaha       | EMX 512SC  | Mixer              | GPA-720      |                 |                |                 |                 |
| Yamaha       | EMX 620    | Mixer              | GPA-720      |                 |                |                 |                 |
| Yamaha       | EMX 640    | Mixer              | GPA-720      |                 |                |                 |                 |
| Yamaha       | EMX 860ST  | Mixer              | GPA-720      |                 |                |                 |                 |
| Yamaha       | EMX2000    | Mixer              | GMC-2222     | G-MIX-B 2118    | G-MIX-L 1822   | G-TOUR 19X21    | GX-1921-7.5     |
| Yamaha       | EMX3000    | Mixer              | GMC-2222     | G-MIX-B 2118    | G-MIX-L 1822   | G-TOUR 19X21    | GX-1921-7.5     |
| Yamaha       | EMX5000    | Mixer              | G-MIX 20X25  |                 |                |                 |                 |
| Yamaha       | EMX5000-12 | Mixer              | G-MIX 20X25  |                 |                |                 |                 |
| Yamaha       | EMX62M     | Mixer              | GPA-720      |                 |                |                 |                 |
| Yamaha       | EMX66M     | Mixer              | GPA-720      |                 |                |                 |                 |
| Yamaha       | EMX68S     | Mixer              | GPA-720      |                 |                |                 |                 |
| Yamaha       | EMX88S     | Mixer              | GPA-720      |                 |                |                 |                 |
| Yamaha       | EZ150      | Keyboard           | GK-49        | GKPE-61-TSA     | G-TOUR 61      |                 |                 |
| Yamaha       | EZ200      | Keyboard           | GK-49        | GKC-1540        | GKPE-61-TSA    | G-TOUR 61       |                 |
| Yamaha       | EZ250I     | Keyboard           | GK-49        | GKPE-61-TSA     | G-TOUR 61      |                 |                 |
| Yamaha       | F335       | Acoustic Guitar    | GC-DREAD     | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD        |
| Yamaha       | F345       | Acoustic Guitar    | GC-DREAD     | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD        |
| Yamaha       | FD01S      | Acoustic Guitar    | GC-DREAD     | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD        |
| Yamaha       | FG700S     | Acoustic Guitar    | GC-DREAD     | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD        |
| Yamaha       | FG720S     | Acoustic Guitar    | GC-DREAD     | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD        |
| Yamaha       | FG730S     | Acoustic Guitar    | GC-DREAD     | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD        |
| Yamaha       | FG735S     | Acoustic Guitar    | GC-DREAD     | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD        |
| Yamaha       | FG750S     | Acoustic Guitar    | GC-DREAD     | G-COM-DREAD     | GL-DREAD       | G-TOUR DREAD-12 | GW-DREAD        |
| Yamaha       | GF12/12    | Mixer              | G-MIX 20X25  |                 |                |                 |                 |
| Yamaha       | GF16/12    | Mixer              | G-MIX 24X36  |                 |                |                 |                 |
| Yamaha       | GF24/12    | Mixer              | G-MIX 22X46  |                 |                |                 |                 |
| Yamaha       | KX25       | Keyboard           | GK-2110      | G-MEDIA PROBPXL |                |                 |                 |
| Yamaha       | KX49       | Keyboard           | GK-49        | GKPE-49-TSA     |                |                 |                 |
| Yamaha       | KX61       | Keyboard           | GK-49        | GKC-1540        | GKPE-61-TSA    | G-TOUR 61       |                 |
| Yamaha       | KX8        | Keyboard           | GKB-88       | GKPE-88-TSA     | G-TOUR 88      |                 |                 |
| Yamaha       | MD4S       | Digital Audio Gear | GMC-2222     | G-MIX 19X21     | G-MIX-B 1818   | G-MIX-L 1618A   | G-TOUR 19X21    |
| Yamaha       | MD8        | Digital Audio Gear | GMC-2222     | G-MIX 20X25     | G-MIX-B 2118   | G-MIX-L 1724    | G-TOUR 19X21    |
| Yamaha       | MG10/2     | Mixer              | G-MIX-B 1212 |                 |                |                 |                 |
| Yamaha       | MG102C     | Mixer              | G-MIX-B 1212 |                 |                |                 |                 |
| Yamaha       | MG12/4     | Mixer              | GMC-2222     | G-MIX 19X21     | G-MIX-B 1815   | G-MIX-L 1618A   | G-TOUR CDMX1317 |
| Yamaha       | MG12/4 FX  | Mixer              | GMC-2222     | G-MIX 19X21     | G-MIX-B 1815   | G-MIX-L 1618A   | G-TOUR CDMX1317 |
| Yamaha       | MG124C     | Mixer              | GMC-2222     | G-MIX 19X21     | G-MIX-B 1815   | G-MIX-L 1618A   |                 |
| Yamaha       | MG124CX    | Mixer              | GMC-2222     | G-MIX 19X21     | G-MIX-B 1815   | G-MIX-L 1618A   |                 |
| Yamaha       | MG16/4     | Mixer              | GMC-2222     | G-MIX 19X21     | G-MIX-B 1818   | G-MIX-L 1822    | G-TOUR 19X21    |
| Yamaha       | MG16/6FX   | Mixer              | GMC-2222     | G-MIX 19X21     | G-MIX-B 1818   | G-MIX-L 1822    | G-TOUR 19X21    |
| Yamaha       | MG166C     | Mixer              | GMC-2222     | G-MIX 20X25     | G-MIX-B 2020   | G-TOUR 19X21    | GX-1921-7.5     |
| Yamaha       | MG166CX    | Mixer              | GMC-2222     | G-MIX 20X25     | G-MIX-B 2020   | G-TOUR 19X21    | GX-1921-7.5     |
| Yamaha       | MG206C     | Mixer              | GMC-2222     | G-MIX 20X25     | G-MIX-B 2020   | G-TOUR 19X21    | GX-1921-7.5     |
| Yamaha       | MG206C-USB | Mixer              | GMC-2222     | G-MIX 20X25     | G-MIX-B 2020   | G-TOUR 19X21    | GX-1921-7.5     |
| Yamaha       | MG24/14    | Mixer              | G-MIX 24X36  |                 |                |                 |                 |
| Yamaha       | MG24/14FX  | Mixer              | GMC-3333     | G-TOUR 24X36    |                |                 |                 |
| Yamaha       | MG32/14FX  | Mixer              | G-MIX 22X46  |                 |                |                 |                 |
| Yamaha       | MG8/2FX    | Mixer              | G-MIX-B 1212 |                 |                |                 |                 |
| Yamaha       | MG82CX     | Mixer              | G-MIX-B 1212 |                 |                |                 |                 |
| Yamaha       | MM1242     | Mixer              | GMC-2222     | G-MIX 19X21     | G-MIX-B 1815   | G-MIX-L 1618A   |                 |
| Yamaha       | MM1402     | Mixer              | GMC-2222     | G-MIX 19X21     | G-MIX-B 1815   | G-MIX-L 1618A   | G-TOUR 19X21    |
| Yamaha       | MM6        | Keyboard           | GK-49        | GKC-1540        | GKPE-61-TSA    | G-TOUR 61       |                 |
| Yamaha       | MM8        | Keyboard           | GKB-88       | GKPE-88-TSA     | G-TOUR 88      |                 |                 |
| Yamaha       | MO6        | Keyboard           | GK-61        | GKC-1540        | GKPE-61-TSA    | G-TOUR 61       |                 |
| Yamaha       | MO8        | Keyboard           | GKC-1648     | G-TOUR 88       |                |                 |                 |
| Yamaha       | MOTIF ES6  | Keyboard           | GK-61        | GKC-1540        | GKPE-61-TSA    | G-TOUR 61       |                 |
| Yamaha       | MOTIF ES7  | Keyboard           | GK-76        | GKC-1648        | GKPE-76-TSA    | G-TOUR 76       |                 |
| Yamaha       | MOTIF ES8  | Keyboard           | GKC-1648     | G-TOUR 88       |                |                 |                 |
| Yamaha       | MOTIF XS6  | Keyboard           | GK-61        | GKC-1540        | GKPE-61-TSA    | G-TOUR 61       |                 |
| Yamaha       | MOTIF XS7  | Keyboard           | GK-76        | GKC-1648        | GKPE-76-TSA    | G-TOUR 76       |                 |

| Manufacturer | Model         | Type       | Fit (1)         | Fit (2)         | Fit (3)         | Fit (4)         | Fit (5)      |
|--------------|---------------|------------|-----------------|-----------------|-----------------|-----------------|--------------|
| Yamaha       | MOTIF XS8     | Keyboard   | GKC-1648        | G-TOUR 88       |                 |                 |              |
| Yamaha       | MOTIF6        | Keyboard   | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |              |
| Yamaha       | MOTIF8        | Keyboard   | GKC-1648        | G-TOUR 88       |                 |                 |              |
| Yamaha       | MSR250        | Speaker    | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |              |
| Yamaha       | MSR400        | Speaker    | GPA-700         | GPA-SCVR450-515 |                 |                 |              |
| Yamaha       | MSR800W       | Speaker    | G-SUB2225-24BAG |                 |                 |                 |              |
| Yamaha       | MW10 USB      | Mixer      | G-MIX-B 1212    |                 |                 |                 |              |
| Yamaha       | MW12 USB      | Mixer      | GMC-2222        | G-MIX 19X21     | G-MIX-B 1815    | G-MIX-L 1618A   |              |
| Yamaha       | MX12/4        | Mixer      | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR 19X21 |
| Yamaha       | MX12/6        | Mixer      | GMC-2222        | G-MIX 19X21     | G-MIX-B 1818    | G-MIX-L 1618A   | G-TOUR 19X21 |
| Yamaha       | MX20/6        | Mixer      | G-MIX 20X30     | G-TOUR 20X30    |                 |                 |              |
| Yamaha       | MX200-12      | Mixer      | GMC-2222        | G-MIX-B 2519    | G-MIX-L 1926    |                 |              |
| Yamaha       | MX200-16      | Mixer      | GMC-3333        | G-MIX 24X36     | G-TOUR 20X30    | G-TOUR 24X36    |              |
| Yamaha       | MX200-24      | Mixer      | GMC-4221        |                 |                 |                 |              |
| Yamaha       | MX200-8       | Mixer      | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1822    | G-TOUR 19X21    | GX-1921-7.5  |
| Yamaha       | N8            | Mixer      | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118    | G-MIX-L 1822    | G-TOUR 19X21 |
| Yamaha       | O1V96         | Mixer      | GMC-2222        | G-MIX-B 2519    | G-MIX-L 1822    | G-MIX-L 1926    |              |
| Yamaha       | O1V96VCM      | Mixer      | GMC-2222        | G-MIX-B 2519    | G-MIX-L 1822    | G-MIX-L 1926    |              |
| Yamaha       | P120          | Keyboard   | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |              |
| Yamaha       | P120S         | Keyboard   | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |              |
| Yamaha       | P140          | Keyboard   | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |              |
| Yamaha       | P-150         | Keyboard   | GKB-88          | GKPE-88-TSA     | G-TOUR 88       |                 |              |
| Yamaha       | P155B         | Keyboard   | GK-88           | GKC-1648        | GKPE-88-TSA     | G-TOUR 88       |              |
| Yamaha       | P200          | Keyboard   | GKC-1648        | G-TOUR 88       |                 |                 |              |
| Yamaha       | P250          | Keyboard   | GKC-1648        |                 |                 |                 |              |
| Yamaha       | P60           | Keyboard   | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |              |
| Yamaha       | P60S          | Keyboard   | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |              |
| Yamaha       | P-70          | Keyboard   | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |              |
| Yamaha       | P85           | Keyboard   | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |              |
| Yamaha       | P90           | Keyboard   | GK-88 SLIM      | GKPE-88SLIM-TSA | G-TOUR 88 SLIM  |                 |              |
| Yamaha       | PDM-1         | LCD/Plasma | G-LCDCOVER-52   | G-TOURLCDP50    |                 |                 |              |
| Yamaha       | PF15          | Keyboard   | GK-88           | GKC-1648        | GKPE-88-TSA     | G-TOUR 88       |              |
| Yamaha       | PF500         | Keyboard   | GKC-1648        |                 |                 |                 |              |
| Yamaha       | PSR 175       | Keyboard   | GK-49           | GKPE-61-TSA     | G-TOUR 61       |                 |              |
| Yamaha       | PSR-172       | Keyboard   | GK-49           | GKPE-61-TSA     | G-TOUR 61       |                 |              |
| Yamaha       | PSR-273       | Keyboard   | GK-49           | G-TOUR 61       |                 |                 |              |
| Yamaha       | PSR-293       | Keyboard   | GKB-61          | GKPE-61-TSA     | G-TOUR 61       |                 |              |
| Yamaha       | PSR-3000      | Keyboard   | GK-61           | GKC-1540        |                 |                 |              |
| Yamaha       | PSR-E203      | Keyboard   | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |              |
| Yamaha       | PSR-E213      | Keyboard   | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |              |
| Yamaha       | PSR-E223      | Keyboard   | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |              |
| Yamaha       | PSR-E303      | Keyboard   | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |              |
| Yamaha       | PSR-E313      | Keyboard   | GK-49           | G-TOUR 61       |                 |                 |              |
| Yamaha       | PSR-E323      | Keyboard   | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |              |
| Yamaha       | PSR-E403      | Keyboard   | GKB-61          | GKPE-61-TSA     | G-TOUR 61       |                 |              |
| Yamaha       | PSR-E413      | Keyboard   | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |              |
| Yamaha       | PSR-OR700     | Keyboard   | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |              |
| Yamaha       | PSR-S500      | Keyboard   | GKB-61          | GKPE-61-TSA     | G-TOUR 61       |                 |              |
| Yamaha       | PSR-S550BK    | Keyboard   | GKB-61          | GKPE-61-TSA     | G-TOUR 61       |                 |              |
| Yamaha       | PSR-S700      | Keyboard   | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |              |
| Yamaha       | PSR-S900      | Keyboard   | GK-61           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |              |
| Yamaha       | RADIUS-R      | Mixer      | G-MIX 12X24     |                 |                 |                 |              |
| Yamaha       | S03           | Keyboard   | GK-4212         |                 |                 |                 |              |
| Yamaha       | S08           | Keyboard   | GK-88           | GKC-1648        | GKPE-88-TSA     | G-TOUR 88       |              |
| Yamaha       | S112V         | Speaker    | GPA-700         | GPA-SCVR450-515 |                 |                 |              |
| Yamaha       | S70 XS        | Keyboard   | GKC-1648        |                 |                 |                 |              |
| Yamaha       | S90           | Keyboard   | GKC-1648        | G-TOUR 88       |                 |                 |              |
| Yamaha       | S90ES         | Keyboard   | GKC-1648        | G-TOUR 88       |                 |                 |              |
| Yamaha       | S90XS         | Keyboard   | GKC-1648        |                 |                 |                 |              |
| Yamaha       | SM12V         | Speaker    | GPA-700         | GPA-SCVR450-515 |                 |                 |              |
| Yamaha       | STAGEPAS 250M | Speaker    | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |              |
| Yamaha       | STAGEPAS 500  | Speaker    | GPA-450-515     | GPA-777         | GPA-E15         | GPA-SCVR450-515 |              |
| Yamaha       | TYROS         | Keyboard   | GKC-1648        |                 |                 |                 |              |
| Yamaha       | TYROS2        | Keyboard   | GKC-1648        |                 |                 |                 |              |
| Yamaha       | TYROS3        | Keyboard   | GK-76           | GKC-1648        | GKPE-76-TSA     | G-TOUR 76       |              |
| Yamaha       | YPG225        | Keyboard   | GK-76           | GKC-1648        | GKPE-76-TSA     | G-TOUR 76       |              |
| Yamaha       | YPG-235       | Keyboard   | GK-76           | GKC-1648        | GKPE-76-TSA     | G-TOUR 76       |              |
| Yamaha       | YPG525        | Keyboard   | GK-88           | GKC-1648        | GKPE-88-TSA     | G-TOUR 88       |              |
| Yamaha       | YPG625        | Keyboard   | GK-88           | GKC-1648        | GKPE-88-TSA     | G-TOUR 88       |              |
| Yamaha       | YPT-200       | Keyboard   | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |              |
| Yamaha       | YPT-310       | Keyboard   | GK-49           | GKC-1540        | GKPE-61-TSA     | G-TOUR 61       |              |
| Yamaha       | YPT-400       | Keyboard   | GKB-61          | GKPE-61-TSA     | G-TOUR 61       |                 |              |
| Yorkville    | AP812         | Mixer      | G-MIX 20X25     | G-MIX-B 2519    | G-MIX-L 1926    | G-TOUR 20X30    |              |
| Yorkville    | AP818         | Mixer      | G-MIX 20X25     | G-MIX-B 2519    | G-MIX-L 1926    | G-TOUR 20X30    |              |
| Yorkville    | MAX16         | Mixer      | GMC-3333        | G-MIX 24X36     | G-TOUR 20X30    |                 |              |
| Yorkville    | MAX22         | Mixer      | GMC-4221        |                 |                 |                 |              |
| Zenith       | P42W22B       | LCD/Plasma | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                 |                 |              |
| Zenith       | P42W24B/P     | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |              |
| Zenith       | P42W34/34H    | LCD/Plasma | G-LCD-4042      | G-TOURLCD-3743T | G-TOURLCDLIFT52 |                 |              |

| Manufacturer | Model      | Type               | Fit (1)         | Fit (2)         | Fit (3)        | Fit (4)       | Fit (5)         |
|--------------|------------|--------------------|-----------------|-----------------|----------------|---------------|-----------------|
| Zenith       | P42W46X    | LCD/Plasma         | G-LCDCOVER-42   | G-TOURLCDLIFT52 |                |               |                 |
| Zenith       | P50W28B    | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50   |               |                 |
| Zenith       | P50W38/38H | LCD/Plasma         | G-LCD-5052      | G-TOURLCDLIFT52 | G-TOURLCDP50   |               |                 |
| Zoom         | G2         | Digital Audio Gear | G-MIX-B 1212    |                 |                |               |                 |
| Zoom         | G7         | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX 12X24     | G-MIX-B 1815   | G-MIX-L 1224  | G-MULTIFX-2411  |
| Zoom         | G7.1UT     | Digital Audio Gear | G-MEDIA PROBPXL | G-MIX 12X24     | G-MIX-B 1815   | G-MIX-L 1224  | G-MULTIFX-2411  |
| Zoom         | G92TT      | Digital Audio Gear | G-MIX-L 1224    |                 |                |               |                 |
| Zoom         | HD-16      | Mixer              | GMC-2222        | G-MIX-B 2118    | G-MIX-L 1622   | G-MIX-L 1724  | G-MIX-L 1822    |
| Zoom         | John 5 G1J | Digital Audio Gear | G-MIX-B 1212    |                 |                |               |                 |
| Zoom         | MRS1044    | Digital Audio Gear | GMC-2222        | G-MEDIA PROBPXL | G-MIX-B 1815   | G-MIX-L 1618A | G-MULTIFX-2411  |
| Zoom         | MRS1608CD  | Digital Audio Gear | GMC-2222        | G-MIX 20X25     | G-MIX-B 2118   | G-MIX-L 1822  | G-TOUR 19X21    |
| Zoom         | MRS4B      | Digital Audio Gear | G-MIX-B 1212    |                 |                |               |                 |
| Zoom         | MRS-8      | Digital Audio Gear | G-MEDIA PRO BP  | G-MULTIFX-1510  |                |               |                 |
| Zoom         | MRS802BCD  | Digital Audio Gear | GMC-2222        | G-MIX-L 1618A   | G-MULTIFX-2411 | G-TOUR 12X17  | G-TOURCARRYONFO |
| Zoom         | RT223      | Digital Audio Gear | G-MIX-B 1212    |                 |                |               |                 |
| Zoom         | SB246      | Digital Audio Gear | G-MIX-B 1212    |                 |                |               |                 |

This list is intended as a guide; not a substitute for testing the actual fit of an instrument. All product information referenced above is based on the manufacturer's published specifications. These specifications may change over time and without notice. If you have questions on a specific case or product, or see that a correction is needed, please contact Gator Customer Service at 813.221.4191 or send us an email at [info@gatorcases.com](mailto:info@gatorcases.com).



# Master Cross Reference Chart

## Interior Case Dimenisons

### Standard

| Model           | Length | Width | Height | Overall Length | Lower Bout Width | Middle Bout Width | Upper Bout Width | Body Length | Body Height |
|-----------------|--------|-------|--------|----------------|------------------|-------------------|------------------|-------------|-------------|
| <b>GUITAR</b>   |        |       |        |                |                  |                   |                  |             |             |
| G-112A          | 25     | 12    | 19.5   |                |                  |                   |                  |             |             |
| G-112-ROTO      | 23.5   | 12.5  | 21     |                |                  |                   |                  |             |             |
| G-212A          | 30     | 12    | 24     |                |                  |                   |                  |             |             |
| G-212-ROTO      | 26.75  | 12.5  | 21     |                |                  |                   |                  |             |             |
| G-901           | 30     | 10.5  | 12.5   |                |                  |                   |                  |             |             |
| GC-BASS         |        |       |        | 47.5           | 13.75            | 13.75             | 13.75            | 21.25       | 3           |
| GC-DREAD        |        |       |        | 41.75          | 16.5             | 12.5              | 13               | 23          | 5.25        |
| GC-DREAD-12     |        |       |        | 43.625         | 16.25            | 11.75             | 12.375           | 23.625      | 5.25        |
| GC-ELECTRIC-A   |        |       |        | 40             | 12.75            | 12.75             | 12.75            | 19.38       | 3.25        |
| GC-ELEC-XL      |        |       |        | 42             | 12.75            | 12.75             | 12.75            | 18.75       | 3.5         |
| GC-JUMBO        |        |       |        | 44             | 17.25            | 11                | 12.5             | 21          | 5.5         |
| GC-LPS          |        |       |        | 41.25          | 13.25            | 7.75              | 9.25             | 18          | 3.75        |
| G-COBRA-BASS    |        |       |        | 47             | 15               | 13                | 12               | 21          | 3.5         |
| G-COBRA-CLASS   |        |       |        | 40.5           | 15.25            | 10.25             | 11.5             | 20          | 3.75        |
| G-COBRA-DREAD   |        |       |        | 41.5           | 16               | 13                | 12               | 22          | 5.5         |
| G-COBRA-ELEC    |        |       |        | 38             | 12.75            | 14.75             | 14.5             | 20          | 3.5         |
| G-COM-BASS      |        |       |        | 47             | 15               | 13                | 12               | 21          | 3.5         |
| G-COM-DREAD     |        |       |        | 41.5           | 16               | 13                | 12               | 22          | 5.5         |
| G-COM-ELEC      |        |       |        | 38             | 12.75            | 14.75             | 14.5             | 20          | 3.5         |
| GC-SG           |        |       |        | 40.5           | 13.5             | 10                | 11               | 17          | 2.25        |
| GL-AC-BASS      |        |       |        | 50.5           | 17.25            | 12                | 13.75            | 25          | 6.5         |
| GL-BASS         |        |       |        | 47.5           | 13.63            | 13.63             | 13.63            | 21          | 3           |
| GL-CLASSIC      |        |       |        | 41             | 15.5             | 10.25             | 11.75            | 20.5        | 4.5         |
| GL-DREAD        |        |       |        | 41.75          | 16               | 12.5              | 12.5             | 21.25       | 5           |
| GL-DREAD-12     |        |       |        | 43             | 16               | 12.5              | 13               | 21.5        | 5           |
| GL-ELECTRIC     |        |       |        | 39.5           | 12.75            | 12.75             | 12.75            | 19          | 3.38        |
| GL-JUMBO        |        |       |        | 44.625         | 17.625           | 11.375            | 13               | 23.25       | 5.5         |
| GL-LPS          |        |       |        | 42.25          | 13.875           | 9.375             | 10               | 21.625      | 3.375       |
| GL-SG           |        |       |        | 40.375         | 13.625           | 9.875             | 11.125           | 17.75       | 2           |
| G-MULTIFX-1110  | 11.25  | 10.25 | 4.25   |                |                  |                   |                  |             |             |
| G-MULTIFX-1510  | 15.5   | 10.5  | 5      |                |                  |                   |                  |             |             |
| G-MULTIFX-2411  | 24     | 11.25 | 4.75   |                |                  |                   |                  |             |             |
| GPE-335-TSA     |        |       |        | 43             | 16.5             | 11.5              | 13               | 22.5        | 4.5         |
| GPE-BASS-TSA    |        |       |        | 47.625         | 13.625           | 13.625            | 13.625           | 21.125      | 2.625       |
| GPE-CLASSIC-TSA |        |       |        | 40             | 15.5             | 10.5              | 11.5             | 21.25       | 4.5         |
| GPE-DREAD-TSA   |        |       |        | 41.5           | 16.5             | 12.75             | 13.75            | 22.5        | 4.75        |
| GPE-ELEC-TSA    |        |       |        | 39.5           | 12.75            | 12.75             | 12.75            | 19.25       | 3.25        |
| GPE-LPS-TSA     |        |       |        | 42             | 13.25            | 7.75              | 9.5              | 18.5        | 3.25        |
| GSLING-BASS     |        |       |        | 47.5           | 16               | 14                | 12.5             | 21          | 2.5         |
| GSLING-CLASS    |        |       |        | 40.5           | 16               | 13.5              | 11.5             | 20          | 4           |
| GSLING-DREAD    |        |       |        | 42.5           | 15.5             | 12.5              | 12.75            | 22          | 4           |
| GSLING-ELEC     |        |       |        | 40.5           | 15.25            | 14                | 14.5             | 22          | 4           |
| G-TOUR AMP HEAD | 32     | 12    | 14     |                |                  |                   |                  |             |             |
| G-TOUR AMP2226  | 26     | 13    | 22     |                |                  |                   |                  |             |             |
| G-TOUR AMP2430  | 30     | 13    | 24     |                |                  |                   |                  |             |             |
| G-TOUR BASS     |        |       |        | 46             | 14               | 11                | 13               | 21          | 2.5         |
| G-TOUR DREAD-12 |        |       |        | 43.5           | 16.75            | 11.5              | 12               | 22.25       | 5.75        |
| G-TOUR ELEC     |        |       |        | 40.13          | 12.75            | 12.75             | 12.75            | 19.25       | 2.5         |
| G-TOUR LPS      |        |       |        | 40             | 13               | 13                | 13               | 18          | 3.5         |
| G-TOUR-4X12-CAB | 32     | 17    | 32     |                |                  |                   |                  |             |             |
| GW-BASS         |        |       |        | 47             | 13               | 13                | 13               | 21.75       | 3.75        |
| GW-BASS-TW      |        |       |        | 46.25          | 13               | 13                | 13               | 21.25       | 3.5         |
| GW-CLASSIC      |        |       |        | 41             | 15.5             | 11.5              | 12               | 23.25       | 5           |
| GW-CLASSIC-TW   |        |       |        | 41.5           | 15               | 11.5              | 11.75            | 20          | 3.75        |
| GW-DREAD        |        |       |        | 43             | 16.5             | 11.75             | 12               | 22.25       | 5.5         |
| GW-DREAD-TW     |        |       |        | 42.5           | 16.5             | 12.25             | 12.75            | 18.25       | 5.5         |
| GWE-ACOU-3/4    |        |       |        | 38             | 13.75            | 9.75              | 10.25            | 19          | 4.75        |
| GWE-BASS        |        |       |        | 46.75          | 12.75            | 12.75             | 12.75            | 22          | 3.25        |
| GWE-CLASSIC     |        |       |        | 40.75          | 14.5             | 10.5              | 11.5             | 23.5        | 4.5         |
| GWE-DREAD 12    |        |       |        | 43.5           | 16.875           | 13.125            | 13.625           | 22.5        | 5.5         |
| GWE-ELEC        |        |       |        | 39.5           | 13               | 13                | 13               | 18.875      | 3.125       |
| GWE-ELEC TW     |        |       |        | 39.5           | 12.68            | 12.68             | 12.68            | 18.33       | 3.32        |
| GW-ELECTRIC     |        |       |        | 40.5           | 12.5             | 12.5              | 12.5             | 19          | 3.25        |
| GW-ELECTRIC-TW  |        |       |        | 40             | 12.75            | 12.75             | 12.75            | 18.75       | 3           |
| GW-ELECT-VIN    |        |       |        | 40             | 12.75            | 12.75             | 12.75            | 18.75       | 3           |
| GWE-LPS CAMO    |        |       |        | 40             | 14               | 9.75              | 10               | 21.25       | 4.5         |

| Model       | Length | Width | Height | Overall Length | Lower Bout Width | Middle Bout Width | Upper Bout Width | Body Length | Body Height |
|-------------|--------|-------|--------|----------------|------------------|-------------------|------------------|-------------|-------------|
| GWE-LPS-BLK |        |       |        | 40             | 14               | 9.75              | 10               | 21.25       | 4.5         |
| GW-JUMBO    |        |       |        | 44.5           | 17.25            | 11.25             | 13               | 23.5        | 5.5         |
| GW-JUMBO-TW |        |       |        | 44.5           | 17.25            | 11.25             | 13               | 23.5        | 5.5         |
| GW-LP-BROWN |        |       |        | 39.5           | 13.5             | 9.5               | 9.5              | 20.5        | 4.25        |
| GW-LPS      |        |       |        | 39.5           | 13.5             | 9.5               | 9.5              | 20.5        | 4.25        |
| GW-LPS-TW   |        |       |        | 39.5           | 13.5             | 9.5               | 9.5              | 20.5        | 4.25        |
| GW-SG-BROWN |        |       |        | 40.5           | 13               | 9                 | 10.5             | 19.75       | 3.25        |

### KEYBOARD

|                 |       |       |      |  |  |  |  |  |  |
|-----------------|-------|-------|------|--|--|--|--|--|--|
| GK-2110         | 22.5  | 11.5  | 4    |  |  |  |  |  |  |
| GK-4212         | 42.25 | 12    | 5.5  |  |  |  |  |  |  |
| GK-49           | 38    | 15    | 5.5  |  |  |  |  |  |  |
| GK-61           | 43    | 17.5  | 6.5  |  |  |  |  |  |  |
| GK-76           | 51.5  | 18    | 6.25 |  |  |  |  |  |  |
| GK-88           | 57.5  | 18    | 6    |  |  |  |  |  |  |
| GK-88 SLIM      | 54    | 15    | 6    |  |  |  |  |  |  |
| GKB-49          | 37    | 15    | 5    |  |  |  |  |  |  |
| GKB-61          | 43    | 17.5  | 6.5  |  |  |  |  |  |  |
| GKB-76          | 51.5  | 18    | 6.25 |  |  |  |  |  |  |
| GKB-88          | 57.5  | 18    | 6.25 |  |  |  |  |  |  |
| GKB-88 SLIM     | 54    | 15    | 6    |  |  |  |  |  |  |
| GKC-1540        | 43    | 17.5  | 6.5  |  |  |  |  |  |  |
| GKC-1648        | 59.1  | 23    | 7    |  |  |  |  |  |  |
| GK-LT25W        | 25    | 12    | 3    |  |  |  |  |  |  |
| GKPE-49-TSA     | 36.5  | 12.5  | 4    |  |  |  |  |  |  |
| GKPE-61-TSA     | 44    | 17.38 | 6    |  |  |  |  |  |  |
| GKPE-76D-TSA    | 51.25 | 20    | 8    |  |  |  |  |  |  |
| GKPE-76-TSA     | 51.25 | 18    | 6    |  |  |  |  |  |  |
| GKPE-88SLIM-TSA | 54    | 15    | 6    |  |  |  |  |  |  |
| GKPE-88SLXL-TSA | 59    | 15    | 6    |  |  |  |  |  |  |
| GKPE-88-TSA     | 59    | 19    | 6.63 |  |  |  |  |  |  |
| G-TOUR 61       | 44    | 17.38 | 6    |  |  |  |  |  |  |
| G-TOUR 76       | 51.25 | 18    | 6    |  |  |  |  |  |  |
| G-TOUR 88       | 59    | 19    | 6.63 |  |  |  |  |  |  |
| G-TOUR 88 SLIM  | 54    | 15    | 6    |  |  |  |  |  |  |

### DJ AND RECORDING

|                 |      |    |      |  |  |  |  |  |  |
|-----------------|------|----|------|--|--|--|--|--|--|
| GDJ-2500        | 18   | 17 | 6.5  |  |  |  |  |  |  |
| G-MEDIA PRO BP  | 15   | 12 | 4    |  |  |  |  |  |  |
| G-MEDIA PROBPXL | 20   | 12 | 4    |  |  |  |  |  |  |
| G-TOUR CD-13X17 | 17   | 13 | 4.25 |  |  |  |  |  |  |
| G-TOUR CD-9X12  | 12.5 | 9  | 4.25 |  |  |  |  |  |  |
| G-TOUR CDMX1317 | 17   | 13 | 4.25 |  |  |  |  |  |  |
| G-TOUR CDMX912  | 12.5 | 9  | 4.25 |  |  |  |  |  |  |

### PROJECTOR AND LAPTOP

|                 |       |      |     |  |  |  |  |  |  |
|-----------------|-------|------|-----|--|--|--|--|--|--|
| GAV-1412-R      | 14    | 12   | 4   |  |  |  |  |  |  |
| GAV-1813-UR     | 18    | 13   | 4   |  |  |  |  |  |  |
| GAV-20          | 14    | 10.5 | 3.5 |  |  |  |  |  |  |
| GAV-DLX-1412R   | 14    | 12   | 4   |  |  |  |  |  |  |
| GAV-DLX-20      | 14    | 10.5 | 3.5 |  |  |  |  |  |  |
| GAV-PE-1412R    | 14    | 12   | 4   |  |  |  |  |  |  |
| G-TOURCARRYONPL | 11.15 | 9.06 | 5.9 |  |  |  |  |  |  |

### LCD

|                 |       |   |       |  |  |  |  |  |  |
|-----------------|-------|---|-------|--|--|--|--|--|--|
| G-LCD-4042      | 41.5  | 5 | 30    |  |  |  |  |  |  |
| G-LCD-4647      | 45.5  | 5 | 30    |  |  |  |  |  |  |
| G-LCD-5052      | 52    | 5 | 32    |  |  |  |  |  |  |
| G-LCDCOVER-3819 | 38    | 6 | 19    |  |  |  |  |  |  |
| G-LCDCOVER-42   | 43    | 6 | 26    |  |  |  |  |  |  |
| G-LCDCOVER-52   | 52    | 6 | 33    |  |  |  |  |  |  |
| G-LCDCOVER-65   | 63    | 6 | 40    |  |  |  |  |  |  |
| G-TOURLCD-3743T | 42.5  | 7 | 28    |  |  |  |  |  |  |
| G-TOURLCDLIFT52 | 52    | 7 | 34    |  |  |  |  |  |  |
| G-TOURLCDLIFT65 | 66    | 7 | 38    |  |  |  |  |  |  |
| G-TOURLCDP-2023 | 24    | 7 | 20.13 |  |  |  |  |  |  |
| G-TOURLCDP-2632 | 32.5  | 7 | 25.75 |  |  |  |  |  |  |
| G-TOURLCDP50    | 50.13 | 8 | 32.5  |  |  |  |  |  |  |
| G-TOURLCDP60    | 58.33 | 8 | 36.25 |  |  |  |  |  |  |

### MICROPHONE

|           |     |     |      |  |  |  |  |  |  |
|-----------|-----|-----|------|--|--|--|--|--|--|
| GM-1W     | 8.5 | 8.5 | 2    |  |  |  |  |  |  |
| GM-1WEVAA | 8   | 8   | 1.75 |  |  |  |  |  |  |
| GM-1WP    | 8.5 | 8.5 | 2    |  |  |  |  |  |  |
| GM-2W     | 8.5 | 8.5 | 3.25 |  |  |  |  |  |  |
| GM-4WR    | 11  | 16  | 1.5  |  |  |  |  |  |  |

| Model           | Length | Width | Height | Overall Length | Lower Bout Width | Middle Bout Width | Upper Bout Width | Body Length | Body Height |
|-----------------|--------|-------|--------|----------------|------------------|-------------------|------------------|-------------|-------------|
| GM-5W           | 8.5    | 7     | 4      |                |                  |                   |                  |             |             |
| GM-7W           | 9.5    | 5.5   | 1.75   |                |                  |                   |                  |             |             |
| G-TOUR WIRELES4 |        |       |        |                |                  |                   |                  |             |             |
| <b>MIXER</b>    |        |       |        |                |                  |                   |                  |             |             |
| GMC-2222        | 22     | 22    | 6      |                |                  |                   |                  |             |             |
| GMC-3333        | 33     | 33    | 6      |                |                  |                   |                  |             |             |
| GMC-4221        | 42     | 21    | 6      |                |                  |                   |                  |             |             |
| G-MIX 12X24     | 23.25  | 12    | 4.25   |                |                  |                   |                  |             |             |
| G-MIX 17X18     | 17.75  | 17.25 | 6.5    |                |                  |                   |                  |             |             |
| G-MIX 19X21     | 21     | 19    | 7      |                |                  |                   |                  |             |             |
| G-MIX 20X25     | 25     | 20    | 8      |                |                  |                   |                  |             |             |
| G-MIX 20X30     | 29.13  | 20    | 6      |                |                  |                   |                  |             |             |
| G-MIX 22X46     | 46     | 22    | 6.5    |                |                  |                   |                  |             |             |
| G-MIX 24X36     | 35.13  | 24    | 6.5    |                |                  |                   |                  |             |             |
| G-MIX-B 1212    | 12     | 11.75 | 5.5    |                |                  |                   |                  |             |             |
| G-MIX-B 1515    | 15.13  | 14.75 | 5.5    |                |                  |                   |                  |             |             |
| G-MIX-B 1815    | 18.5   | 15    | 6.5    |                |                  |                   |                  |             |             |
| G-MIX-B 1818    | 18     | 17.75 | 5.5    |                |                  |                   |                  |             |             |
| G-MIX-B 2020    | 20     | 20    | 5.5    |                |                  |                   |                  |             |             |
| G-MIX-B 2118    | 21     | 18.5  | 7      |                |                  |                   |                  |             |             |
| G-MIX-B 2519    | 25     | 19    | 8      |                |                  |                   |                  |             |             |
| G-MIX-L 1224    | 24     | 12    | 5      |                |                  |                   |                  |             |             |
| G-MIX-L 1618A   | 18     | 16    | 6      |                |                  |                   |                  |             |             |
| G-MIX-L 1622    | 22     | 16    | 5      |                |                  |                   |                  |             |             |
| G-MIX-L 1724    | 24     | 17    | 5      |                |                  |                   |                  |             |             |
| G-MIX-L 1822    | 22     | 18    | 7      |                |                  |                   |                  |             |             |
| G-MIX-L 1926    | 26     | 19    | 6      |                |                  |                   |                  |             |             |
| G-TOUR 12X17    | 17     | 12    | 7.5    |                |                  |                   |                  |             |             |
| G-TOUR 19X21    | 21     | 19    | 7      |                |                  |                   |                  |             |             |
| G-TOUR 20X25    | 25     | 20    | 8      |                |                  |                   |                  |             |             |
| G-TOUR 20X30    | 30     | 20    | 6.5    |                |                  |                   |                  |             |             |
| G-TOUR 24X36    | 36     | 24    | 5.5    |                |                  |                   |                  |             |             |
| <b>SPEAKER</b>  |        |       |        |                |                  |                   |                  |             |             |
| GPA-450-515     | 15     | 15.75 | 26     |                |                  |                   |                  |             |             |
| GPA-600         | 16.5   | 16.5  | 23.25  |                |                  |                   |                  |             |             |
| GPA-700         | 17.5   | 18    | 27.5   |                |                  |                   |                  |             |             |
| GPA-720         | 13     | 13.5  | 20     |                |                  |                   |                  |             |             |
| GPA-777         | 17.5   | 18    | 27.5   |                |                  |                   |                  |             |             |
| GPA-E15         | 15     | 15.75 | 26     |                |                  |                   |                  |             |             |
| GPA-SCVR450-515 | 14.8   | 17.3  | 27     |                |                  |                   |                  |             |             |
| G-SUB2225-24BAG | 22     | 24    | 26.25  |                |                  |                   |                  |             |             |
| <b>UTILITY</b>  |        |       |        |                |                  |                   |                  |             |             |
| GP-PC300        | 45     | 19    | 12     |                |                  |                   |                  |             |             |
| GP-PC301        | 30     | 24    | 16     |                |                  |                   |                  |             |             |
| GP-PC303        | 29     | 17    | 17     |                |                  |                   |                  |             |             |
| GP-PC304        | 36     | 16    | 12     |                |                  |                   |                  |             |             |
| GP-PC308        | 30     | 12    | 14     |                |                  |                   |                  |             |             |
| GP-PC309        | 24     | 12    | 24     |                |                  |                   |                  |             |             |
| GP-PC314        | 25     | 12    | 10     |                |                  |                   |                  |             |             |
| G-TOUR 12X17    | 17     | 12    | 7.5    |                |                  |                   |                  |             |             |
| G-TOURCARRYONFO | 19     | 12.25 | 4.5    |                |                  |                   |                  |             |             |
| GX-1            | 17.5   | 12.25 | 5.25   |                |                  |                   |                  |             |             |
| GX-1224-8       | 24     | 12    | 8      |                |                  |                   |                  |             |             |
| GX-1718-7       | 18     | 17    | 7      |                |                  |                   |                  |             |             |
| GX-1921-7.5     | 21     | 19    | 7.5    |                |                  |                   |                  |             |             |
| GX-1928-17      | 28     | 19    | 17     |                |                  |                   |                  |             |             |
| GX-2            | 17.5   | 12.25 | 7.75   |                |                  |                   |                  |             |             |
| GX-3            | 17.5   | 12.25 | 7.75   |                |                  |                   |                  |             |             |
| GX-42           | 32.75  | 16.25 | 7.25   |                |                  |                   |                  |             |             |
| GX-BAG-1313-15  | 15     | 13    | 13     |                |                  |                   |                  |             |             |
| GX-BAG-2112-12  | 21     | 12    | 12     |                |                  |                   |                  |             |             |



# Master Cross Reference Chart

## Interior Case Dimensions

Metric

| Model           | Length | Width | Height | Overall Length | Lower Bout Width | Middle Bout Width | Upper Bout Width | Body Length | Body Height |
|-----------------|--------|-------|--------|----------------|------------------|-------------------|------------------|-------------|-------------|
| <b>GIUITAR</b>  |        |       |        |                |                  |                   |                  |             |             |
| G-112A          | 635    | 305   | 495    |                |                  |                   |                  |             |             |
| G-112-ROTO      | 597    | 318   | 533    |                |                  |                   |                  |             |             |
| G-212A          | 762    | 305   | 610    |                |                  |                   |                  |             |             |
| G-212-ROTO      | 679    | 318   | 533    |                |                  |                   |                  |             |             |
| G-901           | 762    | 267   | 318    |                |                  |                   |                  |             |             |
| GC-BASS         |        |       |        | 1207           | 349              | 349               | 349              | 540         | 76          |
| GC-DREAD        |        |       |        | 1060           | 419              | 318               | 330              | 584         | 133         |
| GC-DREAD-12     |        |       |        | 1108           | 413              | 298               | 314              | 600         | 133         |
| GC-ELECTRIC-A   |        |       |        | 1016           | 324              | 324               | 324              | 492         | 83          |
| GC-ELEC-XL      |        |       |        | 1067           | 324              | 324               | 324              | 476         | 89          |
| GC-JUMBO        |        |       |        | 1118           | 438              | 279               | 318              | 533         | 140         |
| GC-LPS          |        |       |        | 1048           | 337              | 197               | 235              | 457         | 95          |
| G-COBRA-BASS    |        |       |        | 1194           | 381              | 330               | 305              | 533         | 89          |
| G-COBRA-CLASS   |        |       |        | 1029           | 387              | 260               | 292              | 508         | 95          |
| G-COBRA-DREAD   |        |       |        | 1054           | 406              | 330               | 305              | 559         | 140         |
| G-COBRA-ELEC    |        |       |        | 965            | 324              | 375               | 368              | 508         | 89          |
| G-COM-BASS      |        |       |        | 1194           | 381              | 330               | 305              | 533         | 89          |
| G-COM-DREAD     |        |       |        | 1054           | 406              | 330               | 305              | 559         | 140         |
| G-COM-ELEC      |        |       |        | 965            | 324              | 375               | 368              | 508         | 89          |
| GC-SG           |        |       |        | 1029           | 343              | 254               | 279              | 432         | 57          |
| GL-AC-BASS      |        |       |        | 1283           | 438              | 305               | 349              | 635         | 165         |
| GL-BASS         |        |       |        | 1207           | 346              | 346               | 346              | 533         | 76          |
| GL-CLASSIC      |        |       |        | 1041           | 394              | 260               | 298              | 521         | 114         |
| GL-DREAD        |        |       |        | 1060           | 406              | 318               | 318              | 540         | 127         |
| GL-DREAD-12     |        |       |        | 1092           | 406              | 318               | 330              | 546         | 127         |
| GL-ELECTRIC     |        |       |        | 1003           | 324              | 324               | 324              | 483         | 86          |
| GL-JUMBO        |        |       |        | 1133           | 448              | 289               | 330              | 591         | 140         |
| GL-LPS          |        |       |        | 1073           | 352              | 238               | 254              | 549         | 86          |
| GL-SG           |        |       |        | 1026           | 346              | 251               | 283              | 451         | 51          |
| G-MULTIFX-1110  | 286    | 260   | 108    |                |                  |                   |                  |             |             |
| G-MULTIFX-1510  | 394    | 267   | 127    |                |                  |                   |                  |             |             |
| G-MULTIFX-2411  | 610    | 286   | 121    |                |                  |                   |                  |             |             |
| GPE-335-TSA     |        |       |        | 1092           | 419              | 292               | 330              | 572         | 114         |
| GPE-BASS-TSA    |        |       |        | 1210           | 346              | 346               | 346              | 537         | 67          |
| GPE-CLASSIC-TSA |        |       |        | 1016           | 394              | 267               | 292              | 540         | 114         |
| GPE-DREAD-TSA   |        |       |        | 1054           | 419              | 324               | 349              | 572         | 121         |
| GPE-ELEC-TSA    |        |       |        | 1003           | 324              | 324               | 324              | 489         | 83          |
| GPE-LPS-TSA     |        |       |        | 1067           | 337              | 197               | 241              | 470         | 83          |
| GSLING-BASS     |        |       |        | 1207           | 406              | 356               | 318              | 533         | 64          |
| GSLING-CLASS    |        |       |        | 1029           | 406              | 343               | 292              | 508         | 102         |
| GSLING-DREAD    |        |       |        | 1080           | 394              | 318               | 324              | 559         | 102         |
| GSLING-ELEC     |        |       |        | 1029           | 387              | 356               | 368              | 559         | 102         |
| G-TOUR AMP HEAD | 813    | 305   | 356    |                |                  |                   |                  |             |             |
| G-TOUR AMP2226  | 660    | 330   | 559    |                |                  |                   |                  |             |             |
| G-TOUR AMP2430  | 762    | 330   | 610    |                |                  |                   |                  |             |             |
| G-TOUR BASS     |        |       |        | 1168           | 356              | 279               | 330              | 533         | 64          |
| G-TOUR DREAD-12 |        |       |        | 1105           | 425              | 292               | 305              | 565         | 146         |
| G-TOUR ELEC     |        |       |        | 1019           | 324              | 324               | 324              | 489         | 64          |
| G-TOUR LPS      |        |       |        | 1016           | 330              | 330               | 330              | 457         | 89          |
| G-TOUR-4X12-CAB | 813    | 432   | 813    |                |                  |                   |                  |             |             |
| GW-BASS         |        |       |        | 1194           | 330              | 330               | 330              | 552         | 95          |
| GW-BASS-TW      |        |       |        | 1175           | 330              | 330               | 330              | 540         | 89          |
| GW-CLASSIC      |        |       |        | 1041           | 394              | 292               | 305              | 591         | 127         |
| GW-CLASSIC-TW   |        |       |        | 1054           | 381              | 292               | 298              | 508         | 95          |
| GW-DREAD        |        |       |        | 1092           | 419              | 298               | 305              | 565         | 140         |
| GW-DREAD-TW     |        |       |        | 1080           | 419              | 311               | 324              | 464         | 140         |
| GWE-ACOU-3/4    |        |       |        | 965            | 349              | 248               | 260              | 483         | 121         |
| GWE-BASS        |        |       |        | 1187           | 324              | 324               | 324              | 559         | 83          |
| GWE-CLASSIC     |        |       |        | 1035           | 368              | 267               | 292              | 597         | 114         |
| GWE-DREAD 12    |        |       |        | 1105           | 429              | 333               | 346              | 572         | 140         |
| GWE-ELEC        |        |       |        | 1003           | 330              | 330               | 330              | 479         | 79          |
| GWE-ELEC TW     |        |       |        | 1003           | 322              | 322               | 322              | 466         | 84          |
| GW-ELECTRIC     |        |       |        | 1029           | 318              | 318               | 318              | 483         | 83          |
| GW-ELECTRIC-TW  |        |       |        | 1016           | 324              | 324               | 324              | 476         | 76          |
| GW-ELECT-VIN    |        |       |        | 1016           | 324              | 324               | 324              | 476         | 76          |
| GWE-LPS CAMO    |        |       |        | 1016           | 356              | 248               | 254              | 540         | 114         |



| Model       | Length | Width | Height | Overall Length | Lower Bout Width | Middle Bout Width | Upper Bout Width | Body Length | Body Height |
|-------------|--------|-------|--------|----------------|------------------|-------------------|------------------|-------------|-------------|
| GWE-LPS-BLK |        |       |        | 1016           | 356              | 248               | 254              | 540         | 114         |
| GW-JUMBO    |        |       |        | 1130           | 438              | 286               | 330              | 597         | 140         |
| GW-JUMBO-TW |        |       |        | 1130           | 438              | 286               | 330              | 597         | 140         |
| GW-LP-BROWN |        |       |        | 1003           | 343              | 241               | 241              | 521         | 108         |
| GW-LPS      |        |       |        | 1003           | 343              | 241               | 241              | 521         | 108         |
| GW-LPS-TW   |        |       |        | 1003           | 343              | 241               | 241              | 521         | 108         |
| GW-SG-BROWN |        |       |        | 1029           | 330              | 229               | 267              | 502         | 83          |

### KEYBOARD

|                 |      |     |     |  |  |  |  |  |  |
|-----------------|------|-----|-----|--|--|--|--|--|--|
| GK-2110         | 572  | 292 | 102 |  |  |  |  |  |  |
| GK-4212         | 1073 | 305 | 140 |  |  |  |  |  |  |
| GK-49           | 965  | 381 | 140 |  |  |  |  |  |  |
| GK-61           | 1092 | 445 | 165 |  |  |  |  |  |  |
| GK-76           | 1308 | 457 | 159 |  |  |  |  |  |  |
| GK-88           | 1461 | 457 | 152 |  |  |  |  |  |  |
| GK-88 SLIM      | 1372 | 381 | 152 |  |  |  |  |  |  |
| GKB-49          | 940  | 381 | 127 |  |  |  |  |  |  |
| GKB-61          | 1092 | 445 | 165 |  |  |  |  |  |  |
| GKB-76          | 1308 | 457 | 159 |  |  |  |  |  |  |
| GKB-88          | 1461 | 457 | 159 |  |  |  |  |  |  |
| GKB-88 SLIM     | 1372 | 381 | 152 |  |  |  |  |  |  |
| GKC-1540        | 1092 | 445 | 165 |  |  |  |  |  |  |
| GKC-1648        | 1501 | 584 | 178 |  |  |  |  |  |  |
| GK-LT25W        | 635  | 305 | 76  |  |  |  |  |  |  |
| GKPE-49-TSA     | 927  | 318 | 102 |  |  |  |  |  |  |
| GKPE-61-TSA     | 1118 | 441 | 152 |  |  |  |  |  |  |
| GKPE-76D-TSA    | 1302 | 508 | 203 |  |  |  |  |  |  |
| GKPE-76-TSA     | 1302 | 457 | 152 |  |  |  |  |  |  |
| GKPE-88SLIM-TSA | 1372 | 381 | 152 |  |  |  |  |  |  |
| GKPE-88SLXL-TSA | 1499 | 381 | 152 |  |  |  |  |  |  |
| GKPE-88-TSA     | 1499 | 483 | 168 |  |  |  |  |  |  |
| G-TOUR 61       | 1118 | 441 | 152 |  |  |  |  |  |  |
| G-TOUR 76       | 1302 | 457 | 152 |  |  |  |  |  |  |
| G-TOUR 88       | 1499 | 483 | 168 |  |  |  |  |  |  |
| G-TOUR 88 SLIM  | 1372 | 381 | 152 |  |  |  |  |  |  |

### DJ AND RECORDING

|                 |     |     |     |  |  |  |  |  |  |
|-----------------|-----|-----|-----|--|--|--|--|--|--|
| GDJ-2500        | 457 | 432 | 165 |  |  |  |  |  |  |
| G-MEDIA PRO BP  | 381 | 305 | 102 |  |  |  |  |  |  |
| G-MEDIA PROBPXL | 508 | 305 | 102 |  |  |  |  |  |  |
| G-TOUR CD-13X17 | 432 | 330 | 108 |  |  |  |  |  |  |
| G-TOUR CD-9X12  | 318 | 229 | 108 |  |  |  |  |  |  |
| G-TOUR CDMX1317 | 432 | 330 | 108 |  |  |  |  |  |  |
| G-TOUR CDMX912  | 318 | 229 | 108 |  |  |  |  |  |  |

### PROJECTOR AND LAPTOP

|                 |     |     |     |  |  |  |  |  |  |
|-----------------|-----|-----|-----|--|--|--|--|--|--|
| GAV-1412-R      | 356 | 305 | 102 |  |  |  |  |  |  |
| GAV-1813-UR     | 457 | 330 | 102 |  |  |  |  |  |  |
| GAV-20          | 356 | 267 | 89  |  |  |  |  |  |  |
| GAV-DLX-1412R   | 356 | 305 | 102 |  |  |  |  |  |  |
| GAV-DLX-20      | 356 | 267 | 89  |  |  |  |  |  |  |
| GAV-PE-1412R    | 356 | 305 | 102 |  |  |  |  |  |  |
| G-TOURCARRYONPL | 283 | 230 | 150 |  |  |  |  |  |  |

### LCD

|                 |      |     |      |  |  |  |  |  |  |
|-----------------|------|-----|------|--|--|--|--|--|--|
| G-LCD-4042      | 1054 | 127 | 762  |  |  |  |  |  |  |
| G-LCD-4647      | 1156 | 127 | 762  |  |  |  |  |  |  |
| G-LCD-5052      | 1321 | 127 | 813  |  |  |  |  |  |  |
| G-LCDCOVER-3819 | 965  | 152 | 483  |  |  |  |  |  |  |
| G-LCDCOVER-42   | 1092 | 152 | 660  |  |  |  |  |  |  |
| G-LCDCOVER-52   | 1321 | 152 | 838  |  |  |  |  |  |  |
| G-LCDCOVER-65   | 1600 | 152 | 1016 |  |  |  |  |  |  |
| G-TOURLCD-3743T | 1080 | 178 | 711  |  |  |  |  |  |  |
| G-TOURLCDLIFT52 | 1321 | 178 | 864  |  |  |  |  |  |  |
| G-TOURLCDLIFT65 | 1676 | 178 | 965  |  |  |  |  |  |  |
| G-TOURLCDP-2023 | 610  | 178 | 511  |  |  |  |  |  |  |
| G-TOURLCDP-2632 | 826  | 178 | 654  |  |  |  |  |  |  |
| G-TOURLCDP50    | 1273 | 203 | 826  |  |  |  |  |  |  |
| G-TOURLCDP60    | 1482 | 203 | 921  |  |  |  |  |  |  |

### MICROPHONE

|           |     |     |    |  |  |  |  |  |  |
|-----------|-----|-----|----|--|--|--|--|--|--|
| GM-1W     | 216 | 216 | 51 |  |  |  |  |  |  |
| GM-1WEVAA | 203 | 203 | 44 |  |  |  |  |  |  |
| GM-1WP    | 216 | 216 | 51 |  |  |  |  |  |  |
| GM-2W     | 216 | 216 | 83 |  |  |  |  |  |  |
| GM-4WR    | 279 | 406 | 38 |  |  |  |  |  |  |

| Model           | Length | Width | Height | Overall Length | Lower Bout Width | Middle Bout Width | Upper Bout Width | Body Length | Body Height |
|-----------------|--------|-------|--------|----------------|------------------|-------------------|------------------|-------------|-------------|
| GM-5W           | 216    | 178   | 102    |                |                  |                   |                  |             |             |
| GM-7W           | 241    | 140   | 44     |                |                  |                   |                  |             |             |
| G-TOUR WIRELES4 |        |       |        |                |                  |                   |                  |             |             |
| <b>MIXER</b>    |        |       |        |                |                  |                   |                  |             |             |
| GMC-2222        | 559    | 559   | 152    |                |                  |                   |                  |             |             |
| GMC-3333        | 838    | 838   | 152    |                |                  |                   |                  |             |             |
| GMC-4221        | 1067   | 533   | 152    |                |                  |                   |                  |             |             |
| G-MIX 12X24     | 591    | 305   | 108    |                |                  |                   |                  |             |             |
| G-MIX 17X18     | 451    | 438   | 165    |                |                  |                   |                  |             |             |
| G-MIX 19X21     | 533    | 483   | 178    |                |                  |                   |                  |             |             |
| G-MIX 20X25     | 635    | 508   | 203    |                |                  |                   |                  |             |             |
| G-MIX 20X30     | 740    | 508   | 152    |                |                  |                   |                  |             |             |
| G-MIX 22X46     | 1168   | 559   | 165    |                |                  |                   |                  |             |             |
| G-MIX 24X36     | 892    | 610   | 165    |                |                  |                   |                  |             |             |
| G-MIX-B 1212    | 305    | 298   | 140    |                |                  |                   |                  |             |             |
| G-MIX-B 1515    | 384    | 375   | 140    |                |                  |                   |                  |             |             |
| G-MIX-B 1815    | 470    | 381   | 165    |                |                  |                   |                  |             |             |
| G-MIX-B 1818    | 457    | 451   | 140    |                |                  |                   |                  |             |             |
| G-MIX-B 2020    | 508    | 508   | 140    |                |                  |                   |                  |             |             |
| G-MIX-B 2118    | 533    | 470   | 178    |                |                  |                   |                  |             |             |
| G-MIX-B 2519    | 635    | 483   | 203    |                |                  |                   |                  |             |             |
| G-MIX-L 1224    | 610    | 305   | 127    |                |                  |                   |                  |             |             |
| G-MIX-L 1618A   | 457    | 406   | 152    |                |                  |                   |                  |             |             |
| G-MIX-L 1622    | 559    | 406   | 127    |                |                  |                   |                  |             |             |
| G-MIX-L 1724    | 610    | 432   | 127    |                |                  |                   |                  |             |             |
| G-MIX-L 1822    | 559    | 457   | 178    |                |                  |                   |                  |             |             |
| G-MIX-L 1926    | 660    | 483   | 152    |                |                  |                   |                  |             |             |
| G-TOUR 12X17    | 432    | 305   | 191    |                |                  |                   |                  |             |             |
| G-TOUR 19X21    | 533    | 483   | 178    |                |                  |                   |                  |             |             |
| G-TOUR 20X25    | 635    | 508   | 203    |                |                  |                   |                  |             |             |
| G-TOUR 20X30    | 762    | 508   | 165    |                |                  |                   |                  |             |             |
| G-TOUR 24X36    | 914    | 610   | 140    |                |                  |                   |                  |             |             |
| <b>SPEAKER</b>  |        |       |        |                |                  |                   |                  |             |             |
| GPA-450-515     | 381    | 400   | 660    |                |                  |                   |                  |             |             |
| GPA-600         | 419    | 419   | 591    |                |                  |                   |                  |             |             |
| GPA-700         | 445    | 457   | 699    |                |                  |                   |                  |             |             |
| GPA-720         | 330    | 343   | 508    |                |                  |                   |                  |             |             |
| GPA-777         | 445    | 457   | 699    |                |                  |                   |                  |             |             |
| GPA-E15         | 381    | 400   | 660    |                |                  |                   |                  |             |             |
| GPA-SCVR450-515 | 376    | 439   | 686    |                |                  |                   |                  |             |             |
| G-SUB2225-24BAG | 559    | 610   | 667    |                |                  |                   |                  |             |             |
| <b>UTILITY</b>  |        |       |        |                |                  |                   |                  |             |             |
| GP-PC300        | 1143   | 483   | 305    |                |                  |                   |                  |             |             |
| GP-PC301        | 762    | 610   | 406    |                |                  |                   |                  |             |             |
| GP-PC303        | 737    | 432   | 432    |                |                  |                   |                  |             |             |
| GP-PC304        | 914    | 406   | 305    |                |                  |                   |                  |             |             |
| GP-PC308        | 762    | 305   | 356    |                |                  |                   |                  |             |             |
| GP-PC309        | 610    | 305   | 610    |                |                  |                   |                  |             |             |
| GP-PC314        | 635    | 305   | 254    |                |                  |                   |                  |             |             |
| G-TOUR 12X17    | 432    | 305   | 191    |                |                  |                   |                  |             |             |
| G-TOURCARRYONFO | 483    | 311   | 114    |                |                  |                   |                  |             |             |
| GX-1            | 445    | 311   | 133    |                |                  |                   |                  |             |             |
| GX-1224-8       | 610    | 305   | 203    |                |                  |                   |                  |             |             |
| GX-1718-7       | 457    | 432   | 178    |                |                  |                   |                  |             |             |
| GX-1921-7.5     | 533    | 483   | 191    |                |                  |                   |                  |             |             |
| GX-1928-17      | 711    | 483   | 432    |                |                  |                   |                  |             |             |
| GX-2            | 445    | 311   | 197    |                |                  |                   |                  |             |             |
| GX-3            | 445    | 311   | 197    |                |                  |                   |                  |             |             |
| GX-42           | 832    | 413   | 184    |                |                  |                   |                  |             |             |
| GX-BAG-1313-15  | 381    | 330   | 330    |                |                  |                   |                  |             |             |
| GX-BAG-2112-12  | 533    | 305   | 305    |                |                  |                   |                  |             |             |